



2.1 Channel Sound Bar with Dolby Audio & Wireless Subwoofer 6110 Series



# **User Manual**

# Contents

1	Before you begin	3
2	Welcome	4
_	What's in the box	4
	Overview of the Sound Bar main unit	6
	Overview of the wireless subwoofer	8
	Overview of the remote control	9
	Set up your Sound Bar system	11
	Mount your Sound Bar main unit on the wall	11
	Position your subwoofer	15
	Install/replace the remote control batteries	15
3	Connect your Sound Bar system	17
	Connect with an HDMI cable	17
	Connect with an optical cable	19
	Connect with a 3.5mm-to-3.5mm audio cable	21
	Connect your Sound Bar to power supply	22
	Connect the Sound Bar with your Bluetooth device	23
	Connect your wireless subwoofer to the Sound Bar	25
4	Use your Sound Bar system	27
7	Use your Sound Bar with the top panel or remote	_'
	control	27
	Sound settings	29

	Use the USB cable or device	31
5	Specifications	33
6	Notice Declaration of conformity	34 34
	Disposal of your old product and battery	34
	Trademarks	36
7	FAQ	37

# 1 Before you begin


- Carefully read and observe all safety instructions in the safety leaflet
- This soundbar is intended for indoor use only. In case it accidentally gets in contact with small amounts of water, unplug immediately and use a dry cloth to remove the water.
- Unplug the soundbar if it is not used for long periods of time or during lightning storms.
- Make sure the soundbar is installed on a solid surface or solidly wall-mounted below your TV for the best experience.
- Only use AAA 1.5V non-rechargeable batteries for the remote control.
- In case any of the cables are visibly damaged or pinched, unplug the soundbar and replace the cable.
- Be careful not to sharply bend HDMI and optical cables as they may affect the performance.
- Protect your hearing by adjusting to a proper volume.

## 2 Welcome

Congratulations on the purchase of your new TCL Sound Bar! After it is set up and connected, you can experience a superb sound quality and state-of-the-art design to best fit your home entertainment system. You are recommended to read through this user manual which helps you set up, connect and operate the product easily and properly.

## Let's get started.

## What's in the box





AC power cord x 2



Wall anchor x 2



Wall mounting screw x 2




Wall mount bracket x 2



Safety leaflet




Quick Start Guide



Wall mount template

## Overview of the Sound Bar main unit



- 1  $\circlearrowleft$  Press to turn the Sound Bar main unit on or to standby mode.
- 2 EP
  Press to switch the audio source among
  HDMI/Optical/AUX/USB/Bluetooth modes.
- 3 \* Press to select the Bluetooth function. Press and hold to enter the pairing mode.

#### 4 **+**/-

Press to increase or decrease the volume level.

#### 5 LED indicator

Red: in standby mode.

Purple: in HDMI ARC mode.

Green: in AUX mode.

Blue: in Bluetooth mode.

Yellow: in Optical mode.


Cyan: in USB mode.


#### 6 Sound Mode LED indicator

Flashing mode of LED indicators for MUSIC / MOVIE / TV.

- 7 AC input power connector
- 8 AUX input connector
- 9 Optical input connector
- 10 HDMI ARC connector
- 11 USB Type A connector

#### Overview of the wireless subwoofer





#### 1 AC input power connector


#### 2 Amber LED indicator

- flashes slowly when the subwoofer is in standby mode.
- flashes quickly when pairing is in progress.
- · remains on solidly when pairing is successful.

#### 3 PAIR

Press and hold  $\rightleftharpoons$  button on the Sound Bar main unit or the remote control, 4 LEDs flash. Press and hold **PAIR** button on the subwoofer till the pairing finished. And then the amber LED keep lighting up on the subwoofer.

## Overview of the remote control



- 1 ①
  Press to turn the Sound Bar on or to standby mode.
  Long press to reset the Sound Bar.
- 2 K Press to mute or unmute the sound.
- 3 +/-Press to increase or decrease the volume level.

#### 4 **►**II

Play/pause/resume playback in Bluetooth/USB mode. In Bluetooth mode, press and hold for 3 seconds to disconnect the Bluetooth device and enter pairing status.

#### 5 **M**/**M**

Press to skip to previous or next track in Bluetooth/USB mode.

- 6 →
  - Press to switch the audio source among HDMI/Optical/AUX/USB/Bluetooth modes.
- 7 Ress to switch the audio source to Bluetooth mode.

#### 8 MOVIE / MUSIC / TV

Press to select the equalizer (EQ) effect when you are watching **TV** or **movie** or listening to **music**.


## Set up your Sound Bar system

#### **Notes**


- Make sure you read all the safety information before you mount the Sound Bar main unit on the wall.
- Make sure you use screws provided or specified by the authorized manufacturer.
- TCL Overseas Marketing Limited bears no responsibility for accidents or damage caused by improper wall mounting and screws installation or insufficient wall strength, etc.
- Additional tools (not supplied) are required for installation.

## Mount your Sound Bar main unit on the wall


You can choose to place your Sound Bar main unit below the center of your TV or mount it on the wall.




- Place the supplied wall mount template on the wall. Make sure the wall mount template is at least 5cm below the center of the TV.
- 2 Use a level to make sure the wall mount template is positioned accurately.
- 3 Use the tape to stick the wall mount template firmly on the wall
- 4 Mark on the wall using each marking on the template through the mounting holes.
- 5 Take away the wall mount template.
- 6 Drill a screw hole at each marking on the wall.



- 7 Screw off the rubber cushions from the sound bar. (Reserve the rubber cushions for future use)
- 8 Screw on the wall brackets to the sound bar.
- 9 Insert the supplied screws into the wall anchors.
- 10 Fix and tighten the screws on the wall, and please leave 4mm between the screw heads and the wall.




#### 11 Hang the Sound Bar main unit on the screws.



- Check the installation location before you mount the Sound Bar on the wall (see 'Mount your Sound Bar main unit on the wall' on page 11).
- You may consider to connect the cables first before mounting the Sound Bar on the wall.

## Position your subwoofer

The distance between the subwoofer and the Sound Bar main unit should be within 3 meters.



## Install/replace the remote control batteries

#### Warnings

Danger of explosion if battery is incorrectly replaced.
 Replace only with the same or equivalent type.

- 1 Open the battery compartment, remove the old batteries if necessary.
- Place two new AAA batteries into the battery compartment with the correct polarity (+/-).
- 3 Close the battery compartment.



# 3 Connect your Sound Bar system

After you have fixed the position of the Sound Bar main unit, you can start connecting it to your TV or other devices and listen to the audio through your Sound Bar. Make sure you have muted the audio of your TV or device. For information, check the user manual of your TV or device.

#### Connect with an HDMI cable


#### Note

 Make sure your TV or device supports the HDMI ARC feature. For information, check the user manual of your TV or device.

Connect one end of an HDMI cable to the HDMI ARC input connector on your Sound Bar main unit and another end to the HDMI ARC output connector of your TV or device.

To get the best possible audio experience using an HDMI cable, follow below given steps:


- Connect your Sound Bar to HDMI input marked (ARC) on your TCL TV.
- Press the **Settings** button on your TCL TV remote.
- 234 Navigate to System options.
- Set T-Link on the TV to On. (This feature may be called. Anynet+, SimpLink, BRAVIA Link, EasyLink or VIERA Link\*.)



\* All technology names mentioned are the trademarks or registered trademarks of their respective companies.

## Connect with an optical cable

- 1 Remove the protective caps from an optical cable when necessary.
- 2 Connect one end of an optical cable to the optical input connector on your Sound Bar main unit and another end to the optical output connector of your TV or device.



#### Note

 In case you are not hearing any sound when using HDMI or optical, please go into your TV settings menu and switch audio output to PCM.

#### Direction for setting up your Sound Bar using an optical cable



Do not bend or kink an optical cable (SPDIF) as it is fragile and can easily get damaged and broken.



To get the best possible audio experience using the optical cable.

- 1 Press the Home button on your TCL TV Remote.
- Navigate to **Audio** option under **Settings**.
- 2 Uncheck the "TV speaker enabled" option.
- Under S/PDIF and ARC, select PCM-Stereo.


#### Notes

- · Different devices may have different menu options.
- Devices such as Blu-ray players, set-top boxes, etc. are also applicable.

# Connect with a 3.5mm-to-3.5mm audio cable


#### You can either:

- connect one end of a 3.5mm-to-3.5mm audio cable to the AUX input connector on your Sound Bar main unit and another end to the headphone or audio output connector on your TV or device. This will disable the sound of your TV built-in speakers; or
- connect one end of an RCA-to-3.5mm audio cable to the AUX input connector on your Sound Bar main unit and other ends to the TV's audio output connectors.



# Connect your Sound Bar to power supply

- Make sure that you have completed all other connections before connecting the Sound Bar to power supply.
- 2 Make sure the power supply voltage complies with your country's safety standards (see 'Specifications' on page 33)
- 3 Connect one end of another supplied AC power cord to the AC input connector on your subwoofer and another end to the power socket on the wall.
- 4 Connect one end of a supplied AC power cord to the AC input connector on your Sound Bar main unit and another end to the power socket on the wall.




# Connect the Sound Bar with your Bluetooth device

#### **Notes**

- Make sure your wireless device supports the Bluetooth function.
- The operational range between the Sound Bar main unit and your Bluetooth device is approximately 10 meters (without any obstacle between the Bluetooth device and Sound Bar main unit).
- 1 Press  $\circlearrowleft$  on the top panel of your Sound Bar main unit or remote control to power on the Sound Bar.
- 2 Press and hold \*\* on the top panel of your Sound Bar main unit or remote control.
  - → The blue LED flashes quickly. The Sound Bar is ready to pair.
- 3 Power on your Bluetooth device and activate its Bluetooth function.
- 4 Select **TCL 6110** on the pairing list of your Bluetooth device.
  - → You hear distinct double beep sound.
  - → The blue LED remains on solidly when pairing is successful.

#### Tip

 If you cannot find the model name TCL 6110 on your Bluetooth device, press and hold ►II on the remote control. You will see the blue LED flashes rapidly. Now the Sound Bar main unit is entering the pairing mode.



Your Sound Bar system is now set up and ready to use.

- 5 To disconnect the Bluetooth function, you can:
  - press on the Sound Bar main unit or remote control to switch to another source; or
  - · disable the Bluetooth function on your device; or
  - press and hold >II on the remote control for 3 seconds.


# Connect your wireless subwoofer to the Sound Bar

When the wireless subwoofer is connected, you can enjoy powerful deep bass sounds and a truly immersive audio experience.

#### Auto pairing

Make sure both the Sound Bar and wireless subwoofer are connected to the power supply and are turned on.

- → The Sound Bar will pair with the subwoofer automatically.
- → The amber LED will flash when pairing is in progress.
- → The amber LED will remain on solidly when pairing is successful.



#### Note

 Do not press PAIR at the back of the wireless subwoofer during auto pairing.

#### Manual pairing

- 1 Make sure the Sound Bar and wireless subwoofer are properly connected to the power supply.
- Press and hold button on the Sound Bar main unit or the remote control,
  - → 4 LEDs flash.
- 3 Press and hold PAIR at the back of the wireless subwoofer until the amber LED on the subwoofer flashes quickly.
  - → The wireless subwoofer is ready to pair.
  - → Pairing is successful. The amber LED remains on solidly.

#### Note

 If the amber LED at the back of the subwoofer still flashes after pairing, it means pairing is not successful. Disconnect the AC power cord from the wireless subwoofer and then connect again after 3 minutes. Then repeat steps 1 to 3.

# 4 Use your Sound Bar system

# Use your Sound Bar with the top panel or remote control

- 1 Make sure the Sound Bar is properly connected to the power supply and sources.
- Press at the top panel of your Sound Bar main unit or remote control to switch to the correct source.

#### LED behaviors under different source modes

LED indicators	Source mode
Red	In standby mode
Purple	in HDMI ARC mode
Green	in AUX mode
Blue	in Bluetooth mode
Blue LED flashes slowly	search the paired devices
Blue LED flashes quickly	pairing in progress
Yellow	in Optical mode
Cyan	in USB mode
Yellow LED flashes 3 times	Denotes sound bar is receiving Dolby Audio

<sup>\*</sup> PCM audio format does not show on the display

#### Note

 After powering on your Sound Bar, if there is no operation performed on either the Sound Bar main unit or remote control within 10 seconds, all LED indicators on the Sound Bar main unit will turn off and light up again when the operation is resumed.

#### Tip

 You can use more advanced functions on the remote control (see 'Overview of the remote control' on page 9).

## Sound settings

You can enjoy your movies or music with your ideal sound.

- Press +/- to adjust the volume.
- Press ¾ on the remote control to mute the sound. Press ¾ again to unmute the sound.
- Press the EQ buttons (MOVIE/MUSIC/TV) on the remote control to select the equalizer (EQ) effect when you are watching TV or movies or listening to music.

Symbo	I Operation	LED indicators
+	Volume up	The four white LEDs light up gradually from left to right
_	Volume down	The four white LEDs fade gradually from right to left
Volume up to Maximum		The four white LEDs flash twice
Volume down to Minimum		The left white LED flashes twice
×	Mute the Sound	The white LED keeps flashing
	nmute the Sound	Show the current volume
Select the equalizer (EQ)		MUSIC • • •
		MOVIE -₩- • • -₩-
		TV • • • •

# Listen to music from your Bluetooth device


- Make sure that your device supports A2DP and/or AVRCP. For information, check the specification of your device.
- Pair your Bluetooth device with the Sound Bar main unit (see 'Connect the Sound Bar with your Bluetooth device' on page 23).
- 3 Start listening to music stored in your Bluetooth device through the Sound Bar.
  - If your Bluetooth device supports A2DP, you can listen to music, but you cannot control the playback.
  - If your Bluetooth device supports AVRCP, you can listen to music and control music playback with the remote control. Press ►II to pause or resume music playback. Press ►I to skip to the previous/next track.

#### Note

 The operational range between the Sound Bar main unit and your Bluetooth device is approximately 10 meters (without any obstacle between the Bluetooth device and the Sound Bar main unit).

#### Use the USB cable or device

- 1 Connect the USB device to the USB Type A connector on your Sound Bar main unit.
- Press ∃ on the Sound Bar main unit or remote control. until the cyan LED is on.
- 3 You can now listen to music through the Sound Bar.
  - To pause or resume music, press ►II on the remote control.
  - To skip to the previous or next track, press ⋈ or ⋈ on the remote control.



Operation	LED indicators
Listen to music.	The cyan LED is on.
Press II to pause the music.	The cyan LED keeps flashing

#### Tip

 This Sound Bar can support USB devices of up to 32GB memory and the supported file format is MP3.

# 5 Specifications

#### Sound Bar main unit

- Power adapter: AC~100-240V, 50/60Hz
- Power consumption: 20W
- Power consumption at standby mode: ≤ 0.5W
- Impedance: 6 Ω
- Frequency response: 150 Hz-20 kHz
- Dimensions (WxHxD): 800x62x107mm
- Weight: 1.8 kg
- Operating temperature: 0°C 45°C

#### Wireless subwoofer

- Power adapter: AC~100-240V, 50/60Hz
- Power consumption: 25W
- Power consumption at standby mode: ≤ 0.5W
- Frequency response: 40 Hz-120 Hz
- Frequency range: 2402 MHz 2480 MHz
- Max transmitting power: 13dBm
- Dimensions (WxHxD): 200x326x200mm
- Weight: 3.3 kg

#### **Bluetooth**

- Bluetooth version: 4.2, Bluetooth profile Bluetooth stereo supported (Advanced Audio Distribution Profile -A2DP; Audio Video Remote Control Profile - AVRCP)
- Frequency range: 2402 Mhz 2480 Mhz
- Max transmitting power: 13dBm

#### Remote control

- Distance/Angle: 6m/ 30°
- Battery type: 1.5V AAA battery x 2, user replaceable.

## 6 Notice

## Declaration of conformity

Hereby, TCL Overseas Marketing Limited declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. You can find the Declaration of Conformity on www.tcl.com.

# Disposal of your old product and battery



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



This symbol on a product means that the product is covered by European Directive 2012/19/EU.



This symbol means that the product contains a battery covered by European Directive 2013/56/EU which cannot be disposed of with normal household waste. Inform yourself about the local separate collection system for electrical and electronic products and batteries. Follow local rules and never dispose of the product and batteries with normal household waste. Correct disposal of old products and batteries helps prevent negative consequences for the environment and human health.

#### Remove the disposable battery

To remove the disposable batteries, see the section 'Replace the remote control battery'.

#### **Environmental protection and sustainability**

We have omitted all unnecessary packaging and make sure it is eco-friendly and sustainable.

#### **Trademarks**



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by TTE Corporation is under license. Other trademarks and trade names are those of their respective owners.

# **Dolby** Audio

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.



The Adopted Trademarks HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

# 7 FAQ

#### No power

- Make sure the AC power cord and AC input connector are connected properly.
- Make sure there is power supply.
- Make sure the Sound Bar has turned on.

#### No sound

- Make sure the audio cable is connected to the Sound Bar and your device.
- Make sure you have selected the correct source.
- Press + to increase the volume level.
- Make sure the Sound Bar is not muted.

#### The remote control does not work.

- Make sure you have selected the correct source.
- Make sure the distance of remote control and the Sound Bar main unit is within operational range.
- Make sure the battery is correctly inserted and is working.
- Make sure the remote control is close to the remote control sensor of the Sound Bar main unit.

#### I hear distorted sound.

- Make sure all cables are properly connected.
- Make sure you have selected the correct source.
- Make sure the TV is muted if you play audio from the TV.

I cannot find the Bluetooth name of this Sound Bar on my Bluetooth device.

- Make sure the Bluetooth function is activated on your Bluetooth device.
- Make sure the Sound Bar has paired with your Bluetooth device.

The LED indicator of the subwoofer is off.

 Reset the subwoofer by disconnecting the power supply and reconnecting after 2 minutes.

#### **TCL** support:

Please visit www.tcl.com

# WE ARE READY TO HELP contact us first with any questions

A TAKE CARE WHEN REMOVING THE SOUND BAR

