

Questo manuale d'istruzione è fornito da [trovamezzi.it](https://www.sony.it). Scopri tutte le offerte per **Sony WF-C700N Nero** o cerca il tuo prodotto tra le **migliori offerte di Cuffie e Microfoni**

SONY

Wireless Noise Cancelling Stereo Headset

Reference guide
Guide de référence
Referenzanleitung
Guia de referencia

Guida di riferimento
Referenzanleitung
Referenzanleitung
Referenzanleitung

https://rdl.sony.net/help/mdr/2968/h_zz/



WF-C700N

Model: YY2968

5-047-127-41(1)



* 5 0 4 7 1 2 7 4 1 * (1)

©2023 Sony Corporation

Printed in Vietnam

<https://www.sony.net/>

English

Wireless Noise Cancelling Stereo Headset

Model: YY2968
The term "product" in this document refers to the unit or its accessories.

Do not install the product in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed to excessive heat, such as sunlight, fire, or the like, for a long time.

Do not subject the batteries to extreme low-temperature conditions that may result in overheating and thermal runaway.

Do not dismantle, open, or chew secondary batteries. In the event of a secondary battery leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.

Secondary batteries need to be charged before use. Always refer to the manufacturer's instructions or product manual for proper charging instructions.

After extended periods of storage, it may be necessary to charge and discharge the secondary batteries several times to obtain maximum performance.

Dispose of properly.

Notice for customers: the following information is only applicable to products sold in countries/regions applying EU directives and/or UK applying relevant statutory requirements.

This product has been manufactured by or on behalf of Sony Corporation, Japan.

EU and UK Importer: Sony Europe BV. Inquiries to the EU Importer or related to product compliance in Europe should be sent to the manufacturer's authorized representative, Sony Belgium, bijkantoor van Sony Europe BV, Da Vincklaan 8-D1, 1930 Zaventem, Belgium.

Do not place the unit in water or use it in a humid place such as a bathroom.

Do not drop the unit or expose it to mechanical shock. Doing so may deform or damage the unit, resulting in deterioration of water resistance performance.

The full text of the EU declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

CE

Hereby, Sony Corporation declares that this equipment is in compliance with the UK relevant statutory requirements.

The full text of the declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

UK CA

Disposal of waste materials and electrical and electronic equipment applicable in the European Union and other countries with separate collection systems

This symbol on the product, the battery or on the packaging indicates that the product and the battery shall not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. The chemical symbol for lead (Pb) is added if the battery contains more than 0.004% lead. By ensuring that these products and batteries are disposed of correctly, you will help to prevent potentially negative consequences for the environment and human health which could be caused by inappropriate waste handling. The recycling of waste materials will help to conserve natural resources. In case of products that require special performance or data integrity reasons require a permanent information or record, the incorporated battery, this battery should be replaced by you and disposed of separately. Please ensure that the battery and the electrical and electronic equipment will be treated properly, hand over these products at end-of-life to the appropriate collection point for the recycling of waste materials and electronic equipment. For all other batteries and electrical equipment, for the removal of the battery from the product, safely hand the battery (batteries) to the appropriate collection point for the recycling of waste materials and electronic equipment. For all other batteries and electrical equipment, for the removal of the battery from the product, safely hand the battery (batteries) to the appropriate collection point for the recycling of waste materials and electronic equipment.

Do not use the unit while walking, driving, or cycling. Do not use the unit as a traffic aid.

Do not use the unit in hazardous areas unless the surrounding sound can be heard.

If a foreign or foreign matter enters the unit, it may result in fire or electric shock. If water or other liquid enters the unit, stop use immediately and consult your nearest Sony retailer. In particular, be careful in the following cases:

• When using the unit near a sink or liquid container, be careful that the unit does not fall into a sink or container filled with water.

• When using the unit in the rain or snow, or in humid locations.

For details on the effects of contact with the unit from the mobile phone or other wireless devices connected to the unit, refer to the instruction manual of the wireless device.

If the earbuds tips are not securely attached before use, the earbuds tips are not securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter in the unit or charging cable, and cause abnormal heat generation or malfunction.

Use the earbuds tips as they are. Do not use the unit if the earbuds tips are not securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter in the unit or charging cable, and cause abnormal heat generation or malfunction.

Use the earbuds tips as they are. Do not use the unit if the earbuds tips are not securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter in the unit or charging cable, and cause abnormal heat generation or malfunction.

Use the earbuds tips as they are. Do not use the unit if the earbuds tips are not securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter in the unit or charging cable, and cause abnormal heat generation or malfunction.

Use the earbuds tips as they are. Do not use the unit if the earbuds tips are not securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter in the unit or charging cable, and cause abnormal heat generation or malfunction.

Use the earbuds tips as they are. Do not use the unit if the earbuds tips are not securely attached before use.

This product has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

This product has magnet(s). Swallowing magnet(s) is cause of serious harm, such as choking hazard or intestinal injuries. If magnet(s) (or a magnet) were swallowed, consult a doctor immediately. Keep this product away from children or other supervised individuals to prevent accidental ingestion.

There is a danger that this unit is in small parts may be swallowed. After use, store the unit in a safe place.

Do not use the unit in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed to excessive heat, such as sunlight, fire, or the like, for a long time.

Do not subject the batteries to extreme low-temperature conditions that may result in overheating and thermal runaway.

Do not dismantle, open, or chew secondary batteries. In the event of a secondary battery leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.

Secondary batteries need to be charged before use. Always refer to the manufacturer's instructions or product manual for proper charging instructions.

After extended periods of storage, it may be necessary to charge and discharge the secondary batteries several times to obtain maximum performance.

Dispose of properly.

Notice for customers: the following information is only applicable to products sold in countries/regions applying EU directives and/or UK applying relevant statutory requirements.

This product has been manufactured by or on behalf of Sony Corporation, Japan.

EU and UK Importer: Sony Europe BV. Inquiries to the EU Importer or related to product compliance in Europe should be sent to the manufacturer's authorized representative, Sony Belgium, bijkantoor van Sony Europe BV, Da Vincklaan 8-D1, 1930 Zaventem, Belgium.

Do not place the unit in water or use it in a humid place such as a bathroom.

Do not drop the unit or expose it to mechanical shock. Doing so may deform or damage the unit, resulting in deterioration of water resistance performance.

The full text of the EU declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

CE

Hereby, Sony Corporation declares that this equipment is in compliance with the UK relevant statutory requirements.

The full text of the declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

UK CA

Disposal of waste materials and electrical and electronic equipment applicable in the European Union and other countries with separate collection systems

This symbol on the product, the battery or on the packaging indicates that the product and the battery shall not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. The chemical symbol for lead (Pb) is added if the battery contains more than 0.004% lead. By ensuring that these products and batteries are disposed of correctly, you will help to prevent potentially negative consequences for the environment and human health which could be caused by inappropriate waste handling. The recycling of waste materials will help to conserve natural resources. In case of products that require special performance or data integrity reasons require a permanent information or record, the incorporated battery, this battery should be replaced by you and disposed of separately. Please ensure that the battery and the electrical and electronic equipment will be treated properly, hand over these products at end-of-life to the appropriate collection point for the recycling of waste materials and electronic equipment. For all other batteries and electrical equipment, for the removal of the battery from the product, safely hand the battery (batteries) to the appropriate collection point for the recycling of waste materials and electronic equipment. For all other batteries and electrical equipment, for the removal of the battery from the product, safely hand the battery (batteries) to the appropriate collection point for the recycling of waste materials and electronic equipment.

Do not use the unit while walking, driving, or cycling. Do not use the unit as a traffic aid.

Do not use the unit in hazardous areas unless the surrounding sound can be heard.

If a foreign or foreign matter enters the unit, it may result in fire or electric shock. If water or other liquid enters the unit, stop use immediately and consult your nearest Sony retailer. In particular, be careful in the following cases:

• When using the unit near a sink or liquid container, be careful that the unit does not fall into a sink or container filled with water.

• When using the unit in the rain or snow, or in humid locations.

For details on the effects of contact with the unit from the mobile phone or other wireless devices connected to the unit, refer to the instruction manual of the wireless device.

If the earbuds tips are not securely attached before use, the earbuds tips are not securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter in the unit or charging cable, and cause abnormal heat generation or malfunction.

Use the earbuds tips as they are. Do not use the unit if the earbuds tips are not securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter in the unit or charging cable, and cause abnormal heat generation or malfunction.

Use the earbuds tips as they are. Do not use the unit if the earbuds tips are not securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter in the unit or charging cable, and cause abnormal heat generation or malfunction.

Use the earbuds tips as they are. Do not use the unit if the earbuds tips are not securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter in the unit or charging cable, and cause abnormal heat generation or malfunction.

Use the earbuds tips as they are. Do not use the unit if the earbuds tips are not securely attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the USB plug is inserted while the unit or charging cable is wet, a short circuit may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign matter in the unit or charging cable, and cause abnormal heat generation or malfunction.

Use the earbuds tips as they are. Do not use the unit if the earbuds tips are not securely attached before use.

Trademarks

• The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.

• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "and" marks are not specified.

Licenses

• This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of the copyright for the software. Please access the following URL and read the contents of the license.

<https://rdl.sony.net/help/mdr/r/23/>

• Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Franglais

Caque stéro sans fil à réduction de bruit

Model: YY2968
Le terme "produit" dans ce document désigne l'appareil ou ses accessoires.

N'installez pas le produit dans un espace étroit, tel qu'une armoire ou une armoire encastrée. Ne soumettez pas les batteries à des conditions de température extrêmement basses qui pourraient entraîner une surchauffe et un emballement thermique.

Ne démontez pas, n'ouvrez pas et ne démontez pas les batteries rechargeables.

En cas de fuite d'une batterie rechargeable, ne laissez pas le liquide entrer en contact avec la peau ou les yeux. Si le contact a été établi, lavez la zone touchée avec de grandes quantités d'eau et consultez un médecin.

Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées.

Ne démontez pas, n'ouvrez pas et ne démontez pas les batteries rechargeables.

En cas de fuite d'une batterie rechargeable, ne laissez pas le liquide entrer en contact avec la peau ou les yeux. Si le contact a été établi, lavez la zone touchée avec de grandes quantités d'eau et consultez un médecin.

Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées.

Ne démontez pas, n'ouvrez pas et ne démontez pas les batteries rechargeables.

En cas de fuite d'une batterie rechargeable, ne laissez pas le liquide entrer en contact avec la peau ou les yeux. Si le contact a été établi, lavez la zone touchée avec de grandes quantités d'eau et consultez un médecin.

Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées.

Ne démontez pas, n'ouvrez pas et ne démontez pas les batteries rechargeables.

En cas de fuite d'une batterie rechargeable, ne laissez pas le liquide entrer en contact avec la peau ou les yeux. Si le contact a été établi, lavez la zone touchée avec de grandes quantités d'eau et consultez un médecin.

Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées.

Ne démontez pas, n'ouvrez pas et ne démontez pas les batteries rechargeables.

En cas de fuite d'une batterie rechargeable, ne laissez pas le liquide entrer en contact avec la peau ou les yeux. Si le contact a été établi, lavez la zone touchée avec de grandes quantités d'eau et consultez un médecin.

Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées.

Ne démontez pas, n'ouvrez pas et ne démontez pas les batteries rechargeables.

En cas de fuite d'une batterie rechargeable, ne laissez pas le liquide entrer en contact avec la peau ou les yeux. Si le contact a été établi, lavez la zone touchée avec de grandes quantités d'eau et consultez un médecin.

Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées.

Ne démontez pas, n'ouvrez pas et ne démontez pas les batteries rechargeables.

En cas de fuite d'une batterie rechargeable, ne laissez pas le liquide entrer en contact avec la peau ou les yeux. Si le contact a été établi, lavez la zone touchée avec de grandes quantités d'eau et consultez un médecin.

Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées.

Ne démontez pas, n'ouvrez pas et ne démontez pas les batteries rechargeables.

En cas de fuite d'une batterie rechargeable, ne laissez pas le liquide entrer en contact avec la peau ou les yeux. Si le contact a été établi, lavez la zone touchée avec de grandes quantités d'eau et consultez un médecin.

Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées.

Ne démontez pas, n'ouvrez pas et ne démontez pas les batteries rechargeables.

En cas de fuite d'une batterie rechargeable, ne laissez pas le liquide entrer en contact avec la peau ou les yeux. Si le contact a été établi, lavez la zone touchée avec de grandes quantités d'eau et consultez un médecin.

Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées. Les batteries rechargeables doivent être chargées.

Ne démontez pas, n'ouvrez pas et ne démontez pas les batteries rechargeables.

Si de l'eau ou des corps étrangers pénètrent dans l'appareil, cela pourrait provoquer un incendie ou un choc électrique. Si de l'eau ou un corps étranger pénètre dans l'appareil, cessez immédiatement de l'utiliser, puis consultez votre revendeur Sony ou le personnel de service technique.

• Lors de l'utilisation à côté d'un évier ou d'un récipient de liquide, veillez à ce que l'appareil ne tombe pas dans un évier ou un récipient rempli d'eau.

• Lors de l'utilisation sous la pluie, la neige ou dans des lieux humides.

Pour plus de détails sur les effets du contact entre le corps humain et le téléphone mobile ou d'autres appareils électroniques, voir la section 2.1.

Seules les piles et les accumulateurs fournis avec l'appareil sont compatibles avec le produit. Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Ne réutilisez pas les piles ou les accumulateurs fournis avec l'appareil.

Spécifications

Casque

Source d'alimentation : 3,65 V CC, batterie au lithium-ion rechargeable

Temps de charge : 5 V CC, en cas de charge par USB

Temps de fonctionnement : 2,4 GHz band 2,400 - 2,483,5 MHz

Consommation électrique à la puissance nominale : 0,5 W (Casque), 2,0 W (Batterie de recharge)

Masse : Environ 46 g x 2 (Casque) (y compris les embouts, écouteilles (M))

Éléments fournis : Casque stéréo sans fil à réduction de bruit (1), Câble USB Type-C® (USB-A vers USB-C®) (2), M (3) (piles) (fixées à l'appareil en usine) (2), L (5) (piles) (2), B (4) (charge) (1)

Spécifications de communication

Système de communication : Spécification Bluetooth version 5.2

Sortie : Spécification Bluetooth classe de puissance 1

Gamme de fréquences : Bande de 2,4 GHz (2,400 - 2,483,5 MHz)

Fréquence de fonctionnement : 2,4 GHz band 2,400 - 2,483,5 MHz

Puissance de sortie maximale : Bluetooth : < 10 dBm

La conception et les spécifications peuvent être modifiées sans préavis.

Configuration système pour la charge de la batterie par USB

Adaptateur secteur USB : Adaptateur secteur USB disponible dans le commerce capable de fournir un courant de sortie de 0,5 A (500 mA) minimum

Marques : La marque et les logos Bluetooth® sont des marques commerciales déposées appartenant à Bluetooth SIG, Inc., et toute utilisation de ces marques par Sony Group Corporation et ses filiales est sous licence.

• USB Type-C® et USB-C® sont des marques commerciales déposées de USB Implementers Forum.

• Toutes les autres marques et marques déposées sont des marques ou des marques déposées de leurs détenteurs respectifs. Les symboles "™" et "®" n'apparaissent pas dans ce manuel.

Licences

• Ce produit contient des logiciels utilisés par Sony sous licence de leur détenteur.

• Les services proposés par des tiers peuvent être modifiés, suspendus ou supprimés sans préavis.

• Les services proposés par des tiers peuvent être modifiés, suspendus ou supprimés sans préavis.

• Les services proposés par des tiers peuvent être modifiés, suspendus ou supprimés sans préavis.

• Les services proposés par des tiers peuvent être modifiés, suspendus ou supprimés sans préavis.

• Les services proposés par des tiers peuvent être modifiés, suspendus ou supprimés sans préavis.

• Les services proposés par des tiers peuvent être modifiés, suspendus ou supprimés sans préavis.

• Les services proposés par des tiers peuvent être modifiés, suspendus ou supprimés sans préavis.

• Les services proposés par des tiers peuvent être modifiés, suspendus ou supprimés sans préavis.

