Questo manuale d'istruzione è fornito da trovaprezzi.it. Scopri tutte le offerte per Ernitec Electra-M08 o cerca il tuo prodotto tra le migliori offerte di Switch

ernitec

Installation Guide

1. Package Contents

2. Appearance Overview

- Front panel



- Back panel



- LED indicator

Mark	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to the port, which supply power successfully. Blink: Indicates that the Switch is supplying power.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established Blink: Indicates that the Switch is actively sending or receiving data over that port.
Link	Green	Off: not connected to the network equipment On: Indicates the link through that port is successfully established Blinking: connected devices are data transmission

- Front panel

- Back panel



- LED indicator

Mark	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to the port, which supply power successfully. Blink: Indicates that the Switch is supplying power.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established Blink: Indicates that the Switch is actively sending or receiving data over that port.
Link	Green	Off: not connected to the network equipment On: Indicates the link through that port is successfully established Blinking: connected devices are data transmission

- Front panel

- Back panel

- LED indicator

Mark	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to the port, which supply power successfully. Blink: Indicates that the Switch is supplying power.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established Blink: Indicates that the Switch is actively sending or receiving data over that port.
100M	Green	Off: There is no connected device or the connected device is 10M On: The connected device is 100M Blinking: connected devices are data transmission
Link/Act	Green	Off: not connected to the network equipment On: Indicates the link through that port is successfully established Blinking: connected devices are data transmission

- Front panel

- Back panel

- LED indicator

Mark	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to the port, which supply power successfully. Blink: Indicates that the Switch is supplying power.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established Blink: Indicates that the Switch is actively sending or receiving data over that port.
100M	Green	Off: There is no connected device or the connected device is 10M On: The connected device is 100M Blinking: connected devices are data transmission
Link/Act	Green	Off: not connected to the network equipment On: Indicates the link through that port is successfully established Blinking: connected devices are data transmission

- Front panel

- Back panel



- LED indicator

Mark	Color	Description
PWR	Green	Off: switch does not power on On: the switch is powered on
SYS	Green	Blinking: the system works On: the system is starting or has no power
PoE	Orange	Off: No PoE powered device (PD) connected. on: There is a PoE PD connected to the port, which supply power successfully. Blink: Indicates that the Switch is supplying power.
SFP	Green	Off: No device is connected to the corresponding port. On: Indicates the link through that port is successfully established Blink: Indicates that the Switch is actively sending or receiving data over that port.
100M	Green	Off: There is no connected device or the connected device is 10M On: The connected device is 100M Blinking: connected devices are data transmission
Link/Act	Green	Off: not connected to the network equipment On: Indicates the link through that port is successfully established Blinking: connected devices are data transmission

3. Installation

- Desktop installation

- Rack Installation



4. Login to the web

- To log in to the web page, please confirm the following points:

1. The switch has been powered on normally, and any port has been connected to the management host.
2. The IP address of IP address is set to the same network segment as the switch port, that is, 192.168.2.X (X is any integer between 2 and 254), and the subnet mask is 255.255.255.0.



- The switch web page method is as follows:

1. Open the browser, enter the default management address of the switch, http://192.168.0.1 in the address bar to log in to the web page of the switch.
2. The login page of the switch is shown in the figure below. On this page, enter the user name and password of the switch management account. The factory default value is admin.

5. Console login

- To log in to the web page, please confirm the following points:

1. The switch has been powered on normally, and the Console cable is connected to the Console port.
2. Install terminal emulation software (PuTTY, Secure CRT and X-shell) on the computer

- The method of logging in to the switch console is as follows:

1. Open terminal emulation software (PUTTY, Secure CRT and X-shell).
2. Select Serial as the connection type (the default baud rate of the switch is 38400) on the computer

The following figure uses Putty to log in.

Warranty Card

Customer	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Purchase Date	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within three months after purchase, we will provide you a new product of the same model.
- If the product defects within the three-year warranty period, we will provide the corresponding maintenance service.
- Proof of purchase and a complete product serial number are required to receive any warranty service. Without this, the warranty is void.
- Any other defects that are not caused by workmanship or product quality, such as improper use, accidents, or unauthorized disassembly, maintenance or modification, or damaged, warranty card losing, will disqualify the product from limited warranty.

CE FC RoHS UK CA