













ASSEMBLY GUIDE

ARENA













1




2








5





6









9




10









service@arozzi.com



support@arozzi.se

