

my
city

my
bernette

Machine Overview	2
Details of the sewing machine	
Display Explanation & Operating Functions	3
Buttons Explanation	
Machine Setup	4-5
Threading the Upper Thread	
Inserting the Bobbin	
Start to sew	6-7
How to select a stitch	
Enter a sequence of stitch motifs in Memory Enter Mode	
Start to embroider (Chicago 7)	8-10
Attaching the embroidery foot	
Connecting the embroidery module	
- Hooping the fabric	
Starting to embroider	




Quick Start Guide

Chicago 5
Chicago 7

Machine Overview


Details of the sewing machine

- 1 Thread guide
- 2 Presser foot pressure
- 3 Bobbin winder pre-tension
- 4 Thread tension dial
- 5 Spool pin
- 6 Hole for second spool pin
- 7 Bobbin winder spindle
- 8 Bobbin winder stopper
- 9 LCD display
- 10 Speed dial
- 11 Operation buttons
- 12 Thread cutter
- 13 One-step buttonhole lever
- 14 Needle threader
- 15 Stitch plate cover
- 16 Sewing table and accessory box
- 17 Selection buttons
- 18 Function buttons
- 19 Top cover
- 20 Handwheel
- 21 Embroidery module connector
- 22 Power switch
- 23 Power cord
- 24 Foot control connector
- 25 Handle
- 26 Presser foot lever
- 27 Feed dog lever
- 28 Embroidery module (Chicago 7)



Display Explanation & Operating Functions

Buttons Explanation




- 1 Start/Stop button
- 2 Reverse / Exit button
- 3 Auto-lock / Trace button
- 4 Needle up/down button
- 5 Speed dial
- 6 OK button
- 7 Arrow buttons
- 8 Direct pattern selection and Number buttons
- 9 Mirror image button
- 10 Elongation / Resize button
- 11 Twin Needle / Rotate button
- 12 Stitch length adjustment / Stitch forward/back button
- 13 Stitch width adjustment / Colour forward/back button
- 14 Memory / Setup button
- 15 Clear / Return button
- 16 Pattern group selection / Colour setup button

NOTE

The icon on the button is for sewing mode, and the icon on the side of the button is for embroidery mode.

Machine Setup

Threading the Upper Thread




NOTE


It is important to carry out the threading correctly as by not doing so several sewing problems can occur.

Machine Setup


Inserting the Bobbin




How to select a stitch




Enter a sequence of stitch motifs in Memory Enter Mode




Attaching the embroidery foot



Connecting the embroidery module



Hoop the fabric



Starting to embroider

