


## Festival Microphone

### SING & LISTEN YOUR FAVOURITE SONGS!

Festival, the wireless microphone with built-in speaker that allows you to sing and play your music at the same time, simply connect it to your device in

Bluetooth® mode.

Have fun applying effects to your voice to get the sound you prefer.



MANAGE YOUR TRACKS THANKS TO THE ⏪ ⏩ ⏮ ⏭ ⏯ MODE SELECTION BUTTON (M)

### PLUG & PLAY!

Play your favourite music via the TF card port, AUX input or connect it to your device in Bluetooth® mode.

The 3W output power ensures the best audio performance both indoor and outdoors.



Read this user manual and in particular the safety notes before using the product.

Keep the user manual for future reference and include it when passing the product on to third parties.

Celly S.p.A. will not in any way be held responsible for injury or damage caused to persons or property arising from misuse of the product.

### WARNINGS

- Never disassemble or modify the product for any reason. Doing this may cause the product to malfunction or become combustible.
- Keep your device and all accessories out of the reach of kids or animals. Small parts may cause choking or serious injury if swallowed.
- Avoid exposing your device to very cold or very hot temperatures (below 0 °C or above 40 °C). Extreme

temperatures can cause the deformation of the device and reduce the charging capacity and life of your device.

- Do not get your device wet — liquids can cause serious damage. Do not handle your device with wet hands. Water damage to your device can void your manufacturer's warranty.

- Avoid using your device's light close to the eyes of children or animals.

- Do not use the device during a thunderstorm. Thunderstorms can cause the device to malfunction and increase the risk of electric shock.

### Charging:

For first time use, charge the battery to full capacity (4 hours MAX). To charge, plug the charging cable into the FESTIVAL charging port connecting it to a charger/pc with a USB port (5V, 1A). Red light means it is charging, turning off means full charge.

### Maintenance:

1. Do not use abrasive cleaning solvents to clean FESTIVAL ;
2. Do not touch FESTIVAL with any sharp object as this will cause scratching and damage;
3. Please keep the FESTIVAL away from high-temperature, dust and humidity.

### Specification:

Frequency response: 2.402~2.480MHz  
 Battery: Li-Polymer 1500mAh (5,55Mh)  
 Speaker: 3W  
 Charging Voltage: 3.7V  
 Charging Time: 3.5-4 Hours  
 Maximum power: 0,51mW  
 Bluetooth® version: 4.2  
 Software: JeiLa  
 Software version: 20180412\_V1\_1639



**CUSTOMER'S INFORMATION FOR RIGHT WASTE OF THIS PRODUCT**

### (2013/56/EU Directive)

This marking on the product or its packaging means that the product at the end of its life, including the unremovable battery, must be separated from other types of waste to recycle it responsibly. Safely's use of this product is guaranteed from the respect of this instructions manual, keep it and carefully use it for all life of the product.

The product doesn't need any kind of technical maintenance, NEVER DISASSEMBLE IT.

The battery inside the product is integrated and not replaceable.

Don not try to remove li-ion/polymer battey included in inside the product because can produce overheat's danger, burning and injury.

The battery must be removed only by qualified professional technicians, that are able to remove it without any kind of danger and to recycle it in the respect of

the law.

Users should give free end of life product into the local separate collection centers or to the retailer, in reason of one to one, or free if the product size is bigger than 25 cm.

Adequated waste disposal permit to award the product to recycling, treatment with ecofriendly compatible disposal conduce to prevent possible harm to the environment or human health and promote the reuse and/or product materials recycling.

Unauthorized waste disposal of electronic product, cell and battery from houseold user involve currency legislation sanctions.



This product complies with RoHS 2011/65/EU. The product carries the CE mark and complies with safety standards established by the European Union.


Hereby, Celly SpA declares that the wireless microphone FESTIVAL is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

[www.celly.com/exchange/CELLY-SPA/Di\\_chiarazioni\\_di\\_conformita/FESTIVAL/DO\\_C\\_FESTIVAL.pdf](http://www.celly.com/exchange/CELLY-SPA/Di_chiarazioni_di_conformita/FESTIVAL/DO_C_FESTIVAL.pdf)

**Microfono Festival**
**SING & LISTEN YOUR FAVOURITE SONGS!**

Con Festival, il microfono senza fili con speaker integrato, puoi cantare e riprodurre la tua musica preferita nello

stesso tempo, connettilo facilmente al tuo dispositivo in modalità Bluetooth®. Divertiti ad applicare effetti alla tua voce per ottenere il suono che più preferisci.



**!** La ringraziamo per aver scelto un prodotto Celly! Si prega di leggere questo manuale e, prima di utilizzare il prodotto, fare attenzione alle avvertenze sulla sicurezza qui sotto riportate. Celly S.p.A. non potrà in alcun modo essere ritenuto responsabile di lesioni o danni causati a persone o cose derivanti da un utilizzo improprio del prodotto.

**AVVERTENZE DI SICUREZZA**

- Non disassemblare o modificare Festival per nessuna ragione. Questa operazione potrebbe causare il malfunzionamento o la combustione del prodotto.
- Tenere il dispositivo e tutti gli accessori fuori dalla portata dei bambini o degli animali. Piccole parti possono causare soffocamento o lesioni gravi se ingerite.

- Evitare di esporre il dispositivo a temperature molto fredde o molto calde (sotto 0 °C o superiore a 40 °C). Le temperature estreme possono causare la deformazione del dispositivo e ridurre la capacità di carica e durata del dispositivo.
- Non bagnare il dispositivo - i liquidi possono causare gravi danni. Non maneggiare il dispositivo con le mani bagnate. Il danneggiamento del dispositivo a causa dell'acqua potrebbe invalidare la garanzia del produttore.
- Evitare di utilizzare la luce del dispositivo vicino agli occhi di bambini o animali.
- Non utilizzare il dispositivo durante un temporale. I temporali possono causare il malfunzionamento del dispositivo e aumentare il rischio di scosse elettriche.

**Ricarica:**

Al primo utilizzo caricare la batteria fino

alla massima capacità (4 ore MAX). Per ricaricare, collegare il cavo di carica nella porta di ricarica FESTIVAL connettendolo alla porta USB (5V, 1A) di un carica batterie/pc. La luce rossa indica che il prodotto è in ricarica, quando la luce si spegne, la carica è completa.

**Manutenzione:**

1. Non utilizzare solventi abrasivi per pulire FESTIVAL ;
2. Non intaccare FESTIVAL con qualsiasi tipo di oggetto tagliente in quanto potrebbe graffiare o danneggiare il prodotto;
3. Tenere il FESTIVAL lontano da alte temperature, polvere e umidità.

**Caratteristiche:**

Risposta in frequenza: 2.402~2.480MHz  
 Batteria: Li-Polymer 1500mAh (5,55Mh)  
 Speaker: 3W

Tensione di ricarica: 3.7V  
 Tempo di ricarica: 3.5-4 Hours  
 Potenza massima: 0,51mW  
 Versione Bluetooth®: 4.2  
 Software: JeiLa  
 Versione software: 20180412\_V1\_1639

**INFORMAZIONI ALL'UTENTE PER IL CORRETTO SMALTIMENTO DELL'APPARECCHIO**

(Direttiva 2013/56/EU)  
 Il simbolo del cassonetto barrato riportato sull'apparecchiatura o sulla sua confezione indica che il prodotto alla fine della propria vita utile, incluso della batteria non rimovibile, deve essere raccolto separatamente dagli altri rifiuti per permetterne un adeguato trattamento e riciclo.

L'uso sicuro di questo prodotto è garantito nel rispetto delle seguenti istruzioni, pertanto è necessario conservarle e seguirle in modo scrupoloso lungo tutta la vita del prodotto. Il prodotto non necessita di manutenzione

tecnica, NON SMONTARLO MAI.

La batteria presente all'interno è integrata e non sostituibile.

Non tentare di rimuovere autonomamente la batteria agli ioni/polimeri di litio incorporata perché potrebbe causare lesioni o danni da surriscaldamento, incendi e lesioni. La batteria deve essere rimossa solo da professionisti qualificati indipendenti in grado di rimuoverla senza pericolo e smaltita in conformità con le vigenti leggi in materia.

L'utente dovrà, pertanto, conferire gratuitamente l'apparecchiatura giunta a fine vita agli idonei centri comunali di raccolta differenziata dei rifiuti elettrici ed elettronici, oppure riconsegnarla al rivenditore, in ragione di uno per uno, o gratuitamente per gli apparecchi di dimensioni esterne inferiori a 25 cm.

L'adeguata raccolta differenziata per l'avvio successivo dell'apparecchiatura dismessa al riciclaggio, al trattamento e allo smaltimento ambientalmente compatibile contribuisce ad

evitare possibili effetti negativi sull'ambiente e sulla salute e favorisce il reimpiego e/o riciclo dei materiali di cui è composta l'apparecchiatura.

Lo smaltimento abusivo di apparecchiature, pile ed accumulatori da parte dell'utente comporta l'applicazione delle sanzioni di cui alla corrente normativa di legge.

**CE** Questo prodotto è conforme alla direttiva RoHS 2011/65/EU. Il Prodotto dispone del marchio CE ed è quindi conforme agli standard di sicurezza stabiliti dall'Unione europea.

Celly SpA dichiara che il microfono wireless FESTIVAL è conforme alla direttiva 2014/53/UE.

Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet:

[www.celly.com/exchange/CELLY-SPA/Dichiarazioni\\_di\\_conformita/FESTIVAL/DOC\\_FESTIVAL.pdf](http://www.celly.com/exchange/CELLY-SPA/Dichiarazioni_di_conformita/FESTIVAL/DOC_FESTIVAL.pdf)

Celly® is a trademark owned by CELLY SpA.

All brands are registered trademarks of their respective owners

Imported by **CELLY SpA** Via Energy Park 22 - 20871 - Vimercate - MB (Italia)

Made in China

"The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Celly SpA is under license. Other trademarks and trade names are those of their respective owners."

**Celly SpA is a Company Certified by BSI to ISO 9001:2015 - Certificate N° FM 630013**