



Disney


43184



WARNING: CHOKING HAZARD.
Toy contains small parts and a small ball.
Not for children under 3 years.



2




AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.

Le jouet contient des petites pièces ainsi qu'une petite boule.
Il ne convient pas aux enfants de moins de 3 ans.




ADVERTENCIA: PELIGRO DE ASFIXIA.


Juguete que contiene partes pequeñas y una pelota pequeña.
No recomendado para niños menores de 3 años.



1x


1





2x


2





2x

3



4



2x




2x

4



2x






2x




2x


5




6




6




2




3




4






5






7





2x

8






2x

9




2x





2x

10





6x





2x

11






6x






12





1x

13






2x



1x


14





4x

15



18





1x



1x


16









2x

17








18



19


22








1x


20








21






22





1x

23





26





2x

24





25





1x






1x





1x

26







27





Disney




43189

43175

43176

43177



[LEGO.com/disney](https://www.LEGO.com/disney)



Friends™



41445



41442



41446



DOTS™

41921

41924

41925

41926

41934

41909

41910

41918

41923

LEGO



1x
6186681



4x
6258135



1x
300501



2x
6218841



2x
6046905



1x
6321349



2x
6259700



1x
4560178



1x
6249273



4x
4515364

34



1x
6322480



4x
6347309



4x
245401



2x
6137926



2x
4568956



2x
6336553



1x
4249506



2x
4547489



4x
6310185



1x
6179606



4x
4142865



1x
6317283




4x
6271228



1x
6294716



2x
4243824



1x
4509897



1x
6331737



3x
4206482



1x
6266252



4x
6247792



2x
6252043



1x
6171733



2x
6344752



1x
6317222



1x
370526



1x
370526

4



4x
6240467



2x
6228967



2x
6213777



2x
6249427



1x
6273853



2x
6307898



1x
6249299



1x
6317535



1x
6324010



2x
6336539



2x
4211375



4x
6043656



1x
4211440



2x
6039479



1x
4509884



2x
6316263



5x
6291647



2x
6296491



1x
6290401



3x
6282861



10x
6209691



1x
4505990



1x
4621352





1x
6020147



1x
4243920



2x
6199886



4x
6336530



1x
6336544



1x
6336531



2x
6336529



1x
6336658



2x
6107194



1x
6324649



1x
6312464



1x
6348209



2x
4619520



2x
6097493



2x
6124250



1x
4625036



2x
6136419



2x
6071246



2x
6335566



5x
6322830



1x
6236582



2x
6058746



1x
6261392



8x
6320292



2x
6056998



3x
6174592



5x
6322807



1x
6324389



2x
4619513



1x
6336541



1x
6070757



1x
6324939



1x
6236437



1x
6295242



1x
6287309




2x
6339228




1x
6299884



3x
6210460



1x
6292823



1x
6304883



1x
6317332



2x
6253885



1x
6037890



2x
6110050



2x
6130007

3



Customer Service

Kundenservice

Service Consommateurs


Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346



Rebuild
the
world



LEGO and the LEGO logo are trademarks of the/sont des marques de commerce du/son marcas registradas de LEGO Group.
©2021 The LEGO Group. All rights reserved/Tous droits réservés/Todos los derechos reservados. 6354211
© Disney