



Questo manuale d'istruzione è fornito da trovaprezzi.it. Scopri tutte le offerte per [Bestway FlowClear MusicWave](#) o cerca il tuo prodotto tra le [migliori offerte di Diffusori Audio](#)



Questo manuale d'istruzione è fornito da trovaprezzi.it. Scopri tutte le offerte per [Bestway FlowClear MusicWave](#) o cerca il tuo prodotto tra le [migliori offerte di Diffusori Audio](#)

Bestway®

58700

©2022 Bestway Inflatables & Material Corp.

All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten/Tutti i diritti riservati

Trademarks used in some countries under license from/

Marques utilisées dans certains pays sous la licence de/

Marcas comerciales utilizadas en algunos países bajo la licencia de/

Die Warenzeichen werden in einigen Ländern verwendet unter Lizenz der/

Marchi utilizzati in alcuni paesi concessi in licenza a

Bestway Inflatables & Material Corp., Shanghai, China

Manufactured, distributed and represented in the European Union by/

Fabriqués, distribués et représentés dans l'Union Européenne par/Fabricado, distribuido y representado en la Unión Europea por/

Hergestellt, vertrieben und in der Europäischen Union vertreten von/Prodotto, distribuito e rappresentato nell'Unione Europea da

Bestway Europe S.p.a., Via Resistenza, 5, 20098 San Giuliano Milanese (Milano), Italy

Distributed in Latin America by/Distribué en Amérique latine par/Distribuido en Latinoamérica por/Distribuido na América Latina por

Bestway Central & South America Ltda, Salar Ascotan 1282, Parque Enea, Pudahuel, Santiago, Chile

Distributed in Australia & New Zealand by **Bestway Australia Pty Ltd, Unit 2/98-104 Carnarvon St Silverwater, NSW 2128, Australia**

Tel: Australia: (+61) 2 9037 1388; New Zealand: 0800 142 101

Distributed in United Kingdom by **Bestway Corp UK Ltd, 8 Wentworth Road, Heathfield Industrial Estate, Newton Abbot, Devon, TQ12 6TL**

Exported by/Exporté par/Exportado por/Exportiert von/Esportato da

Bestway (Hong Kong) International Ltd./Bestway Enterprise Company Limited

Suite 713, 7/Floor, East Wing, Tsim Sha Tsui Centre, 66 Mody Road, Kowloon, Hong Kong

www.bestwaycorp.com

OWNER'S MANUAL

58700 Floating LED Bluetooth Speaker

IMPORTANT SAFETY INSTRUCTIONS

WARNING

READ AND FOLLOW ALL INSTRUCTIONS

SAVE THESE INSTRUCTIONS

The light source/battery of this luminaire is not replaceable; when the light source/battery reaches its end of life the whole luminaire shall be replaced. The power source should meet limited power source or PS2 requirements according to IEC 62368-1.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

DISPOSAL



Electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

PRODUCT SPECIFICATIONS

Bluetooth version	V5.1, compatible V4.2 and V2.1+ED
Battery capacity	2500mAh lithium battery 3.7V
Working hours	MAX: 6 hrs
Frequency	2402MHz-2480MHz
Protocol	A2DP/AVRCP/HFP/SPP/GAT
Communication distance	10-15 meters (32.8-49.2 ft.)
Speaker	Mono mixing output 4Ω6W, high-fidelity waterproof speaker (Φ57mm)
Dimensions	4.94" x 4.94" x 6.63"
LED light	Yellow, Green, Red, Blue
LED mode	8 modes
Waterproof	IP67
Max. ambient	50°C
Max RF output power:	<10dBm

CHARGING

Connect the included USB cord to the USB port and plug it into a 5V USB outlet and the DC jack to the CT602. During charging, the LED indicator light will remain red. When the battery is full, the LED indicator will turn green.

NOTE:

- Use the included cable and respect the voltage!
- Please charge before use.
- Before inserting the charger, dry the charging port.

BUTTON FUNCTION DESCRIPTION



Multifunction Button:

- Hold the button down for 3 seconds to power on, and hold again for 3 seconds to power off.
- When playing music, press this button to pause music, and press again to continue playing music.
- When a call is incoming, press the button to answer the phone, and push again to hang up the call.



“Volume - and Previous” Button:

Press the button to play the previous track, and hold the button down to reduce the volume.



“Volume + and Next” Button:

Press the button to play the next track, and hold the button down to increase the volume.



Light Mode Button:

- Press to switch through the different LED modes.
- Hold down the light button for 5 seconds to remove Bluetooth pairing.

BLUETOOTH PAIRING SETTINGS

Hold down the multifunction button for 3 seconds to power on. Wait until the blue light flashes, then open the bluetooth mode on your smartphone and select “CT602” to pair the device. It’s now paired. You can broadcast your music! If not, start again or relaunch the CT602.

