



Questo manuale d'istruzione è fornito da trovaprezzi.it. Scopri tutte le offerte per [Hamlet HHEADM-UJM](#) o cerca il tuo prodotto tra le [migliori offerte di Cuffie e Microfoni](#)

 **trovaprezzi.it**

Questo manuale d'istruzione è fornito da trovaprezzi.it. Scopri tutte le offerte per [Hamlet HHEADM-UJM](#) o cerca il tuo prodotto tra le [migliori offerte di Cuffie e Microfoni](#)

Hamlet

RENOVA HEADSET UJM/UJS Business Headphone & Mic Combo USB + Jack + Remote Control



Manuale Utente

HHEADM-UJM

HHEADM-UJS

www.hamletcom.com

Gentile Cliente,

La ringraziamo per la fiducia riposta nei nostri prodotti. La preghiamo di seguire le norme d'uso e manutenzione che seguono. Al termine del funzionamento di questo prodotto La preghiamo di non smaltirlo tra i rifiuti urbani misti, ma di effettuare per detti rifiuti una raccolta separata negli appositi raccoglitori di materiale elettrico ed elettronico o di riportare il prodotto dal rivenditore che lo ritirerà gratuitamente.



Informiamo che il prodotto è stato realizzato con materiali e componenti in conformità a quanto previsto dalle Direttive RoHS 2011/65/EU & 2015/863/EU, dalle Direttive RAEE 2002/96/CE, 2003/108/CE D.lgs. 151/2005 e dalla Direttiva EMC 2014/30/EU per i seguenti standard:

EN 55032: 2015 + A11: 2020

EN 55035: 2017 + A11: 2020



La dichiarazione di conformità CE completa relativa al prodotto può essere richiesta contattando Hamlet all'indirizzo e-mail info@hamletcom.com.


Visita www.hamletcom.com per informazioni complete su tutti i prodotti Hamlet e per accedere a download e supporto tecnico. Importato da: CARECA ITALIA SPA - Scandiano (RE) . Italia.

Marchi e variazioni

Tutti i marchi e i nomi di società citati in questa guida sono utilizzati al solo scopo descrittivo e appartengono ai rispettivi proprietari.

La presente guida ha scopo puramente informativo. I contenuti, le specifiche e le caratteristiche esteriori del prodotto sono indicative e possono variare senza obbligo di preavviso.

FUNZIONI DEL TELECOMANDO



1. Altoparlanti Cuffia On/Off

Attiva e disattiva l'audio della cuffia.

2. Volume +/-

Premere i pulsanti + e - per aumentare o diminuire il volume della cuffia.

3. Microfono On/Off

Attiva e disattiva l'audio del microfono.

4. Connettore USB

Permette di collegare la cuffia ad una porta USB-A del computer.

5. Jack 3,5 mm

Connettore audio standard. Può essere utilizzato con computer o dispositivi mobili dotati di uscita audio 3,5 mm o per l'utilizzo del cavo USB in dotazione.

6. Led Blu

Lampeggia quando la cuffia è collegata e l'uscita audio è attiva. Rimane fisso quando l'audio della cuffia è spento.

7. Led Rosso

Si accende quando il microfono è disattivato.

CONNESSIONE DELLA CUFFIA CON MICROFONO

Potete collegare la cuffia con microfono al vostro computer o dispositivo mobile in due modi.

1. Tramite connettore jack 3,5 mm


Collegate il connettore da 3,5 mm all'ingresso da 3,5 mm (cuffie) del computer, dello smartphone o del tablet.

2. Tramite connettore USB

Inserite il connettore da 3,5 mm della cuffia nell'ingresso da 3,5 mm del cavo USB in dotazione quindi ad una porta USB-A del computer.

IMPOSTAZIONI AUDIO WINDOWS

1. Aprire il “Pannello di Controllo” e selezionare “Hardware e Suoni”.



Adjust your computer's settings

View by: [Category](#) ▾



System and Security

Review your computer's status
Save backup copies of your files with File History
Backup and Restore (Windows 7)



Network and Internet

View network status and tasks



Hardware and Sound

View devices and printers
Add a device
Adjust commonly used mobility settings



Programs

Uninstall a program



User Accounts

Change account type



Appearance and Personalization



Clock and Region

Change date, time, or number formats



Ease of Access

Let Windows suggest settings
Optimize visual display

2. Cliccare su “Audio” e impostare “USB Audio Device” come dispositivo predefinito nei pannelli “Riproduzione” e “Registrazione”.



Devices and Printers

[Add a device](#) | [Advanced printer setup](#) | [Mouse](#) | [Device Manager](#) | [Change Windows To Go startup options](#)



AutoPlay

[Change default settings for media or devices](#) | [Play CDs or other media automatically](#)



Sound

[Adjust system volume](#) | [Change system sounds](#) | [Manage audio devices](#)



Power Options

[Change battery settings](#) | [Change what the power buttons do](#) | [Change when the computer sleeps](#)
[Choose a power plan](#) | [Edit power plan](#)



Windows Mobility Center

[Adjust commonly used mobility settings](#) | [Adjust settings before giving a presentation](#)



Sound



Playback

Recording

Sounds

Communications

Select a playback device below to modify its settings:



Speakers

Realtek(R) Audio

Ready



Speakers

USB Audio Device

Default Device



Configure

Set Default



Properties


OK

Cancel


Apply

IMPOSTAZIONI AUDIO MAC

1. Aprire le “Preferenze di Sistema” e cliccare su “Suono”.



2. Selezionare “USB Audio Device” come dispositivo audio nei pannelli “Uscita” e “Ingresso”.



Hamlet

RENOVA HEADSET UJM/UJS

Business Headphone & Mic
Combo USB + Jack + Remote Control



User Manual

HHEADM-UJM

HHEADM-UJS

Dear Customer,

Thanks for choosing a Hamlet product. Please carefully follow the instructions for its use and maintenance and, once this item has run its life span, we kindly ask You to dispose of it in an environmentally friendly way, by putting it in the separate bins for electrical/electronic waste, or to bring it back to your retailer who will collect it for free.



We inform You this product is manufactured with materials and components in compliance with RoHS Directives 2011/65/EU & 2015/863/EU, with WEEE Directives 2002/96/CE, 2003/108/CE Italian Legislative Decree 2005/151 and EMC Directive 2014/30/EU for the following standards:

EN 55032: 2015 + A11: 2020

EN 55035: 2017 + A11: 2020



The complete CE declaration of conformity of the product can be obtained by contacting Hamlet at info@hamletcom.com.

Visit www.hamletcom.com for complete information on all Hamlet products and to access downloads and support.


Imported by: CARECA ITALIA SPA - Scandiano (RE) . Italy.

Trademarks and changes

All trademarks and company names mentioned in this manual are used for description purpose only and remain property of their respective owners.

The material in this document is for information only. Contents, specifications and appearance of the product are indicative and may change without notice.

REMOTE CONTROL FUNCTIONS



1. Headphones On/Off

Activates and deactivates the sound of the headphones.

2. Volume +/-

Press the + and – buttons to increase or decrease the volume of the headphones.

3. Microphone On/Off (Mute)

Press this button to turn the microphone on and off.

4. USB Plug

Allows you to connect headphones to a standard USB-A port on your computer.

5. 3.5 mm Jack

Standard audio connector. It can be used with computers or mobile devices with 3.5 mm audio output or for using the supplied USB cable.

6. Blue Led

Flashes when the headphones are connected and the audio output is active. Steady light indicates the headphone is off.

7. Red Led

Lights up when the microphone is muted.

CONNECTING THE HEADSET

You can connect the headset to your computer or mobile device in two ways.

1. Via 3.5 mm connector


Connect the 3.5mm plug to the 3.5 mm input (headphone) on your computer, smartphone or tablet.

2. Via USB connector

Insert the 3.5mm plug of the headset into the 3.5 mm socket of the supplied USB cable then to a USB-A port on your computer.

WINDOWS SOUND SETTINGS

1. Open “Control Panel” and select “Hardware and Sound”.



Adjust your computer's settings

View by: [Category](#) ▾



System and Security

Review your computer's status
Save backup copies of your files with File History
Backup and Restore (Windows 7)



Network and Internet

View network status and tasks



Hardware and Sound

View devices and printers
Add a device
Adjust commonly used mobility settings



Programs

Uninstall a program



User Accounts

Change account type



Appearance and Personalization



Clock and Region

Change date, time, or number formats



Ease of Access

Let Windows suggest settings
Optimize visual display

2. Click “Sound” and set “USB Audio Device” as default audio device in “Playback” and “Recording” tabs.



Devices and Printers

[Add a device](#) | [Advanced printer setup](#) | [Mouse](#) | [Device Manager](#) | [Change Windows To Go startup options](#)



AutoPlay

[Change default settings for media or devices](#) | [Play CDs or other media automatically](#)



Sound

[Adjust system volume](#) | [Change system sounds](#) | [Manage audio devices](#)



Power Options

[Change battery settings](#) | [Change what the power buttons do](#) | [Change when the computer sleeps](#)
[Choose a power plan](#) | [Edit power plan](#)



Windows Mobility Center

[Adjust commonly used mobility settings](#) | [Adjust settings before giving a presentation](#)



Sound



Playback Recording Sounds Communications

Select a playback device below to modify its settings:



Speakers
Realtek(R) Audio
Ready



Speakers
USB Audio Device
Default Device



Configure

Set Default



Properties


OK

Cancel

Apply

MAC SOUND SETTINGS

1. Open “System Preferences” and click “Sound”.



2. Select “USB Audio Device” as audio device in the “Output” and “Input” tabs.

