

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as "EZVIZ"). This user manual (hereinafter referred to as "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

Revision Record

New release – January, 2019

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS", WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Contenuto della confezione



Internet Camera (x1)



Cavo USB (x1)



Alimentatore (x1)



Adesivi
gommati (x2)



Piastra metallica
(x1) (Diametro foro
3,5 mm)




Informazioni sulle
norme (x1)



Guida rapida
(x1)

i L'aspetto effettivo della telecamera dipende dal modello acquistato.

Panoramica



Nome	Descrizione
Indicatore LED	• Rosso fisso: la telecamera si sta avviando. • Rosso lampeggiante lento: connessione alla rete Wi-Fi non riuscita. • Rosso lampeggiante veloce: Eccezione dispositivo (ad es., errore scheda micro SD). • Blu fisso: il video viene trasmesso o riprodotto dall'app EZVIZ. • Blu lampeggiante veloce: telecamera pronta per la connessione Wi-Fi. • Blu lampeggiante lento: la telecamera funziona correttamente.
Scheda micro SD	La scheda micro SD va acquistata a parte. Inizializzare la scheda nell'app EZVIZ prima di utilizzarla.
Pulsante di RESET	Tenere premuto il pulsante RESET per 5 secondi mentre la videocamera è accesa. La videocamera viene riavviata e tutti i parametri vengono reimpostati ai valori predefiniti.

Impostazione

Passo 1 Accensione

Collegare il cavo di alimentazione a videocamera e alimentatore, quindi collegare quest'ultimo alla presa di corrente (figura sotto).



Passo 2 Configurazione della videocamera


1. Creare un account utente



- Connettere il cellulare alla rete Wi-Fi.
- Scaricare e installare l'app EZVIZ cercando "EZVIZ" nell'App Store o in Google Play™.
- Lanciare l'app e registrare un account utente EZVIZ seguendo la procedura guidata di avvio.


2. Aggiungere una videocamera a EZVIZ

- Accedere all'app EZVIZ.
- Dalla schermata iniziale dell'app EZVIZ, toccare "+" nell'angolo superiore destro per passare alla pagina di scansione del QR.



- Acquisire il QR code riportato la videocamera.

Parte inferiore della
videocamera



- Seguire la procedura guidata dell'app EZVIZ per completare la configurazione della rete Wi-Fi.

i Controllare che il telefono sia connesso al Wi-Fi a 2,4 GHz nelle opzioni di configurazione Wi-Fi del router.

Installazione


Passo 1 Installare la piastra metallica (opzionale)

Scegliere un punto d'installazione in cui la superficie sia liscia e libera da ostacoli, quindi fissare la piastra metallica nel punto desiderato utilizzando l'adesivo gommato o delle viti (non fornite a corredo).

- i** All'interno della videocamera è presente una calamita. Se la superficie è metallica, questo passaggio può essere ignorato.

Passo 2 Installare la telecamera

Agganciare la videocamera alla piastra metallica o altra superficie di metallo tramite il supporto magnetico (figura sotto).




Passo 3 Completamento dell'installazione

Regolare l'angolazione della videocamera secondo necessità.

Appendice

Installazione della scheda di memoria

Inserire una scheda microSD nello slot finché un clic non ne conferma il corretto innesto.



Inizializzazione della scheda di memoria

1. Controllare lo stato della scheda di memoria nell'app EZVIZ, toccando **Storage Status (Stato Archivio)** nell'interfaccia **Device Settings (Impostazioni dispositivo)**.

Wi-Fi Configure	TEST-WiFi  >
Storage Status	>
Device Version	Vx.x.x build xxxxxx No new version.

2. Se lo stato della scheda di memoria è **Uninitialized (Non inizializzato)**, toccare per iniziarla. Lo stato diventerà **Normal (Normale)**.

 Per informazioni dettagliate, visitare il sito www.ezvizlife.com.