






Disney


43205








1








2






3







4





5








6





7






8



9







4x



4x


10






2x

11






12



13





4x

14




2x

15



2x


16




1x



2x

17






18




19







20




21



22



23





24



25




26






2x


27





2x

28






29




30







31




32






33


1




2




3



4






1x

34


1



2




16






1x


35





36



1




2




3

















Customer Service
Kundenservice
Service Client
Assistenza clienti
Atención al cliente
Serviço de Apoio ao Consumidor
Ügyfélszolgálat
Klientu apkalpošanas dienests
Serviciul pentru clienți
客户服务
コンシューマーサービス
고객 서비스
LEGO.com/service

