




# Disney

43212






3










































































































Disney  
PRINCESS

4+

43211



©Disney

[LEGO.com/disney](https://www.lego.com/disney)



Rebuild  
the  
world™





LEGO and the LEGO logo are trademarks of the LEGO Group. ©2023 The LEGO Group. 6461319  
©Disney