

GIGI™ 2

THE WORLD'S
MOST POPULAR
G-SPOT VIBRATOR



PRODUCT DESCRIPTION

A sexy pleasure product with a curved and flattened tip to accurately target your G-spot, GIGITM 2 offers exhilarating solo pleasure, making it one of the most popular G-spot massagers of all time!

Sublime Design for Precise Pleasure

The flattened tip is ideal for channeling the powerful, near-silent vibrations during G-spot massage

Double Trouble for Twice the Fun

The tip is designed to be flipped over so GIGI™ 2 becomes a clitoral massager too

The Perfect Curves for Every Body

GIGI™ 2's design and size is all about unlocking the G-spot orgasm for every woman




SPECIFICATIONS

- Materials: ABS Plastic / Silicone
- Finish: Glossy / Matte
- Size: 165 x 35 x 33mm / 6.5 x 1.4 x 1.3in.
- Diameter: Ø 37.8mm / 1.5in.
- Insertable Length: 95mm / 3.7in.
- Weight: 79g / 2.8oz.
- Battery: Li-Ion 920mAh 3.7V
- Charging: 2hrs at 5.0V 500mA
- User Time: Up to 4hrs
- Standby: Up to 90 days
- Frequency: 100Hz
- Max Noise Level: <50dB</p>
- Contents: GIGI™ 2, Charger, Satin Storage Pouch, 1-year Warranty.



FEATURES



CONTROLS



- Press + to turn on and to increase vibration strength.
- Press to lower vibration strength; hold to turn off.
- Press ▲ and ▼ to cycle through the different vibration patterns.
- Lock by holding + and for 5 seconds;
 the light will turn off when the device is locked.
- Unlock by pressing for 5 more seconds; the light will turn on when the device is active.

CHARGING

Always charge LELO massagers before first use and only use original chargers provided by LELO



HYGIENE & CARE



Use **LELO's Antibacterial Cleaning Spray** before and after each use for total peace of mind.

When cleaning with water, ALWAYS use a premium antibacterial solution

100% Waterproof and Rechargeable Design

Store your LELO massager in its protective storage pouch between uses.

WARNING: Do not boil or use metal scour. Avoid leaving your LELO in direct sunlight and NEVER expose it to extreme heat. Do not use on swollen or damaged skin. Keep your LELO out of the reach of children.

IMPORTANT: For Adult Use Only. Those who may be pregnant, have a pacemaker, diabetes, phlebitis or thrombosis should consult with a medical professional regarding the risk of blood clots before using any personal massage product.



WARRANTY REGISTRATION

- Visit LELO.com and click REGISTER/LOG IN in the top right corner of the screen.
- 2. Follow the directions to register your product and attach details of your purchase.

Don't forget to take advantage of LELO's full warranty coverage.



The serial number is on the back of the authenticity card provided with every LELO product.



DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems).

The crossed-out dustbin symbol indicates that this product should not be treated as household waste, but rather be brought to the appropriate collection point for recycling of electrical and electronic equipment.











* FCC Mark, C-Tick and IC certifications relevant to remote-controlled products only.

Disclaimer: Users of this LELO Product do so at their own risk. Neither LELO nor its retailers assume any responsibility or liability for the use of this product. Further, LELO reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Applicable for ALL products. Model may be changed for improvements without notice.

© 2015 LELOI AB. ALL RIGHTS RESERVED. LELOI AB, Birger Jarlsgatan 22, 114 34 STOCKHOLM, SWEDEN. LELO Inc., 4320 STEVENS CREEK BLVD., SUITE #205, SAN JOSE, CA 95129, USA. DESIGNED AND DEVELOPED BY LELO SWEDEN MANUFACTURED BY LELO IN CHINA

