

MIA[™]2

THE WATERPROOF USB-LIPSTICK VIBE



PRODUCT DESCRIPTION

The perfect way to keep your pleasure truly to yourself, the USB-rechargeable MIATM 2 massager possesses hidden power and looks perfectly at home in your purse or bedside drawer.

- Lipstick-Style Design for Discretion and Secrecy
 The disguised body of MIA™ 2 will keep you confident in your pleasure
- Sculpted Tip for Accurate Pleasure
 The shape has been specifically molded to target the clitoris for fast, intense climaxes
- USB-Rechargeable for More Power than Batteries
 The integrated USB charger means you can charge quickly for deceptive strength



SPECIFICATIONS

- Materials: ABS Plastic / Silicone
- **Finish**: Glossy
- **Size**: 111 x 22 x 22mm / 4.4 x 0.9 x 0.9in.
- Weight: 32g / 1.1oz.
- **Battery**: Li-Ion 70mAh 3.7V
- Charging: 1hr at 5.0V 100mA
- **User Time:** Up to 1.5hrs
- Standby: Up to 90 days
- **Frequency**: 120Hz
- Max Noise Level: <50dB</p>



FEATURES

Fully waterproof and USB-rechargeable

Easy-to-use controls to explore 6 vibration patterns

Deceptively strong, whisper-quiet vibrations



Body-safe ABS for smooth sensations

LELC

CONTROLS



- Press + to turn on and to increase vibration strength.
- Press to lower vibration strength; hold to turn off.
- Hold + for 2 seconds to enable cycling through the different vibration patterns
- Press + again to change to the next vibration pattern
- Lock by holding + and for 5 seconds;
 the light will turn off when the device is locked.
- Unlock by pressing for 5 more seconds; the light will turn on when the device is active.

CHARGING

Always charge LELO massagers before first use



CHARGING



HYGIENE & CARE



Use **LELO's Antibacterial Cleaning Spray** before and after each use for total peace of mind.

When cleaning with water, ALWAYS use a premium antibacterial solution.

100% Waterproof and Rechargeable Design.

Store your LELO massager in its protective storage pouch between uses.

WARNING: Do not boil or use metal scour. Avoid leaving your LELO in direct sunlight and NEVER expose it to extreme heat. Do not use on swollen or damaged skin. Keep your LELO out of the reach of children.

IMPORTANT: For Adult Use Only. Those who may be pregnant, have a pacemaker, diabetes, phlebitis or thrombosis should consult with a medical professional regarding the risk of blood clots before using any personal massage product.



WARRANTY REGISTRATION

- Visit LELO.com and click REGISTER/LOG IN in the top right corner of the screen.
- 2. Follow the directions to register your product and attach details of your purchase.

Don't forget to take advantage of LELO's full warranty coverage.



The serial number is on the back of the authenticity card provided with every LELO product.



DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems).

The crossed-out dustbin symbol indicates that this product should not be treated as household waste, but rather be brought to the appropriate collection point for recycling of electrical and electronic equipment.











* FCC Mark, C-Tick and IC certifications relevant to remote-controlled products only.

Disclaimer: Users of this LELO Product do so at their own risk. Neither LELO nor its retailers assume any responsibility or liability for the use of this product. Further, LELO reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Applicable for ALL products. Model may be changed for improvements without notice.

© 2015 LELOI AB. ALL RIGHTS RESERVED. LELOI AB, Birger Jarlsgatan 22, 114 34 STOCKHOLM, SWEDEN. LELO Inc., 4320 STEVENS CREEK BLVD., SUITE #205, SAN JOSE, CA 95129, USA. DESIGNED AND DEVELOPED BY LELO SWEDEN MANUFACTURED BY LELO IN CHINA