



Questo manuale d'istruzione è fornito da trovaprezzi.it. Scopri tutte le offerte per [Midland Dual Mike Wireless](#) o cerca il tuo prodotto tra le [migliori offerte di Cuffie e Microfoni](#)

DUAL MIKE WIRELESS WITH CBTALK APP

Download the CBTalk APP Android/iOs




PTT CBTALK

Push and talk into CBTalk



CHANGE A CHANNEL ON CBTALK



LED

- Turning ON:**
Blue led 3 sec.
- Turning OFF:**
Red led 3 sec.
- Pairing:**
Red and blue leds alternated
- Pairing with Smartphone:**
Blue led blinking 3 times
- Smartphone's pairing not successful:** red led blinking 3 times
- Full charge:**
Blue led blinks once
- While charging:**
Red led blinks once

LIGHT RING

- Default color:**
Steady blue (it will be set through the CBTalk APP)
- Incoming call:**
Steady white
- Low battery:**
blinking red
- PTT pressed:**
Steady yellow



Prodotto o importato da:
CTE INTERNATIONAL srl
Via. R.Sevardi 7 42124 Reggio Emilia - Italia.
Prima dell'uso leggere attentamente le istruzioni.

Produced or imported by:
CTE INTERNATIONAL srl
Via. R.Sevardi 7 42124 Reggio Emilia - Italy.
Read the instructions carefully before installation and use.

Vertrieb durch: **ALAN ELECTRONICS GmbH**
Daimlerstraße 1K - D-63303 Dreieich Deutschland.
Vor Benutzung Bedienungsanleitung beachten.

Importado por: **MIDLAND IBERIA, SA**
C/Cobalt, 48 - 08940 Cornellà de Llobregat, Barcelona - España.
Antes de utilizar, lea atentamente el manual de uso.

Importé par: **ALAN FRANCE S.A.R.L.**
5, Rue Ferrie, Zac les Portes du Vexin 95300 Ennery - France.
Avant l'utilisation, lire les instructions.



BLUETOOTH MICROPHONE
DUALMIKE
((WIRELESS))




To download the complete user manual and for information about the warranty please visit www.midlandeurope.com

QUICK GUIDE


EN

DUALMIKE WIRELESS OVERVIEW




1. Volume -
2. Led
3. Volume + (Power Off - 3 sec.)
4. Emergency key (or customizable)
5. Channel up; Channel down (CBTalk)
6. Speaker
7. USB charging port/FW upgrade port
8. Light ring
9. Secondary PTT
10. PTT CBTalk (Power On - 3 sec.)
11. DUAL MIKE WIRELESS is supplied with a metallic plate very useful for magnetic fixing of the microphone and wireless recharge. To use it remove the plastic support fixed with a screw*.

RECHARGE



With USB cable (included)



WIRELESS RECHARGE
Through DK-DUAL,
optional Docking
Station
(The plastic support
must be removed,
see point 11*)

POWER ON



- Power On
- Led steady blue 3 sec.

POWER OFF



- Power Off
- Led steady red 3 sec.

PAIRING WITH SMARTPHONES

3 sec. PRESS TOGETHER
PTT CBTALK and VOL+



STEP 1

- Pairing
- Red and blue leds alternately blink



STEP 2

- Telephone connected
- Blue led blinks 3 times

PAIRING WITH OTHER BLUETOOTH DEVICES

3 sec. PRESS TOGETHER
secondary PTT and VOL+



STEP 1


- Pairing
- Red and blue leds alternately blink



STEP 2

- Bluetooth connected
- Blue led blinks 3 times

HAND-FREE PHONE CALLS



To answer/to end a call

- White light ring



To reject an incoming call

- White light ring



To make a voice dial

AUDIO VOLUME



Bop (max vol. Beep)