


# Questo manuale d'istruzione è fornito da trovaprezzi.it. Scopri tutte le offerte per Planet GSW-1601 o cerca il tuo prodotto tra le migliori offerte di Switch

# 1. Package Contents

Thank you for purchasing PLANET 16-/24-Port 10/100/1000BASE-T Unmanaged Gigabit Ethernet Switch, GSW-1601/GSW-2401. **"Gigabit Ethernet Switch"** mentioned in this User's Manual refers to the GSW-1601/GSW-2401.

Open the box of the Gigabit Ethernet Switch and carefully unpack it. The box should contain the following items:



If any of these are missing or damaged, please contact your dealer immediately; if possible, retain the carton including the original packing material, and use them again to repack the product in case there is a need to return it to us for repair.

### **Hardware Features**

- 100~240V AC, 0.5A, 50~60Hz universal power input (GSW-1601)
- 100~240V AC, 0.8A, 50~60Hz universal power input (GSW-2401)
- FCC, CE class A compliant

## 3. Product Specifications

Product	GSW-1601	GSW-2401		
Hardware Specifications				
Hardware Version	8			
10/100/1000BASE-T MDI/MDIX Ports	16	24		
Throughput (packet per second)	23.8Mpps	35.7Mpps		
Switch Fabric	32Gbps	48Gbps		
Weight	1.4kg	1.5kg		
Power Consumption/ Dissipation	8.6 watts/ 29 BTU	15.7 watts/ 53 BTU		
Power Requirements	100~240V AC, 0.5A, 50-60Hz	100~240V AC, 0.8A, 50-60Hz		

## 4. Switch Front Panel

Figures 1 & 2 show the front panels of the GSW-1601 and GSW-2401.



Figure 1: GSW-1601 Front Panel



Figure 2: GSW-2401 Front Panel

## 5. Switch Rear Panel

Figure 3 shows the rear panel of the GSW-1601/GSW-2401



Figure 3: GSW-1601/GSW-2401 Rear Panel



- 1. The device is a power-required device, meaning it will not work till it is powered. If your network should be active all the time, please consider using UPS (Uninterrupted Power Supply) for your device. It will prevent you from network data loss or network downtime.
- 2. In some areas, installing a surge suppression device may also help to protect your Gigabit Ethernet Switch from being damaged by unregulated surge or current to the Switch or the power adapter.

- 1 -

- 3 -

- 5 -

# LED Indicators

GSW-1601/GSW-2401

## System

LED	Color	Function	
PWR	Green	<b>Lights:</b> to indicate that the Switch has power.	

## Per 10/100/1000BASE-T Port

LED	Color	Function	
10/100 LNK/ACT	Orange	Lights: to indicate the link through that port is established successfully at 10/100Mbps.  Blinks: to indicate that the Switch is actively sending or receiving data over that port.	
1000 LNK/ACT	Green	Lights: to indicate the link through that port is established successfully at 1000Mbps.  Blinks: to indicate that the Switch is actively sending or receiving data over that port.	

# 6. Installing the Switch

This part describes how to install your Gigabit Ethernet Switch and make connections to it. Please follow the procedure below:

- 7 -



This Gigabit Ethernet Switch does not need software configuration.

## **Desktop Installation**

To install the Gigabit Ethernet Switch on the desktop, simply follow these steps:

- **Step 1:** Attach the rubber feet to the recessed areas on the bottom of the Gigabit Ethernet Switch.
- **Step 2:** Place the Gigabit Ethernet Switch on the desktop near an AC power source.
- **Step 3:** Keep enough ventilation space between the Gigabit Ethernet Switch and the surrounding objects.



When choosing a location, please keep in mind the environmental restrictions discussed in Section 3 under Product Specifications.

## 2. Product Features

## **Physical Port**

- 16/24 10/100/1000BASE-T Gigabit Ethernet ports
- Supports auto MDI/MDI-X function

## Layer 2 Features

- Complies with IEEE 802.3, 10BASE-T, IEEE 802.3u 100BASE-TX, IEEE 802.3ab 1000BASE-T Ethernet standards
- Features Store-and-Forward mode with wire-speed filtering and forwarding rates
- Integrated address look-up engine, supporting 8K absolute MAC addresses
- 9K jumbo packet support
- Power saving ability for Green networking
- IEEE 802.1Q VLAN packet transparency support
- IEEE 802.3x flow control for full duplex operation and back pressure for half duplex operation
- Hardware-based 10/100BASE-TX, half/full duplex and 1000BASE-T full duplex mode, flow control and autonegotiation
- Automatic address learning and address aging
- Supports CSMA/CD protocol

Dimensions 440 x 210 x 44mm, 1U height  $(W \times D \times H)$ Switch Processing Store-and-Forward Scheme Address Table 8K entries Jumbo Packet Size 9K Back pressure for half duplex, IEEE Flow Control 802.3x Pause Frame for full duplex Operating: 0~50 degrees C Temperature Storage: -10~70 degrees C Operating: 5% to 95% (non-condensing) Humidity Storage: 5% to 95% (non-condensing) Standards Conformance FCC Part 15 Class A, CE Compliance IEEE 802.3 (Ethernet) IEEE 802.3u (Fast Ethernet) IEEE 802.3ab (Gigabit Ethernet) Standards IEEE 802.3x (Full-Duplex Flow Compliance Control) IEEE 802.3az Energy Efficient Ethernet (EEE)

-2- -6- -8-

- Step 4: Connect your Gigabit Ethernet Switch to network devices.
  - A. Connect one end of a standard network cable to the 10/100/1000BASE-T RJ45 ports on the front of the Gigabit Ethernet Switch.
  - B. Connect the other end of the cable to the network devices such as printer servers. workstations or routers, etc.
- **Step 5:** Supply power to the Gigabit Ethernet Switch.
  - A. Connect one end of the power cable to the Gigabit Ethernet Switch.
  - **B.** Connect the power plug of the power cable to a standard wall outlet.

When the Gigabit Ethernet Switch receives power, the Power LED should remain solid Green.

- 9 -

## **Rack Mounting**

To install the Gigabit Ethernet Switch in a 19-inch standard rack, follow the instructions described below:

- Step 1: Place your Gigabit Ethernet Switch on a hard flat surface, with the front panel positioned towards your front side.
- Step 2: Attach a rack-mount bracket to each side of the Switch with supplied screws attached to the package. Figure 4 shows how to attach brackets to one side of the Gigabit Ethernet Switch.



Figure 4: Attaching the brackets to the Gigabit Ethernet Switch



You must use the screws supplied with the mounting brackets. Damage caused to the parts by using incorrect screws would invalidate your warranty.

- Step 3: Secure the brackets tightly.
- Step 4: Follow the same steps to attach the second bracket to the opposite side.
- Step 5: After the brackets are attached to the Gigabit Ethernet Switch, use suitable screws to securely attach the brackets to the rack, as shown in Figure 5.




Figure 5: Mounting the Gigabit Ethernet Switch in a Rack

Step 6: Proceed with Steps 4 and 5 of Desktop Installation to connect the network cabling and supply power to your Gigabit Ethernet Switch.

- 11 -

## **Customer Support**

Thank you for purchasing PLANET products. You can browse our online FAQ resource on PLANET Web site first to check if it could solve your issue. If you need more support information, please contact PLANET switch support team.

PLANET online FAO:

http://www.planet.com.tw/en/support/faq

Switch support team mail address: support@planet.com.tw

Copyright © PLANET Technology Corp. 2019 Contents are subject to revision without prior notice. PLANET is a registered trademark of PLANET Technology Corp. All other trademarks belong to their respective owners.

- 12 -- 10 -





User's Manual

www.PLANET.com.tw

16/24-Port Gigabit Ethernet Switch

➤ GSW-1601/GSW-2401



PLANET Technology Corp.

10F No 96 Minguan Rd Xindian Dist New Tainei City 231 Taiwan

2011-A50140-006



#### **EC Declaration of Conformity**

For the following equipmen

: 16-/24-Port 10/100/1000Mbps Gigabit Ethernet Switch : GSW-1601, GSW-2401

: Planet Technology Corp. Manufacturer's Address : 10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan R.O.C.

is herewith confirmed to comply with the requirements set out in Approximation of the Laws of the Member States relating to Elect Directive on 2014/30/EU; Low Voltage Directive 2014/35/EU.

For the evaluation regarding the EMC, the following standards were applied

EN 55032 (2015) EN 61000-3-2 (2014) EN 61000-3-3 (2013) EN 55024 (2010)

(2006+A11:2009+A1:2010+A12:2011+A2: 2013) EN 60950-1

Responsible for marking this declaration if the:

☑ Manufacturer ☐ Authorized representative established within the EU Authorized representative established within the EU (if applicable)

Company Name: Planet Technology Corp. Company Address: 10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan R.O.C.

Person responsible for making this declaration Name, Surname Kent Kang Position / Title : Director

## PLANET TECHNOLOGY CORPORATION

e-mail: sales@planet.com.tw http://www.planet.com.tw
10F., No.96, Minquan Rd., Xindian Dist., New Taipei City, Taiwan, R.O.C. Tel:886-2-2219-9518 Fax:886-2-2219-9528