



RAZER NOMMO

MASTER GUIDE

The **Razer Nommo** is designed for gamers who want to flood their rooms with the sounds of their favorite games, music and movies. With Kevlar®-coated 77mm drivers, a wide sound field with high positional accuracy, dedicated rear-facing firing bass ports and bass control with automatic gain control technology, you have the ultimate in power and versatility.

CONTENTS

1. PACKAGE CONTENTS / SYSTEM REQUIREMENTS	3
2. REGISTRATION / TECHNICAL SUPPORT.....	4
3. TECHNICAL SPECIFICATIONS.....	5
4. DEVICE LAYOUT.....	6
5. USING YOUR RAZER NOMMO.....	7
6. SAFETY AND MAINTENANCE	10
8. LEGALESE.....	11

1. PACKAGE CONTENTS / SYSTEM REQUIREMENTS

PACKAGE CONTENTS

- Razer Nommo 2.0 gaming speakers
- 3.5 mm audio cable
- Power adapter with regional plug*
- Important Product Information Guide

**May vary for specific regions*

HARDWARE REQUIREMENTS

- Devices with 3.5 mm audio port


2. REGISTRATION / TECHNICAL SUPPORT

REGISTRATION

Register your product online at razer-id.razerzone.com/warranty to get real-time information on your product's warranty status.

If you haven't registered for a Razer ID yet, register now at razer-id.razerzone.com to get a wide range of Razer benefits.

*Your product's serial number
can be found here.*



TECHNICAL SUPPORT

What you'll get:


- 1 year limited manufacturer's warranty.
- Free online technical support at support.razerzone.com.

3. TECHNICAL SPECIFICATIONS

SPEAKERS

- 2 x 77mm full range drivers (1 x per speaker)
- Frequency response – 50-20,000hz
- 1 x 3.5mm audio input jack
- 1 x 3.5mm headphone jack
- 1 x 3.5mm aux-in jack
- Bass and volume control


4. DEVICE LAYOUT




- A. 2.5" Full range speakers
- B. Bass control
- C. Power switch / volume control
- D. Audio input port
- E. Aux input port
- F. DC power port
- G. Headphone output port
- H. 3.5 mm audio cable
- I. Power adapter
- J. Interchangeable plugs

5. SETTING UP YOUR RAZER NOMMO


1. Attach the regional plug to the power adapter.



2. Plug the power adapter from your speakers to an appropriate power source.




3. Plug the 3.5mm cable from the audio input port of your Razer Nommo to your audio device.



6. USING YOUR RAZER NOMMO

POWERING ON / OFF

To power on the speakers, simply rotate the volume control clockwise until you hear a click. To power off the speakers, rotate the volume control counter-clockwise until you hear a click.



USING THE VOLUME CONTROL

While powered on, rotate the volume control to increase or decrease the volume. This function also works on the headphone that is connected to your Razer Nommo.




USING THE BASS CONTROL

Rotate the bass control clockwise to increase or counter-clockwise to decrease the bass levels. This function also works on the headphone that is connected to your Razer Nommo.



USING THE AUX INPUT PORT


Plug a 3.5mm cable* from the aux input port of your Razer Nommo to your audio device. If the audio input port and aux input port are in use, Razer Nommo will combine both sounds.



**not included*

USING THE HEADPHONE OUTPUT PORT

While powered on, connect your headphone to the headphone output port of your Razer Nommo.



Note: The sound output will automatically switch from the speakers to the headphones.

6. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer Nommo, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to razer.com/support for support. Do not attempt to service or fix the device yourself at any time.

Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

Listening to excessively loud volumes over extended periods of time can damage your hearing. Furthermore, legislation of certain countries permits a maximum sound level of 86db to affect your hearing for 8 hours a day. We therefore recommend that you reduce the volume to a comfortable level when listening for prolonged periods of time. Please, take good care of your hearing.

MAINTENANCE AND USE

The Razer Nommo requires minimum maintenance to keep it in optimum condition. Once a month we recommend you unplug the device from the computer and clean it using a soft cloth or cotton swab with a bit of warm water to prevent dirt buildup. Do not use soap or harsh cleaning agents.

8. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2017 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Powered by Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks and trade names are the property of their respective owners and other company and product names mentioned herein may be trademarks of their respective companies.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Nommo (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit:
razerzone.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

COSTS OF PROCUREMENT

For the avoidance of doubt, in no event will Razer be liable for any costs of procurement unless it has been advised of the possibility of such damages, and in no case shall Razer be liable for any costs of procurement liability exceeding the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.