

# Questo manuale d'istruzione è fornito da trovaprezzi.it. Scopri tutte le offerte per Samsung Galaxy

Buds Live Mystic Bronze o cerca il tuo prodotto tra le migliori offerte di Cuffie e Microfoni

# SAMSUNG Galaxy Buds Live




### What's in the box


- Earbuds (L/R)
- · Charging case
- · Wingtips (S/L)
- · USB cable (Plug sold seperately)
- · Quick Start Guide

## Your device

#### Ear buds



### Charging case



# Charge your device

- 1. Insert the buds into the charging case.
- Close the charging case and connect the USB cable.
- 3. The earbuds and the charging case are charged simultaneously

You can also charge the earbuds and charging case simultaneously using a wireless charger.

Use only Samsung-approved charging devices and accessories. Using other accessories may void your warranty and may cause damage.

# Charging case indicators

- Green Fully charged or above
  60% battery
- Yellow Between 30% and 60% battery
- Red Charging or below 30% battery
- Flashing Red Charging disabled or error due to abnormal temperatures or low battery

#### Download

#### Galaxy Wearable app

To connect your earbuds and smart-phone, install the **Galaxy Wearable** (Android devices) or **Samsung Galaxy Buds** (iOS devices) app.

Download the app on to a compatible phone from the Galaxy Store, Playstore or the App store. Use the app to view the connection status, and various setting options.



# Connect

## Connect to your Samsung device

Open the charging case to enter Bluetooth pairing mode.

Note: Press the left and right touchpads at the same time to manually enter Bluetooth pairing mode.


A pop-up window displays on your mobile device > tap Connect and follow the prompts.

You can download the Galaxy Wearable app only on mobile devices running Android operating system 5.0 (API 21), or later, and with 1.5 GB of RAM or more.



# Wearing your device

Check the direction of each earbud and point their lower halves (speakers) in the direction of the lower part of your ear.



# Gestures



Single Tap Music Play/Pause

# Double Tap

Music

Next song

Calls Answer/End a call Switch between calls

Triple Tap

Music Previous song Touch & Hold

Digital assistant Launch Bixby or Google

Music

Launch supported music apps

Calls

Reject a call

Noise cancellation

Launch active noise canceling

Samsung Electronics America, Inc.

85 Challenger Road Ridgefield Park, New Jersey 07660

Phone: 1-800-SAMSUNG (726-7864)

Internet: www.samsung.com

©2020 Samsung Electronics America, Inc. Samsung, Samsung Galaxy, Samsung Health, and Galaxy Wearable are all trademarks of Samsung Electronics Co., Ltd. Other marks are the property of their

respective owners.

Screen images are simulated. Appearance of device may vary.