

SMB • DICKIE • GROUP			
Item No.	10 589 3264	Process Colors	C, M, Y, K
Client	Simba Toys	Extra Colors	xx
Account Contact	Mr. U. J. Stork	Discount	xx (no discount, see print, use as a positional guide only)
Job No.	81154	Color Profile	ISO Coated v2 (ECI)
Artwork Contact	e.hack@simba-dickie.com	Programs	Adobe Creative Suite CC
Artwork Contact Email	smaller@simba-dickie.com	Kind of package	WM • Inset
Date	17.04.2019		
Size	200 (mm) x 311 (mm) x 180 (mm)		


This artwork will require colorimetric approval. This proof of this work will be required by the client. Then the proof and the data should be sent together to the maker. The Simba Dickie Group will not be held responsible for the color that is produced. The color should not be altered.



D: ACHTUNG! GB: WARNING! F: ATTENTION! I: AVVERTENZA! NL: WAARSCHUWING!
E: ¡ADVERTENCIA! P: ATENÇÃO! DK: ADVARSEL! S: VARNING! FIN: VAROITUS!
N: ADVARSEL! H: HIGYELMEZTETÉS! CZ: UPOZORNĚNÍ! PL: OSTRZEŻENIE!
GR: ΠΡΟΕΙΔΟΠΟΙΗΣΗ! RU: ВНИМАНИЕ! TR: UYARI! SI: OPOZORILO!
HRV: UPOZORENJE! SK: UPOZORNENIE! BG: ВНИМАНИЕ! RO: AVERTISMENT!
UA: УВАГА! EST: HOIATUS! LT: ĮSPĖJIMAS! LV: BRĪDĪJUMS! AR: تحذير!



[illegible][illegible]

POSITION






POO POO PUPPY INSTRUCTION



EASY TO CLEAN



D: Nach jeder Verwendung bitte die Knete vollständig entfernen. **GB:** Please remove the dough completely after each use. **F:** Retirer entièrement la pâte à modeler après chaque utilisation. **I:** Rimuovere completamente la plastilina dopo ogni utilizzo. **NL:** Na elk gebruik de kneedmassa a.u.b. volledig verwijderen. **E:** Retirar completamente la masa después de cada uso. **P:** Retirar completamente a plasticina após a utilização. **DK:** Renses for modellervoks efter hver anvendelse. **S:** Ta bort all deg efter varje användning. **FIN:** Poista muovailuvaha kokonaan jokaisen käytön jälkeen. **N:** Pass på å fjerne modelleiren helt hver gang. **H:** A gyurmát minden használat után gondosan el kell távolítani. **CZ:** Hmotu po každém použití kompletně odstraňte. **PL:** Po każdym użyciu proszę całkowicie usunąć plastelinę. **GR:** Μετά από κάθε χρήση να απομακρύνεται πλήρως την πλαστελίνη. **RUS:** После каждого использования полностью удалите пластилин. **TR:** Kullandıktan sonra lütfen oyun hamurunu kalıntı bırakmadan temizleyiniz. **SI:** Po vsaki uporabi odstranite vso maso iz igrače. **HRV:** Nakon svake uporabe u cijelosti ukloniti korišten plastelin. **SK:** Hmotu po každom použití úplne odstráňte. **BG:** След всяка употреба, моля пластилинът напълно да се премахне. **RO:** După fiecare utilizare îndepărtați plastilina complet. **UA:** Після кожного використання повністю видаліть пластилін. **EST:** Palun eemaldada voolimismass täielikult pärast iga kasutamist. **LT:** Po kiekvieno naudojimo pašalinkite visą plastiliną. **LV:** Pēc katras lietošanas pilnībā noņemiet plastilīnu. **AR:** أزل الصلصال تمامًا بعد كل استخدام.