




Questo manuale d'istruzione è fornito da trovaprezzi.it. Scorri tutte le offerte per Sony WI-C100

Sei o cerca il tuo prodotto tra i migliori offerte in Cuffie wireless



This product (including accessories) has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

There is a danger that small parts may be swallowed. Do not use this product in a location of reach of small children.

Note about static electricity
If you use the unit when the air is dry, you may experience discomfort due to static electricity accumulated on your body. This is not a malfunction of the unit. You can reduce the effect by wearing clothes made of natural materials that do not easily generate static electricity.

Precautions
The two-dimensional code or the URL on the cover may help you access the help guide that describes useful notes or procedures in details.

On water resistant of the unit
• Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions.
Note the following cautions carefully and use the unit correctly.
(Make sure that the USB Type-C® port cover is closed when you use the unit.)

To maintain water-resistant performance
Carefully note the precautions below to ensure proper use of the unit.
• Make sure the USB Type-C port cover is closed securely when using the unit. If there is any foreign material on the cover, clean it off. When completely closed, the water-resistant performance cannot be maintained. Water may get inside and cause the unit to malfunction.

Notice for customers: the following information is only applicable to products sold in countries applying EU directives and/or UK applying relevant statutory requirements
This product has been manufactured by or on behalf of Sony Corporation.
Inquiries to the EU Importer or related to product compliance in Europe should be sent to the manufacturer's authorized representative, Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciënlaan 7-01, 1930 Zaventem, Belgium.
Hereby, Sony Corporation declares that this information is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

This product has been manufactured by or on behalf of Sony Corporation.
UK Importer: Sony Europe B.V.
Inquiries to the UK Importer or related to product compliance in the UK should be sent to the manufacturer's authorized representative, Sony Europe B.V., The Heights, Brooklands, Weybridge, Surrey KT20 0DW, United Kingdom.
Hereby, Sony Corporation declares that this information is in compliance with the UK relevant statutory requirements.

The full text of the declaration of conformity is available at the following internet address: <https://compliance.sony.co.uk>

Disposal of waste batteries and electrical and electronic equipment (applicable in the EU and other countries with separate collection systems)
This symbol on the product, the battery or on the packaging indicates that the product and the battery should not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. This is not a malfunction. The chemical symbol for lead (Pb) is added if the battery contains more than 0.04% lead. By ensuring that these products and batteries are disposed of correctly, you will help to prevent potentially negative consequences for the environment and human health. Damage may be caused by inappropriate waste handling. The recycling of the materials will help to conserve natural resources. In case of products that the safety, performance or data integrity reasons require a permanent connection to a power source, incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery and the electrical and electronic equipment will be treated properly, hand over these products at end-of-life to the appropriate collection point for the recycling of electrical and electronic equipment. For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery to the appropriate collection point for the recycling of waste batteries. For more detailed information about recycling of this product or battery, please contact your local City, Office, your household waste disposal service or the shop where you purchased the product or battery.

On charging the unit
• Make sure to close the USB Type-C port cover securely after charging. Respiration or water may cause damage (Fig. 1).
Notes on wearing the unit
• After removing the headphones slowly. When wearing the earbuds type, the speaker diaphragm may produce a click sound. This is not a malfunction.
Other notes
• If you experience discomfort while using the unit, stop using it immediately.
• If you have any questions or problems concerning this product that are not covered in this manual, please consult your nearest Sony dealer.

Specifications
Headset
Power source: DC 3.7 V. Built-in lithium-ion rechargeable battery.
Battery: DC 5 V. When charged using USB.
Operating temperature: 0 °C to 40 °C.
Rated power consumption: 0.4 W.
Mass: Approx. 20 g.
Included items:
• Wireless Stereo Headset (1)
• Hybrid silicone rubber earbud tips (SS (1 line) (2), M (3 lines) (two), L (5 lines) (two))
• USB Type-C cable (1) (2, LL (5 lines) (2))

Communication system
Bluetooth Specification Version 5.0
Frequency band: 2.4 GHz band (2400 MHz - 2483.5 MHz)
Maximum output power: Bluetooth: 2400 MHz - 2483.5 MHz
Bluetooth: 2400 MHz - 2483.5 MHz

Design and specifications are subject to change without notice.
System requirements for battery charge using USB
USB AC adaptor
A commercially available USB AC adaptor capable of supplying a constant output current of 0.5 A (500 mA) or more.

USB cable
Connect the USB cable to the USB Type-C cable (compatible with USB standards).

Compatible iPhone/iPod models
iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2nd generation), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone SE, iPod touch (7th generation), iPod touch (6th generation).
(As of January 2022)

Trademarks
• Apple, iPhone, iPod and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
• The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.
• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "™" marks are not specified.

On water resistant of the unit
• Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions.
Note the following cautions carefully and use the unit correctly.
(Make sure that the USB Type-C® port cover is closed when you use the unit.)

To maintain water-resistant performance
Carefully note the precautions below to ensure proper use of the unit.
• Make sure the USB Type-C port cover is closed securely when using the unit. If there is any foreign material on the cover, clean it off. When completely closed, the water-resistant performance cannot be maintained. Water may get inside and cause the unit to malfunction.

Notice for customers: the following information is only applicable to products sold in countries applying EU directives and/or UK applying relevant statutory requirements
This product has been manufactured by or on behalf of Sony Corporation.
Inquiries to the EU Importer or related to product compliance in Europe should be sent to the manufacturer's authorized representative, Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciënlaan 7-01, 1930 Zaventem, Belgium.
Hereby, Sony Corporation declares that this information is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

Remarques sur le port du dispositif
• Après utilisation, retirez le casque d'écoute intentionnellement.
• Les écouteurs d'oreillettes permettant d'établir un joint étanche sur les oreilles, le fait de les presser avec vigueur ou de les retirer rapidement peut entraîner des lésions des tympons.
Lors du port des écouteurs d'oreillettes, le diaphragme du haut-parleur peut produire un cliquetis. Il ne s'agit pas d'un dysfonctionnement.

Autres remarques
• Si vous ressentez une gêne lors de l'utilisation du dispositif, arrêtez de l'utiliser immédiatement.
• Pour obtenir des réponses à toutes questions ou des solutions pour tous problèmes concernant le dispositif, qui ne sont pas abordés dans ce manuel, veuillez consulter votre revendeur Sony le plus proche.

Spécifications
Casque
Source d'alimentation : 3,7 V CC - batterie au lithium-ion rechargeable intégrée.
5 V CC - en cas de charge par USB.
Température de fonctionnement : 0 °C à 40 °C.
Consommation électrique à la puissance nominale : 0,4 W.
Masse : Environ 20 g.

Éléments inclus
• Casque stéréo sans fil (1)
• Embouts d'oreillettes en caoutchouc hybride (SS (1 ligne) (2), M (3 lignes) (deux), L (5 lignes) (deux))
• Câble USB Type-C (1) (2, LL (5 lignes) (2))

Spécifications de communication
Système de communication : Spécification Bluetooth version 5.0
Sortie : Spécification Bluetooth classe de puissance 2
Gamme de fréquences : Bande 2,4 GHz (2400 GHz - 2483,5 GHz)
Fréquence de fonctionnement : Bluetooth : 2400 MHz - 2483,5 MHz
Puissance de sortie maximale : Bluetooth : < 3 dBm

Configuration système pour la charge de la batterie
Adaptateur secteur USB
Adaptateur secteur USB disponible dans le commerce capable de fournir un courant de sortie de 0,5 A (500 mA) minimum.
Câble USB
Câble USB Type-C disponible dans le commerce (conforme aux normes USB).

Modèles compatibles avec iPhone/iPod
iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2ème génération), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone SE, iPod touch (7ème génération), iPod touch (6ème génération).
(À compter de janvier 2022)

Marques
• Apple, iPhone, iPod et iPod touch sont des marques commerciales d'Apple Inc., enregistrées aux États-Unis et dans d'autres pays.
• La marque et les logos Bluetooth® sont des marques commerciales déposées appartenant à Bluetooth SIG, Inc. et toute utilisation de ces marques par Sony Group Corporation et ses filiales est sous licence.
• USB Type-C® et USB-C® sont des marques commerciales déposées d'USB Implementers Forum.
• Tous les autres marques et marques déposées sont des marques ou des marques déposées de leurs détenteurs respectifs. Les symboles "®" et "™" ne sont pas spécifiés dans ce manuel.

On water resistant of the unit
• Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions.
Note the following cautions carefully and use the unit correctly.
(Make sure that the USB Type-C® port cover is closed when you use the unit.)

To maintain water-resistant performance
Carefully note the precautions below to ensure proper use of the unit.
• Make sure the USB Type-C port cover is closed securely when using the unit. If there is any foreign material on the cover, clean it off. When completely closed, the water-resistant performance cannot be maintained. Water may get inside and cause the unit to malfunction.

Notice for customers: the following information is only applicable to products sold in countries applying EU directives and/or UK applying relevant statutory requirements
This product has been manufactured by or on behalf of Sony Corporation.
Inquiries to the EU Importer or related to product compliance in Europe should be sent to the manufacturer's authorized representative, Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciënlaan 7-01, 1930 Zaventem, Belgium.
Hereby, Sony Corporation declares that this information is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

Disposal of waste batteries and electrical and electronic equipment (applicable in the EU and other countries with separate collection systems)
This symbol on the product, the battery or on the packaging indicates that the product and the battery should not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. This is not a malfunction. The chemical symbol for lead (Pb) is added if the battery contains more than 0.04% lead. By ensuring that these products and batteries are disposed of correctly, you will help to prevent potentially negative consequences for the environment and human health. Damage may be caused by inappropriate waste handling. The recycling of the materials will help to conserve natural resources. In case of products that the safety, performance or data integrity reasons require a permanent connection to a power source, incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery and the electrical and electronic equipment will be treated properly, hand over these products at end-of-life to the appropriate collection point for the recycling of electrical and electronic equipment. For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery to the appropriate collection point for the recycling of waste batteries. For more detailed information about recycling of this product or battery, please contact your local City, Office, your household waste disposal service or the shop where you purchased the product or battery.

On charging the unit
• Make sure to close the USB Type-C port cover securely after charging. Respiration or water may cause damage (Fig. 1).
Notes on wearing the unit
• After removing the headphones slowly. When wearing the earbuds type, the speaker diaphragm may produce a click sound. This is not a malfunction.
Other notes
• If you experience discomfort while using the unit, stop using it immediately.
• If you have any questions or problems concerning this product that are not covered in this manual, please consult your nearest Sony dealer.

Specifications
Headset
Power source: DC 3.7 V. Built-in lithium-ion rechargeable battery.
Battery: DC 5 V. When charged using USB.
Operating temperature: 0 °C to 40 °C.
Rated power consumption: 0.4 W.
Mass: Approx. 20 g.
Included items:
• Wireless Stereo Headset (1)
• Hybrid silicone rubber earbud tips (SS (1 line) (2), M (3 lines) (two), L (5 lines) (two))
• USB Type-C cable (1) (2, LL (5 lines) (2))

Communication system
Bluetooth Specification Version 5.0
Frequency band: 2.4 GHz band (2400 MHz - 2483.5 MHz)
Maximum output power: Bluetooth: 2400 MHz - 2483.5 MHz
Bluetooth: 2400 MHz - 2483.5 MHz

Design and specifications are subject to change without notice.
System requirements for battery charge using USB
USB AC adaptor
A commercially available USB AC adaptor capable of supplying a constant output current of 0.5 A (500 mA) or more.

USB cable
Connect the USB cable to the USB Type-C cable (compatible with USB standards).

Compatible iPhone/iPod models
iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2nd generation), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone SE, iPod touch (7th generation), iPod touch (6th generation).
(As of January 2022)

Trademarks
• Apple, iPhone, iPod and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
• The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.
• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "™" marks are not specified.

On water resistant of the unit
• Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions.
Note the following cautions carefully and use the unit correctly.
(Make sure that the USB Type-C® port cover is closed when you use the unit.)

To maintain water-resistant performance
Carefully note the precautions below to ensure proper use of the unit.
• Make sure the USB Type-C port cover is closed securely when using the unit. If there is any foreign material on the cover, clean it off. When completely closed, the water-resistant performance cannot be maintained. Water may get inside and cause the unit to malfunction.

Notice for customers: the following information is only applicable to products sold in countries applying EU directives and/or UK applying relevant statutory requirements
This product has been manufactured by or on behalf of Sony Corporation.
Inquiries to the EU Importer or related to product compliance in Europe should be sent to the manufacturer's authorized representative, Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciënlaan 7-01, 1930 Zaventem, Belgium.
Hereby, Sony Corporation declares that this information is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

Disposal of waste batteries and electrical and electronic equipment (applicable in the EU and other countries with separate collection systems)
This symbol on the product, the battery or on the packaging indicates that the product and the battery should not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. This is not a malfunction. The chemical symbol for lead (Pb) is added if the battery contains more than 0.04% lead. By ensuring that these products and batteries are disposed of correctly, you will help to prevent potentially negative consequences for the environment and human health. Damage may be caused by inappropriate waste handling. The recycling of the materials will help to conserve natural resources. In case of products that the safety, performance or data integrity reasons require a permanent connection to a power source, incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery and the electrical and electronic equipment will be treated properly, hand over these products at end-of-life to the appropriate collection point for the recycling of electrical and electronic equipment. For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery to the appropriate collection point for the recycling of waste batteries. For more detailed information about recycling of this product or battery, please contact your local City, Office, your household waste disposal service or the shop where you purchased the product or battery.

On charging the unit
• Make sure to close the USB Type-C port cover securely after charging. Respiration or water may cause damage (Fig. 1).
Notes on wearing the unit
• After removing the headphones slowly. When wearing the earbuds type, the speaker diaphragm may produce a click sound. This is not a malfunction.
Other notes
• If you experience discomfort while using the unit, stop using it immediately.
• If you have any questions or problems concerning this product that are not covered in this manual, please consult your nearest Sony dealer.

Specifications
Headset
Power source: DC 3.7 V. Built-in lithium-ion rechargeable battery.
Battery: DC 5 V. When charged using USB.
Operating temperature: 0 °C to 40 °C.
Rated power consumption: 0.4 W.
Mass: Approx. 20 g.
Included items:
• Wireless Stereo Headset (1)
• Hybrid silicone rubber earbud tips (SS (1 line) (2), M (3 lines) (two), L (5 lines) (two))
• USB Type-C cable (1) (2, LL (5 lines) (2))

Communication system
Bluetooth Specification Version 5.0
Frequency band: 2.4 GHz band (2400 MHz - 2483.5 MHz)
Maximum output power: Bluetooth: 2400 MHz - 2483.5 MHz
Bluetooth: 2400 MHz - 2483.5 MHz

Design and specifications are subject to change without notice.
System requirements for battery charge using USB
USB AC adaptor
A commercially available USB AC adaptor capable of supplying a constant output current of 0.5 A (500 mA) or more.

USB cable
Connect the USB cable to the USB Type-C cable (compatible with USB standards).

Compatible iPhone/iPod models
iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2nd generation), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone SE, iPod touch (7th generation), iPod touch (6th generation).
(As of January 2022)

Trademarks
• Apple, iPhone, iPod and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
• The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.
• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "™" marks are not specified.

On water resistant of the unit
• Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions.
Note the following cautions carefully and use the unit correctly.
(Make sure that the USB Type-C® port cover is closed when you use the unit.)

To maintain water-resistant performance
Carefully note the precautions below to ensure proper use of the unit.
• Make sure the USB Type-C port cover is closed securely when using the unit. If there is any foreign material on the cover, clean it off. When completely closed, the water-resistant performance cannot be maintained. Water may get inside and cause the unit to malfunction.

Notice for customers: the following information is only applicable to products sold in countries applying EU directives and/or UK applying relevant statutory requirements
This product has been manufactured by or on behalf of Sony Corporation.
Inquiries to the EU Importer or related to product compliance in Europe should be sent to the manufacturer's authorized representative, Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciënlaan 7-01, 1930 Zaventem, Belgium.
Hereby, Sony Corporation declares that this information is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

Disposal of waste batteries and electrical and electronic equipment (applicable in the EU and other countries with separate collection systems)
This symbol on the product, the battery or on the packaging indicates that the product and the battery should not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. This is not a malfunction. The chemical symbol for lead (Pb) is added if the battery contains more than 0.04% lead. By ensuring that these products and batteries are disposed of correctly, you will help to prevent potentially negative consequences for the environment and human health. Damage may be caused by inappropriate waste handling. The recycling of the materials will help to conserve natural resources. In case of products that the safety, performance or data integrity reasons require a permanent connection to a power source, incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery and the electrical and electronic equipment will be treated properly, hand over these products at end-of-life to the appropriate collection point for the recycling of electrical and electronic equipment. For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery to the appropriate collection point for the recycling of waste batteries. For more detailed information about recycling of this product or battery, please contact your local City, Office, your household waste disposal service or the shop where you purchased the product or battery.

On charging the unit
• Make sure to close the USB Type-C port cover securely after charging. Respiration or water may cause damage (Fig. 1).
Notes on wearing the unit
• After removing the headphones slowly. When wearing the earbuds type, the speaker diaphragm may produce a click sound. This is not a malfunction.
Other notes
• If you experience discomfort while using the unit, stop using it immediately.
• If you have any questions or problems concerning this product that are not covered in this manual, please consult your nearest Sony dealer.

Specifications
Headset
Power source: DC 3.7 V. Built-in lithium-ion rechargeable battery.
Battery: DC 5 V. When charged using USB.
Operating temperature: 0 °C to 40 °C.
Rated power consumption: 0.4 W.
Mass: Approx. 20 g.
Included items:
• Wireless Stereo Headset (1)
• Hybrid silicone rubber earbud tips (SS (1 line) (2), M (3 lines) (two), L (5 lines) (two))
• USB Type-C cable (1) (2, LL (5 lines) (2))

Communication system
Bluetooth Specification Version 5.0
Frequency band: 2.4 GHz band (2400 MHz - 2483.5 MHz)
Maximum output power: Bluetooth: 2400 MHz - 2483.5 MHz
Bluetooth: 2400 MHz - 2483.5 MHz

Design and specifications are subject to change without notice.
System requirements for battery charge using USB
USB AC adaptor
A commercially available USB AC adaptor capable of supplying a constant output current of 0.5 A (500 mA) or more.

USB cable
Connect the USB cable to the USB Type-C cable (compatible with USB standards).

Compatible iPhone/iPod models
iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2nd generation), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone SE, iPod touch (7th generation), iPod touch (6th generation).
(As of January 2022)

Trademarks
• Apple, iPhone, iPod and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
• The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.
• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "™" marks are not specified.

On water resistant of the unit
• Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions.
Note the following cautions carefully and use the unit correctly.
(Make sure that the USB Type-C® port cover is closed when you use the unit.)

To maintain water-resistant performance
Carefully note the precautions below to ensure proper use of the unit.
• Make sure the USB Type-C port cover is closed securely when using the unit. If there is any foreign material on the cover, clean it off. When completely closed, the water-resistant performance cannot be maintained. Water may get inside and cause the unit to malfunction.

Notice for customers: the following information is only applicable to products sold in countries applying EU directives and/or UK applying relevant statutory requirements
This product has been manufactured by or on behalf of Sony Corporation.
Inquiries to the EU Importer or related to product compliance in Europe should be sent to the manufacturer's authorized representative, Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciënlaan 7-01, 1930 Zaventem, Belgium.
Hereby, Sony Corporation declares that this information is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

Disposal of waste batteries and electrical and electronic equipment (applicable in the EU and other countries with separate collection systems)
This symbol on the product, the battery or on the packaging indicates that the product and the battery should not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. This is not a malfunction. The chemical symbol for lead (Pb) is added if the battery contains more than 0.04% lead. By ensuring that these products and batteries are disposed of correctly, you will help to prevent potentially negative consequences for the environment and human health. Damage may be caused by inappropriate waste handling. The recycling of the materials will help to conserve natural resources. In case of products that the safety, performance or data integrity reasons require a permanent connection to a power source, incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery and the electrical and electronic equipment will be treated properly, hand over these products at end-of-life to the appropriate collection point for the recycling of electrical and electronic equipment. For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery to the appropriate collection point for the recycling of waste batteries. For more detailed information about recycling of this product or battery, please contact your local City, Office, your household waste disposal service or the shop where you purchased the product or battery.

On charging the unit
• Make sure to close the USB Type-C port cover securely after charging. Respiration or water may cause damage (Fig. 1).
Notes on wearing the unit
• After removing the headphones slowly. When wearing the earbuds type, the speaker diaphragm may produce a click sound. This is not a malfunction.
Other notes
• If you experience discomfort while using the unit, stop using it immediately.
• If you have any questions or problems concerning this product that are not covered in this manual, please consult your nearest Sony dealer.

Specifications
Headset
Power source: DC 3.7 V. Built-in lithium-ion rechargeable battery.
Battery: DC 5 V. When charged using USB.
Operating temperature: 0 °C to 40 °C.
Rated power consumption: 0.4 W.
Mass: Approx. 20 g.
Included items:
• Wireless Stereo Headset (1)
• Hybrid silicone rubber earbud tips (SS (1 line) (2), M (3 lines) (two), L (5 lines) (two))
• USB Type-C cable (1) (2, LL (5 lines) (2))

Communication system
Bluetooth Specification Version 5.0
Frequency band: 2.4 GHz band (2400 MHz - 2483.5 MHz)
Maximum output power: Bluetooth: 2400 MHz - 2483.5 MHz
Bluetooth: 2400 MHz - 2483.5 MHz

Design and specifications are subject to change without notice.
System requirements for battery charge using USB
USB AC adaptor
A commercially available USB AC adaptor capable of supplying a constant output current of 0.5 A (500 mA) or more.

USB cable
Connect the USB cable to the USB Type-C cable (compatible with USB standards).

Compatible iPhone/iPod models
iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2nd generation), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone SE, iPod touch (7th generation), iPod touch (6th generation).
(As of January 2022)

Trademarks
• Apple, iPhone, iPod and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
• The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.
• USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
• All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, "®" and "™" marks are not specified.

On water resistant of the unit
• Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions.
Note the following cautions carefully and use the unit correctly.
(Make sure that the USB Type-C® port cover is closed when you use the unit.)

To maintain water-resistant performance
Carefully note the precautions below to ensure proper use of the unit.
• Make sure the USB Type-C port cover is closed securely when using the unit. If there is any foreign material on the cover, clean it off. When completely closed, the water-resistant performance cannot be maintained. Water may get inside and cause the unit to malfunction.

Notice for customers: the following information is only applicable to products sold in countries applying EU directives and/or UK applying relevant statutory requirements
This product has been manufactured by or on behalf of Sony Corporation.
Inquiries to the EU Importer or related to product compliance in Europe should be sent to the manufacturer's authorized representative, Sony Belgium, bijkantoor van Sony Europe B.V., Da Vinciënlaan 7-01, 1930 Zaventem, Belgium.
Hereby, Sony Corporation declares that this information is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <https://compliance.sony.eu>

Disposal of waste batteries and electrical and electronic equipment (applicable in the EU and other countries with separate collection systems)
This symbol on the product, the battery or on the packaging indicates that the product and the battery should not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. This is not a malfunction. The chemical symbol for lead (Pb) is added if the battery contains more than 0.04% lead. By ensuring that these products and batteries are disposed of correctly, you will help to prevent potentially negative consequences for the environment and human health. Damage may be caused by inappropriate waste handling. The recycling of the materials will help to conserve natural resources. In case of products that the safety, performance or data integrity reasons require a permanent connection to a power source, incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery and the electrical and electronic equipment will be treated properly, hand over these products at end-of-life to the appropriate collection point for the recycling of electrical and electronic equipment. For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery to the appropriate collection point for the recycling of waste batteries. For more detailed information about recycling of this product or battery, please contact your local City, Office, your household waste disposal service or the shop where you purchased the product or battery.

On charging the unit
• Make sure to close the USB Type-C port cover securely after charging. Respiration or water may cause damage (Fig. 1).
Notes on wearing the unit
• After removing the headphones slowly. When wearing the earbuds type, the speaker diaphragm may produce a click sound. This is not a malfunction.
Other notes
• If you experience discomfort while using the unit, stop using it immediately.
• If you have any questions or problems concerning this product that are not covered in this manual, please consult your nearest Sony dealer.

Specifications<

