

Manuals+

User Manuals Simplified.



dyson TP7A Autoreact Purifier Cool User Manual

February 21, 2022 February 22, 2022

Home » dyson * dyson TP7A Autoreact Purifier Cool User Manual

Contents [hide

- 1 dyson TP7A Autoreact Purifier Cool
- 2 Assembling your machine
- **3 Getting started**
- 4 Power and continuous monitoring
- **5 Information menu**
- 6 Changing your HEPA+Carbon filter
- 7 Resetting your HEPA+Carbon filter life
- 8 Changing your HEPA and carbon filters
- 9 Resetting your HEPA and carbon filter life
- 10 Changing your HEPA+Carbon filters with a catalytic filter
- 11 Resetting your HEPA+Carbon filter life
- 12 Looking after your machine
- **13 Documents / Resources**
 - 13.1 Related Manuals / Resources



dyson TP7A Autoreact Purifier Cool



Front view of the Dyson Pure Cool Auto React air purifier fan, showing the amplifier loop and mesh filter cover.

Assembling your machine

Use both hands to lift your machine out of the box, by its base. Do not lift out by the loop amplifier. Assemble your machine with the filters that are supplied. **Dyson Purifier Cool Auto React**

Supplied with a HEPA+Carbon filter. Push your HEPA+Carbon filter into the outer cover and position onto the base. Push firmly until both outer covers click securely into place



The air purifier fan with the filter covers open showing a HEPA plus carbon filter located in the filter covers. Arrows demonstrate that the filter covers will need to be assembled onto the base of the machine.

Dyson Purifier Cool Auto React

Supplied with separate HEPA and carbon filters.

Push the carbon filters into place on the machine.

Push the HEPA filter into the outer cover. Put the outer covers into position on the base and push firmly until they both click securely into place.



The air purifier fan with the filter covers open showing a HEPA filter located in the filter covers and a carbon filter. Arrows demonstrate that the carbon filter is

fitted directly to the base of the machine and the filter covers will need to be assembled onto the base of the machine.


Dyson Purifier Cool Formaldehyde

Your machine comes with a permanent catalytic filter and a HEPA+Carbon filter.

Push the catalytic filter into position on the machine.

Push the HEPA+Carbon filter into the outer cover and position on the base.


Push firmly until both outer covers click into place.



The air purifier fan with the filter covers open showing a HEPA plus carbon filter located in the filter covers and a catalytic filter. Arrows demonstrate that the catalytic filter is fitted directly to the base of the machine and the filter covers will need to be assembled onto the base of the machine


Getting started

An image of the air purifier fan with the remote placed on the top of the loop amplifier and the location of the standby on/off button on the top of the base of the machine



The layout of the remote control with the power button on the top left, the

airflow speed toggle button in the middle left and the oscillation button on the bottom left. On the top right-hand side is the Information menu button, then going downwards is the Auto mode button, Airflow direction and then the Night mode button at the bottom.



Power and continuous monitoring

Stand-by on/off

Press the Standby on/off button on your Dyson purifying fan or remote control to stop your machine. It will continue to monitor the air quality.

Continuous monitoring

Continuous monitoring is turned off by default. Once turned on, it will always be active until you turn it off again. With continuous monitoring turned on, your Dyson purifying fan will gather air quality, temperature and humidity information, which is displayed on the LCD screen.

Continuous monitoring

Press and hold the Auto mode button on the remote control for 5 seconds to turn it on. The LCD screen will indicate

when continuous monitoring is on or off.

Information menu

Press this button to scroll through the information being monitored by your Dyson purifying fan. Information about air quality, temperature, humidity and filter levels is shown on the LCD screen. When a particular type of pollutant causes air quality to decrease, a symbol for the pollutant will show on the LCD screen.



The remote control with the information button on the top right

Indoor air quality – 12 seconds

Monitor the current air quality with a graph showing the last 12 seconds of data.

• Particulate matter (PM10)

Larger microscopic particles up to 10 microns in size, suspended in the air we breathe. These include dust, mould and pollen.

Nitrogen dioxide and other oxidising gases

These potentially harmful gases are released into the air by combustion, for example, the burning gas when cooking and in vehicle exhaust emissions

Indoor humidity

The amount of water vapour in the air, shown as a percentage.

• Formaldehyde (HCHO)

A common indoor pollutant. It can be released for many years from furnishings, floorings and glue.

Particulate matter (PM2.5

Microscopic particles up to 2.5 microns in size, suspended in the air we breathe. These include smoke, bacteria and allergens.

Volatile organic compounds

VOCs are typically odours that may be potentially harmful. These can be found in cleaning products, paints and furnishings.

Indoor temperature

Monitor the ambient temperature to help maintain a comfortable environment.

Filters

The remaining filter life is shown on the LCD screen and will indicate when your filters need replacing.

Auto mode

Set your Dyson purifying fan to Auto mode and the on-board sensors will intelligently adjust the settings of the machine according to the air quality.

Air quality: your machine will pause when the target air quality has been reached, switching on again when the air quality levels drop.

Airflow speed: the airflow speed will increase until the target air quality and temperature have been reached.



The remote control with the Auto mode button below the Information button on the right.

Airflow speed and direction

Press the Airflow speed button to increase and decrease the airflow speed. Press the Airflow direction button to change the direction of airflow from front to back. Change the airflow direction for your personal comfort. Select the Airflow direction to Fan mode for airflow from the front for purifying and cooling.





Oscillation

Press the Oscillation button to circulate the air around the room and scroll through the oscillation settings from 0° to



The remote control with the oscillation button on the bottom left.

350°.

Night mode and Sleep timer

In Night mode, your Dyson purifying fan will continue to monitor and respond to changes in air quality, but only using its quietest settings – and with its LCD screen dimmed.

Press the Night mode and Sleep timer button to scroll through the timer options.

The remote control with the Night mode and sleep timer button on the bottom right.



Changing your HEPA+Carbon filter

Before changing your filter, switch off and unplug your Dyson purifying fan.

The remaining filter life is displayed on the screen and will indicate when your non-washable filters need replacing. Press the Information button on your remote.


You'll need to reset the filter life on your machine.

Dyson Purifier Cool Auto React

Supplied with a HEPA+Carbon filter.

To change your HEPA+Carbon filter, push down on the buttons either side of your machine to release the outer cover. Push down on the tabs to remove the filter.

- Push the replacement filter into the outer cover and make sure the tabs click into place.
- Put the outer covers into position on your machine and push firmly until they both click securely into position.
- Plug in and switch your machine, and reset your filter life.



The air purifier fan with the filter covers open showing a HEPA plus

carbon filter located in the filter covers. Arrows demonstrate that the filter covers will need to be assembled onto the base of the machine.

Resetting your HEPA+Carbon filter life

It's important to reset your filter life after you have replaced your filter.

Resetting your HEPA+Carbon filter life

Press and hold the Night mode button on your remote control.

The display on your machine will countdown from five, the filter life will be reset and your machine is ready to use.



Pressing the night mode and sleep timer button on the bottom right of the remote

control for 5 seconds.

Changing your HEPA and carbon filters


Before changing your filter, switch off and unplug your Dyson purifying fan.

The remaining filter life is displayed on the screen and will indicate when your non-washable filters need replacing. Press the Information button on your remote.

You'll need to reset the filter life on your machine.

Dyson Purifier Cool Auto React

- Supplied with separate HEPA and carbon filters.
- To change your HEPA filter, push down on the buttons either side of your machine to release the filter covers. Push down on the tabs to remove the HEPA filter.
- Push the replacement filter into the outer cover and make sure the tabs click into place.
- To change the carbon filter from your machine, remove the filter from the base of your machine and insert the replacement filter.
- Put the outer covers into position on your machine and push firmly until they both click securely into position.
- Plug in and switch your machine, and reset your filter life.



The air purifier fan with the filter covers open showing a HEPA

filter located in the filter covers and a carbon filter. Arrows demonstrate that the carbon filter is fitted directly to the base of the machine and the filter covers will need to be assembled onto the base of the machine

Resetting your HEPA and carbon filter life

It's important to reset your filter life after you have replaced your filter.

Resetting your HEPA filter life

Press and hold the Night mode button on your remote control.


The display on your machine will countdown from five, the filter life will be reset and your machine is ready to use.

Resetting your carbon filter life

Press and hold the Oscillation button on your remote control.

The display on your machine will countdown from five, the filter life will be reset and your machine is ready to use.

Pressing the night
mode and sleep timer
button on the bottom
right of the remote
control for 5 seconds.Pressing the Oscillation
button on the bottom
left of the remote control
for 5 seconds.



Changing your HEPA+Carbon filters with a catalytic filter

Before changing your filter, switch off and unplug your Dyson purifying fan.


The remaining filter life is displayed on the screen and will indicate when your non-washable filters need replacing. Press the Information button on your remote.

You'll need to reset the filter life on your machine.

Dyson Purifier Cool Formaldehyde

Your machine comes with a permanent catalytic filter and a HEPA+Carbon filter. You won't need to change your catalytic filter.

- To change your HEPA+Carbon filter, push down on the buttons either side of your machine to release the outer cover. Push down on the tabs to remove the filter.
- Push the replacement filter into the outer cover and make sure the tabs click into place.
- Put the outer covers into position on your machine and push firmly until they both click securely into position.
- Plug in and switch your machine, and reset your filter life.



The air purifier fan with the filter covers open showing a HEPA filter located in the filter covers and a car-bon filter. Arrows demonstrate that the carbon filter is fitted directly to the base of the machine and the filter covers will need to be assembled onto the base of the machine.


Resetting your HEPA+Carbon filter life

It's important to reset your filter life after you have replaced your filter.

Resetting your HEPA+Carbon filter life

Press and hold the Night mode button on your remote control.

The display on your machine will countdown from five, the filter life will be reset and your machine is ready to use.



Pressing the night mode and sleep timer button on the bottom right of the remote

control for 5 seconds.

Looking after your machine

To always get the best performance from your Dyson purifying fan, it's important to regularly clean it and check for blockages.

Cleaning your machine

- If your machine is dusty, wipe with a damp lint-free cloth.
- Look for blockages in the air inlet holes on the filter and the small aperture inside the loop amplifier.
- Use a soft brush to remove dust and debris.
- Don't use detergents or polishes to clean your machine.

Error codes

If your machine shows an error code, try turning it off and then on again. If this doesn't clear the error code contact Dyson Customer Care.

For more information and support for your machine go online: www.dyson.com/support

www.uyson.com/support

Documents / Resources



Related Manuals / Resources









Manuals+,

- home
- privacy

Dyson Purifier Cool User Manual

Dyson Purifier Cool Front view of the Dyson Pure Cool air purifier fan, showing the amplifier loop and...

dyson 379629-01 Purifier Hot+Cool Formaldehyde Purifying Fan Heater User Guide

Purifies Cools you Designed for business hepo cool formaldehyde Reengineered to deliver cleaner air.1 Fully sealed filtration and...

dyson Purifier Cool User Manual

dyson Purifier Cool User Manual Assembling your machine Use both hands to lift your machine out of the...

dyson HP07 Purifier Hot+Cool User Manual

dyson HP07 Purifier Hot+Cool User Manual Assembling your machine Use both hands to lift your machine out of...