



# MAG Series LCD Monitor

MAG 274QRF-QD-E2 (3CC2)

User Guide

# **Contents**

Getting Started	3
Package Contents	3
Installing the Monitor Stand	4
Adjusting the Monitor	5
Monitor Overview	6
Connecting the Monitor to PC	8
OSD Setup	9
Navi Key	9
Hot Key	9
OSD Menus	10
Gaming	11
Professional	13
lmage	14
Input Source	14
PIP/PBP	15
Navi Key	16
Settings	16
Specifications	18
Preset Display Modes	20
Troubleshooting	21
Safety Instructions	22
TÜV Rheinland Certification	24
Regulatory Notices	25
J , , , , , , , , , , , , , , , , , , ,	

#### Revision

V1.0, 2023/09

# **Getting Started**

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

### **Package Contents**

Monitor	MAG 274QRF-QD-E2	
Documentation	Quick Start Guide	
Accessories	Stand with Screw(s)	
	Stand Base with Screw(s)	
	Screw(s) for Wall Mount Bracket(s)	
	External Power Supply	
	Power Cord	
Cables	USB Upstream Cable (Optional) (for USB Type-B Upstream Port)	
	Premium High Speed HDMI™ Cable (Optional)	
	DisplayPort Cable (Optional)	




# ! Important

- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- Package contents may vary by country.
- The included power cord is exclusively for this monitor and should not be used with other products.

### Installing the Monitor Stand

- 1. Leave the monitor in its protective foam packaging. Align the stand bracket to the monitor groove.
- 2. Tighten the stand bracket with screws.
- 3. Connect the base to the stand and tighten the base screw to secure the base.
- Make sure the stand assembly is properly installed before setting the monitor upright.



# <u>(1)</u>

#### 

- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- The groove for installing the stand bracket can also be used for wall mount. Please contact your dealer for proper wall mount kit.
- This product comes with NO protective film to be removed by the user! Any
  mechanical damages to the product including removal of the polarizing film may
  affect the warranty!




# **Adjusting the Monitor**

This monitor is designed to maximize your viewing comfort with its adjustment capabilities.




# / Important

- Avoid touching the display panel when adjusting the monitor.
- Please slightly tilt the monitor backwards before pivoting it.




#### **Monitor Overview**



1 Power Button & Navi Key **Power LED** Lit in white after the monitor is turned on. If no signal input, the LED will turn into orange. Lit in orange when the monitor is in Stand-by mode. 3 **Cable Routing Hole Kensington Lock** Power Jack Headphone Jack HDMI™ Connector HDMI™ Supports HDMI™ CEC, 2560x1440@144Hz as specified in HDMI™ 2.0b. HDMI™ Connector 8 Supports 2560x1440@144Hz as specified in HDMI™ 2.0b. DisplayPort Supports 2560x1440@180Hz as specified in DisplayPort 1.4a. **USB Type-C Port** 10 **USB Type-C** This port supports DisplayPort Alternate (DP Alt) Power Delivery Mode and up to 20V/3.25A (65W) power delivery. 5V / 3A (15W) 9V / 3A (27W) **Important** 12V / 3A [36W] Your USB Type-C Port signal source and cable 15V / 3A (45W) must support DisplayPort Alternate Mode to 20V / 3.25A (65W) enable video output to the monitor. USB 2.0 Type-B Upstream Port a For USB Upstream Cable. To Monitor Important Check the package for USB Upstream Cable and connect it to the PC and monitor. Once this cable is connected, the USB Type-A Downstream Ports on the monitor will be ready for use. 12 USB 2.0 Type-A Port

### Connecting the Monitor to PC

- 1. Turn off your computer.
- 2. Connect the video cable from the monitor to your computer.
- **3.** Assemble the external power supply & power cord. (Figure A)
- **4.** Connect the external power supply to the monitor power jack. (Figure B)
- **5.** Plug the power cord into the electrical outlet. (Figure C)
- **6.** Turn on the monitor. (Figure D)
- 7. Power on the computer and the monitor will auto detect the signal source.



# **OSD Setup**

This chapter provides you with essential information on OSD Setup.




#### Important

All information is subject to change without prior notice.

#### **Navi Key**

The monitor comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.



#### Up/Down/Left/Right:

- selecting function menus and items
- adjusting function values
- entering into/exiting from function menus


#### Press (OK):

- launching the On-Screen Display (OSD)
- entering submenus
- · confirming a selection or setting

### **Hot Key**

- Users may enter into preset function menus by moving the Navi Key up, down, left or right when the OSD menu is inactive.
- Users may customize their own Hot Keys to enter into different function menus.

# **OSD Menus**





The following settings will be grayed out when HDR signals are received:

- Night Vision
- MPRT
- Low Blue Light
- HDCR

- Brightness
- Contrast
- Color Temperature
- PIP/PBP

# Gaming

1st Level Menu	2nd/3rd Lev	rel Menu	Description	
Game Mode	Premium Co	olor		ton to select and preview
	User		mode effects.	to confirm and apply your
	FPS		mode type.	to commin and apply your
	Racing			
	RTS			
	RPG			
Night Vision	0FF			zes background brightness
	Normal		and is recommended	d for FPS games.
	Strong			
	Strongest			
	A.I.			
Response Time	Normal		Setting to Fastest will reach the shortest	
	Fast		response time and h when playing very fa	elp improve blurred images st games.
	Fastest			
MPRT	OFF		MPRT is available when the refresh rate is over	
	ON		<ul><li>85Hz.</li><li>Activating MPRT will</li></ul>	offoot.
			Affected Function	Function Status
			» Response Time	FullCiloli Status
			» Brightness	Unable to select
			» Adaptive-Sync	
			» HDCR	Set to OFF
			» PIP/PBP » Screen Size 1:1	Set to Auto
		1		
Refresh Rate	Location	Left Top		le in OSD Menu. Press the n and apply your Refresh
		Right Top	Rate Location.	
		Left Bottom	This monitor follows and works at the Opera System's preset Screen Refresh Rate.	
		Right Bottom	System s preset scr	een Nedesti Nate.
		Customize		
	OFF			
	ON			

1st Level Menu	2nd/3rd Lev	el Menu	Description	
Alarm Clock		Left Top		e, press the OK Button to
		Right Top	activate the timer.	ally restore their preset
		Left Bottom	Alarm Clock after an	
		Right Bottom	reconnection.	
		Customize		
	OFF		]	
	15:00	00:01 ~ 99:59		
	30:00			
	45:00			
	60:00			
KVM	Auto			itor to automatically switch
	Upstream		between USB input sources, such as keyboards, mice or other USB devices.	
	Type C		Users can also desig Type-C as the only U	nate Upstream port or USB SB signal source.
Screen Assistance	None		Users can adjust Screen Assistance in any	
	Position Recet		mode.	
Adamting C	Reset		Adaptin S	
Adaptive-Sync	OFF		Adaptive-Sync prever     Activating Adaptive-S	The state of the s
	ON		Affected Function	Function Status
			» MPRT	
			» PIP/PBP	Set to OFF
			» Screen Size 1:1	Set to Auto

### **Professional**

1st Level Menu	2nd Level Menu	Description		
Pro Mode  Low Blue Light	Eco User Anti-Blue Movie Office sRGB Adobe RGB Display P3 OFF ON	Use Up or Down Button to select and preview mode effects.  Press the OK Button to confirm and apply your mode type.  Low Blue Light protects your eyes against blue light. When enabled, Low Blue Light adjusts the screen color temperature to a more yellow glow.		
		When Pro Mode is set to Anti-Blue, it is mandatory to enable Low Blue Light.		
HDCR	OFF	HDCR enhances image quality by increasing the contrast of images.      Activating HDCR will affect:      Affected Function Function Status     Brightness Unable to select     WPRT Set to OFF		
MPRT	OFF	MPRT is available when the refresh rate is over 85Hz.		
	ON	Activating MPRT will affect:		
		Affected Function Function Status		
		» Response Time  » Brightness  » Adaptive-Sync		
		» HDCR Set to 0FF » PIP/PBP » Screen Size 1:1 Set to Auto		
		55.55.55.67.65		
		Image Enhancement enhances image edges to improve their acutance.		
	Weak	then acutance.		
	Medium			
	Strong			
	Strongest			

# **Image**

1st Level Menu	2nd/3rd Level Menu		Description	
Brightness	0-100		Properly adjust Brigh surrounding lighting.	
Contrast	0-100		Properly adjust Contr	ast to relax your eyes.
Sharpness	0-5		Sharpness improves images.	clarity and details of
Color Temperature	Cool Normal Warm			on to select and preview
			mode effects.  • Press the OK Button to confirm and apply your mode type.	
	Customization	R (0-100)		
		G (0-100)		
		B (0-100)		
Screen Size	Auto			een Size in any mode, any
	4:3		resolution and any sc  • Activating Screen Size	
	16:9		Affected Function	Function Status
			» MPRT	FullCtion Status
			» Adaptive-Sync » PIP/PBP	Set to OFF

# **Input Source**

1st Level Menu	2nd Level Menu	Description
HDMI™ 1		Users can adjust Input Source in any mode.
HDMI™ 2		
DP		
Type C		
Auto Scan	OFF	Users can use the Navi Key to select Input Source at
	ON	below status:     While "Auto Scan" is set to "OFF" with the monitor at power saving mode;     While "No Signal" message box is shown on the monitor.

# PIP/PBP

1st Level Menu	2nd/3rd Level Menu		Description	
OFF			PIP (Picture in Picture) allows users to	
PIP	Source	ource HDMI™ 1 simultaneously display multiple vi		
		HDMI™ 2	displayed on the full s	creen at the same
		DP	time as one or more of displayed in inset win	
		Type C	PBP (Picture by Pictu	
	PIP Size	Small	feature that displays t side-by-side on the so	
		Medium	Display Switch allows	
		Large	between primary and	secondary input
	Location	Left Top	If there is only one significant.	
	Right Top Switch and Audio Switch will be	3 ,		
		Left Bottom	Activating PIP/PBP with Affected Function	Function Status
		Right Bottom	» Response Time	Unable to select
	Display Swi	tch	» MPRT	
	Audio Switch		» Adaptive-Sync	Set to OFF
PBP	Source 1	HDMI™ 1	» HDMI™ CEC	Set to OFF & unable to select
		HDMI™ 2	» PIP: Screen Size 1:1	Set to Auto &
		DP	» PBP: Screen Size	unable to select
		Туре С		
	Source 2	HDMI™ 1		
		HDMI™ 2		
		DP		
		Туре С		
	Display Swi	tch		
	Audio Switc	h		

# Navi Key

1st Level Menu	2nd Level Menu	Description
Up	OFF	All Navi Key items can be adjusted via OSD Menus.
Down	Brightness	
Left	Game Mode	
Right	Screen Assistance	
	Alarm Clock	
	Input Source	
	PIP/PBP Mode	
	Refresh Rate	
	Info. On Screen	
	Night Vision	
	KVM	

# Settings

1st Level Menu	2nd Level Menu	Description
Language	繁體中文	Users have to press the OK Button to confirm and
	English	apply the Language setting.  • Language is an independent setting. Users' own
	Français	language setting will override the factory default.
	Deutsch	When users set Reset to Yes, Language will not be changed.
	Italiano	onangea.
	Español	
	한국어	
	日本語	
	Русский	
	Português	
	简体中文	
	Bahasa Indonesia	
	Türkçe	
	(More languages coming soon)	
Transparency	0~5	Users can adjust Transparency in any mode.
OSD Time Out	5~30s	Users can adjust OSD Time Out in any mode.
RGB LED	OFF	Users can adjust RGB LED to ON or OFF.
	ON	

1st Level Menu	2nd Level Menu	Description
Power Button	OFF	When set to OFF, users can press the power button to turn off the monitor.
	Standby	When set to Standby, users can press the power button to turn off the panel and backlight.
Info. On Screen	0FF	The information of the monitor status will be shown
	ON	on the right side of the screen.
HDMI™ CEC	OFF	HDMI™ CEC (Consumer Electronics Control)
	devices that are CEC-capable.  • If HDMI™ CEC is set to ON:	Xbox Series XIS consoles and various audio-visual
		If HDMI™ CEC is set to ON:
		The monitor will automatically power on when the CEC device is turned on.
		<ul> <li>The CEC device will enter power saving mode when the monitor is turned off.</li> </ul>
		<ul> <li>When Sony PlayStation®, Nintendo® Switch™, or Xbox Series X S console is connected, Game Mode and Pro Mode will be automatically set to default modes and can be adjusted to users' preferred modes later.</li> </ul>
Type C PD Charge	0FF	Type-C PD Charge enables users to charge their
	ON	devices through a USB Type-C connector, which can deliver up to 65W (20V/3.25A).
Reset	YES	Users can Reset and restore settings to original
	N0	OSD Default in any mode.

# **Specifications**

Monitor	MAG 274QRF-QD E2		
Size	27 inch		
Curvature	Flat		
Panel Type	Rapid IPS		
Resolution	2560x1440 (WQHD)		
Aspect Ratio	16:9		
Brightness	Typical SDR: 400 nits		
	• Peak HDR: 400 nits		
Contrast Ratio	1000:1		
Refresh Rate	180Hz		
Response Time	• 1ms (MPRT)		
	• 1ms (GTG)		
1/0	• Headphone Jack x 1		
	HDMI™ Connector x 2		
	DisplayPort x 1		
	USB Type-C Port (DP Alt Mode) x 1		
	USB 2.0 Type-B Upstream Port x1		
	USB 2.0 Type-A Port x2		
View Angles	178°(H) , 178°(V)		
DCI-P3*/ sRGB	95%/150%		
Surface Treatment	Anti-glare		
Display Colors	1.07B (8 bits + FRC)		
Monitor Power Options	19V === 6.32A		
External Power Supply	120.08W, 19V		
Power Input	100~240Vac, 50~60Hz		
Power Output	19V === 6.32A		
Adjustment (Height)	0 ~ 130mm		
Adjustment (Tilt)	-5° ~ 20°		
Adjustment (Swivel)	-45° ~ 45°		
Adjustment (Pivot)	-90° ~ 90°		
Kensington Lock	Yes		
VESA Mounting	Plate Type: 75 x 75 mm		
Dimension (W x H x D)	613.5 x 402.1 x 196.5 mm		

Monitor		MAG 274QRF-QD E2	
Weight Net		6.05 kg	
	Gross	13.3 kg	
Environment	• Temperature: 0°C to 40°C		
		• Humidity: 20% to 90%, non-condensing	
		• Altitude: 0 ~ 5000m	
	Storage	• Temperature: -20°C to 60°C	
		• Humidity: 10% to 90%, non-condensing	

<sup>\*</sup> Based on CIE1976 test standards.

# **Preset Display Modes**



All information is subject to change without prior notice.

Chandrad	D latin		MAG 274QRF-QD E2	
Standard	Resolution		HDMI™	DP/ USB-C
VGA	640x480	@60Hz	V	V
		@67Hz	V	V
		@72Hz	V	V
		@75Hz	V	V
Dos-Mode	720x480	@60Hz	V	V
	720x576	@50Hz	V	V
SVGA	800x600	@56Hz	V	V
		@60Hz	V	V
		@72Hz	V	V
		@75Hz	V	V
XGA	1024x768	@60Hz	V	V
		@70Hz	V	V
		@75Hz	V	V
SXGA	1280x1024	@60Hz	V	V
		@75Hz	V	V
WSXGA+	1680x1050	@60Hz	V	V
QHD	2560x1440	@60Hz	V	V
		@120Hz	V	V
		@144Hz	V	V
		@165Hz		V
		@180Hz		V
Video Timing	720P		V	V
Resolution	1080P	@60Hz	V	V
		@120Hz	V	V
	2160P	@30Hz	V	
		@60Hz	V	
PBP Mode	1280x1440 ര	60Hz	V	V

# **Troubleshooting**

#### The power LED is off.

- Press the monitor power button again.
- Check if the monitor power cable is properly connected.

#### No image.

- Check if the computer graphics card is properly installed.
- Check if the computer and monitor are connected to electrical outlets and are turned on.
- Check if the monitor signal cable is properly connected.
- The computer may be in Standby mode. Press any key to activate the monitor.

#### The screen image is not properly sized or centered.

 Refer to Preset Display Modes to set the computer to a setting suitable for the monitor to display.

#### No Plug & Play.

- Check if the monitor power cable is properly connected.
- Check if the monitor signal cable is properly connected.
- Check if the computer and graphics card are Plug & Play compatible.

#### The icons, font or screen are fuzzy, blurry or have color problems.

- · Avoid using any video extension cables.
- Adjust brightness and contrast.
- Adjust RGB color or tune color temperature.
- Check if the monitor signal cable is properly connected.
- Check for bent pins on the signal cable connector.

#### The monitor starts flickering or shows waves.

- Change the refresh rate to match the capabilities of your monitor.
- Update your graphics card drivers.
- Keep the monitor away from electrical devices that may cause electromagnetic interference (EMI).

# **Safety Instructions**

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- Refer servicing to qualified personnel only.

#### Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed mains socket-outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated 120/240V, 20A (maximum).
- Always disconnect the power cord or switch the wall socket off if the device would be left unused for a certain time to achieve zero energy consumption.
- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI provided AC adapter approved for use with this device.

#### **Environment**

- To reduce the possibility of heat-related injuries or of overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazard, keep this device away from humidity and high temperature.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below -20°C, which may damage the device.
- The maximum operating temperature is around 40°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial chemical to clean the device. Never pour any liquid into the opening; that could damage the device or cause electric shock.
- Always keep strong magnetic or electrical objects away from the device.

- If any of the following situations arises, get the device checked by service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated into the device.
  - The device has been exposed to moisture.
  - The device does not work well or you can not get it working according to the User Guide.
  - The device has dropped and damaged.
  - The device has obvious sign of breakage.

# **TÜV Rheinland Certification**

## TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.



- Place the screen 20 28 inches (50 70 cm) away from your eyes and a little below eye level.
- Consciously blinking the eyes every now and then will help to reduce eye strain after extended screen time.
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.
- Make stretches to relieve body fatigue or pain during breaks.
- Turn on the optional Low Blue Light function.

#### TÜV Rheinland Flicker Free Certification

 TÜV Rheinland has tested this product to ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eyes of users.



- TÜV Rheinland has defined a catalogue of tests, which sets out minimum standards at various frequency ranges. The test catalogue is based on internationally applicable standards or standards common within the industry and exceeds these requirements.
- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 3000 Hz under various brightness settings.
- The display will not support Flicker Free when Anti Motion Blur/MPRT is enabled. (The availability of Anti Motion Blur/MPRT varies by products.)

# Regulatory Notices

### **CE Conformity**

This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility [2014/30/EU], Low-voltage Directive [2014/35/EU], ErP Directive [2009/125/EC] and RoHS directive [2011/65/EU]. This product has been tested and found to comply with the harmonized standards for Information Technology Equipment published under Directives of Official Journal of the European Union.

#### FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/television technician for help.

#### Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### Notice 2

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

#### MSI Computer Corp.

901 Canada Court, City of Industry, CA 91748, USA (626) 913-0828

www.msi.com

#### **WEEE Statement**

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



#### **Chemical Substances Information**

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at: https://csr.msi.com/global/index

#### RoHS Statement

#### Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006.

https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations

#### India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

#### **Turkey EEE Regulation**

Conforms to the EEE Regulations of the Republic Of Turkey

#### Ukraine Restriction of Hazardous Substances

The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of 10 March 2017,  $\mathbb{N}^2$  139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

#### Vietnam RoHS

As from December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for a number of hazardous substances in electronic and electric products.

#### **Green Product Features**

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- · Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- · Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

### **Environmental Policy**

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.



- Visit the MSI website and locate a nearby distributor for further recycling information.
- Users may also reach us at gpcontdev@msi.com for information regarding proper disposal, take-back, recycling, and disassembly of MSI products.

#### Warning!

Overuse of screens is likely to affect eyesight.

#### Recommendations:

- 1. Take a 10-minute break for every 30 minutes of screen time.
- 2. Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

### **Copyright and Trademarks Notice**

Copyright © Micro-Star Int'l Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int'l Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.



The terms HDMI™, HDMI™ High-Definition Multimedia Interface, HDMI™ Trade dress and the HDMI™ Logos are trademarks or registered trademarks of HDMI™ Licensing Administrator. Inc.

#### **Technical Support**

If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit https://www.msi.com/support/ for further guidance.