



# OnePlus 11 5G\_User

## Manual

Due to software updates, your experience of the software interface (including but not limited to software features, user interfaces, and interaction experiences) may differ from the interface presented in this manual. The software interface is subject to change.



.....	1
<b>GETTING STARTED.....</b>	<b>4</b>
SETTING UP YOUR DEVICE .....	4
BATTERY AND CHARGING.....	4
PHYSICAL BUTTONS .....	5
TRANSFER DATA TO ONEPLUS DEVICE.....	6
<b>THE BASICS .....</b>	<b>7</b>
BASIC GESTURES.....	7
INSTALL AND UNINSTALL APPS.....	8
USE APPS.....	8
HOME SCREEN .....	9
NOTIFICATION .....	10
GOOGLE ASSISTANT .....	11
<b>SETTINGS .....</b>	<b>12</b>
Wi-Fi.....	12
MOBILE NETWORK .....	13
BLUETOOTH .....	13
CONNECTION & SHARING .....	14
HOME SCREEN & LOCK SCREEN .....	17
DISPLAY & BRIGHTNESS .....	18
SOUND & VIBRATION.....	19
NOTIFICATIONS & STATUS BAR.....	21
APPS .....	22
PASSWORD & SECURITY.....	23
PRIVACY .....	25
LOCATION .....	26

SAFETY & EMERGENCY .....	27
BATTERY .....	27
SPECIAL FEATURES.....	28
DIGITAL WELLBEING & PARENTAL CONTROLS .....	30
ADDITIONAL SETTINGS .....	30
ABOUT DEVICE .....	35
USERS & ACCOUNTS .....	35
GOOGLE .....	36
HELP & FEEDBACK.....	36
<b>APPS.....</b>	<b>36</b>
PHONE.....	36
CONTACTS.....	37
MY FILES.....	38
MESSAGES.....	38
WEATHER.....	39
CALCULATOR .....	39
RECORDER .....	40
NOTES .....	40
PHOTOS.....	41
CLOCK.....	41
ZEN MODE .....	42
CLONE PHONE.....	42
GOOGLE APPS .....	42
PLAY STORE .....	43
<b>ADVANCED .....</b>	<b>44</b>
GAMES .....	44
APP CLONER.....	46
<b>REBOOT, UPDATE, BACKUP, RECOVERY .....</b>	<b>46</b>
REBOOT OR FORCE REBOOT.....	46
SYSTEM UPDATES .....	46
BACKUP AND RESTORE .....	46
FACTORY RESET .....	47
<b>ACCESSIBILITY .....</b>	<b>47</b>
PRESS POWER BUTTON TO END CALLS .....	47
MAGNIFICATION .....	47
COLOR CORRECTION .....	48
COLOR VISION ENHANCEMENT .....	48
COLOR INVERSION.....	48
HIGH CONTRAST TEXT .....	49
<b>LEGAL NOTICE .....</b>	<b>49</b>

DECLARATION .....	49
TRADEMARKS AND PERMISSIONS .....	49
PRIVACY POLICY .....	50
PRECAUTIONS FOR USING THE DEVICE.....	50
GENERAL SAFETY INFORMATION .....	50
BATTERY SAFETY .....	51
CHARGING SAFETY .....	52
DRIVING SAFETY .....	52
HEALTH INFORMATION .....	53
LASER SAFETY STATEMENT.....	53
EU/UK REGULATORY CONFORMANCE .....	53
ISED REGULATORY CONFORMANCE.....	58
INDIA REGULATORY CONFORMANCE .....	59
HOW TO SWITCH SYSTEM LANGUAGES .....	60

# Getting started

Learn more about your device and start using it.

## Setting up your device

### Insert SIM card

1. Insert the SIM Tray Ejector into the small hole on the SIM card holder. Press the ejector firmly into the hole to push the SIM card tray out.
2. Slowly pull the SIM card tray out of the tray slot.
3. Place the SIM card into the SIM card tray.
4. Plug the SIM card tray back into your device.

\* Use the original Nano-SIM card. Non-original cards may cause damage.

### Booting up your OnePlus device

Press and hold the **power button** for a few seconds to boot up the phone. If your phone does not power on, you may need to charge it.

### Setup Wizard

When you first boot up the phone (or after a factory reset), the **Setup Wizard** lets you customize all features, including language, software buttons, gestures, fingerprint unlock, and other features. If you want to change these later, you can do so after setting up the phone in the Settings app.

### Battery and charging

**You will need to charge the phone when you first get it or if you have not used it for a long time.**

### Safety Information

1. To ensure your safety and avoid damaging the device, only use the official charger and USB cable.
2. OnePlus device supports the USB Type-C cable.
3. Unplug the charger after you finish charging to avoid wasting electricity.
4. Do not place anything on your phone while it is charging.

## Charge the battery

1. Connect the USB cable to the adapter;
2. Plug the USB cable into the phone's USB port.
3. Plug the adapter into a power socket.
4. After charging, unplug the USB cable from the phone and unplug the adapter from the socket.

## Save power and extend battery life

Reduce power consumption by doing the following:

1. Turn off the screen when the device is not in use.
2. Turn on **Battery Saver** mode when the battery is low.
3. Disable Bluetooth and Wi-Fi when you are not using them.
4. Dim screen brightness and shorten sleep time in Settings.
5. Delete apps that you do not use.

## Charging

When you use the OnePlus charger and USB cable for charging, you can charge your phone safely (10V/6.5A) and quickly.

It is recommended to use between 15°C and 35°C degrees.

## Physical buttons

### Power button

The power button is located on the right side of the phone.

- Press and hold the power button to turn on the device when the device is off.
- Press and hold the power button for Voice Assistant.
- Press the power button and volume up button simultaneously for Emergency/Power off/Restart when the device is on.
- Click the power button to turn on/off the screen.

### Volume button

The volume button is located on the left side of the phone.

- When playing music or video, press the volume button to adjust the media volume.

- Press the volume button during a call to adjust the call volume.
- Press the volume button to silence the ringtone when you get an incoming call.

## Alert Slider

Alert Slider is on the right side of the phone.

\*It is available on some models.

You can adjust the system ringtone status (**silent, vibrate, ring**) by toggling the alert slider.

- **Silent:** Calls and notifications will be silenced with no vibration, except for alarms.
- **Vibrate:** Calls and notifications will be silenced, except for alarms.
- **Ring:** Calls, alarms and notifications will function normally.

NOTE: If the phone is in **Do Not Disturb** mode, the ringtone and vibration will be turned off.

## Shortcut keys

You can perform quick actions using the shortcut keys.

- Press and hold the power button and volume up button simultaneously to turn off the device.
- Press and hold the power button and volume down button simultaneously to take a screenshot.
- Press and hold the power button and volume down button simultaneously to access recovery mode when the device is powered off.
- Long press the power button and volume up for 10 seconds to force a power off.

## Transfer data to OnePlus device

**Clone Phone** can quickly transfer all your data, including contacts, messages and photos, from your old device to your new OnePlus device.

If only OnePlus Switch is installed on your old phone, you will need to scan the new QR code to download the Clone Phone.

- **If the old device is OnePlus or other Android device:**
  1. Open the Clone Phone. Select **This is the new phone**, then select your old phone's type. Follow the prompts on the new phone screen. Download and install Clone Phone on your old phone.
  2. Tap Continue on your new phone.
  3. Open the Clone Phone in your old phone, select **This is the old phone**, and scan the QR code on your new phone to connect the two phones.
  4. After connecting the two phones, select the data you want to migrate from your old phone. Tap to start. Then wait until the transfer is completed.
- **If the old device is iPhone:**
  1. Sync the data of your iOS device to iCloud and download Clone Phone app on your old

phone.

2. Open Clone phone app on new device and choose **This is the new phone** and then tap on **iPhone**.
3. Sign in to your iCloud account and connect two phones on Clone Phone.
4. Start importing data.
5. It's recommended to complete the whole data transfer process while connected to a Wi-Fi network, and Clone phone should always stay on the screen. If you ever get disconnected from the iCloud server, please try logging into iCloud again and pick up with the data transmission. Please note that only certain formats of data can be transferred due to compatibility issues.


## The Basics

**Learn to use your OnePlus device.**


### Basic gestures

Learn to use basic gestures, such as tap, drag, swipe, and zoom, to control your phone and apps.

1. Tap to enter the app or select it.




2. When viewing a webpage or list, swipe up or down to scroll.



3. Swipe left or right with your finger to switch tabs, change pages or slide content in the weather / calendar / photos / app list.




4. Two-finger zoom for images and web pages.



5. Press and hold the screen to open the pop-up window for advanced settings or enter edit

status.



## Install and uninstall apps

### Install apps from Play Store

It is advisable to download and install apps from Play Store available on your device. Open Play Store to search for apps using keywords or on screen.

- Tap the app icon to view application details.
- Tap **Install** to download and install apps.
- \* It is advisable to download apps on a Wi-Fi network.
- \* New upgradation of apps that you download would be reminded. (Choose yes/no)

### Uninstall apps

Uninstall apps as follows:

- On the home screen, press and hold the app icon, and go to **App info > Uninstall**.
- On the app drawer, press and hold the app icon and select **Uninstall**.
- Go to **Settings > Apps > App management > App list** and select the app. Then go to App info and select uninstall.
- \* Some pre-installed apps cannot be uninstalled.

## Use Apps

Learn how to open apps, switch between apps, close apps and view app information.

### App drawer

Swipe up on the home screen to view all your apps in the app drawer

### Open apps

Open the app by the app icon on the desktop or in the app drawer.

### View app info

Long press an app's icon and select **App info** in the pop-up box to view app info and setting options.



## Switch apps

- In **Navigation gestures**, swipe left or right along the bottom bar to switch between apps.
- After you set Navigation buttons **Back**, **Home** and **Recents**, tap **Recents** button in the navigation bar to switch between apps.

## Close apps


- In **Navigation gestures**, swipe up from the bottom edge of the screen and hold, then close apps by swiping up on the app card.
- Tap the **Recents** button and close apps by swiping up on the app card.

## Clear background tasks

- In **Navigation gestures**, swipe up from the bottom edge of the screen and hold, then tap “Clear All” to clear background tasks.
- Tap **Recents** button to enter the recent apps list, then tap “Clear All” to clear background tasks.

\* Pinned apps will not be closed.

## Lock background apps

In the recent apps list, click  in the top right corner of the app card to access menu options. Select **Lock** to stop the app from being closed or cleared.

## Home screen

Learn to set **wallpapers**, **icons**, **widgets**, **layout**, **transitions** and **home settings** to personalize your phone.

## App icons and folders

- Open the app drawer by swiping up from the home screen.
- In the drawer, press and drag an app icon to add it to the home screen.
- Drag an app icon onto another app on the home screen to create a folder.

## Wallpapers

Long press a blank space on the home screen and select **Wallpapers** to set your home screen wallpaper and lock screen wallpaper.

## Icons

Long press a blank space on the home screen and select **Icons** to set icons on the home screen.

## Widgets

Long press on a blank space from the home screen and select **Widgets**, then press a widget and drag it to the home screen.

## Layout

Long press on a blank space from the home screen and select **Layout**. Adjust the number of desktop grids.

## Transitions

Long press on a blank space from the home screen and select **Transitions**. Choose the style of page transition in the Home screen.

## More

More specific home settings can be set in **Settings > Home screen & Lock screen**.

## Notification

When a new system notification or app notification is received, the status bar will display the corresponding icon. Pull down the notification panel by swiping down from the top of the application page or anywhere on the home screen.























- You can clear notifications by swiping it right (Some notifications need to be cleared by closing the related app).
- **Long press** a notification to enter the notification settings for that app.
- There are three choices: Turn off notification / set as silent / more settings.

## Quick Settings

- Tap the quick settings icon to turn on/off specific functions quickly.
- Press and hold an icon in the quick settings menu to open the corresponding settings interface.
- Swipe down again to view more buttons.

## Status icons

Status icons are displayed on the status bar at the top of the screen. The icons listed in the table below are the most common ones.

	Signal strength		Location service enabled
	Wi-Fi		Alarm enabled
	No SIM card		Silent mode enabled
	Roaming		Vibration mode enabled
	Connected to GPRS network		Airplane mode enabled
	Connected to UMTS network		Normal charging
	Connected to HSDPA network		Battery capacity
	Connected to HSPA+ network		NFC enabled
	Connected to LTE network		Gaming mode enabled
	Connected to 5G network		Do not disturb mode enabled
	Bluetooth enabled		Wi-Fi hotspot enabled

## Google Assistant

\* When using Google Assistant for the first time, follow the prompts to log in to your Google account.

You can quickly access Google Assistant, by either pressing and holding down your home button, swiping up from the corner of the phone screen (if you have enabled “**Navigation gestures**”), or by press the power button, or by simply saying, "Hey Google."

With Google Assistant, you can:

- Make quick phone calls on the go (e.g., "Call Mom")

- Send text messages (e.g., "Text Sara I am running late")
- Set reminders (e.g., "Remind me to buy a birthday gift for John")
- Take a selfie (e.g., "Take a selfie")
- Set calendar events (e.g., "Set a calendar event for dinner with Charlie tomorrow from 7-9")
- Play music (e.g., "Play jazz music on YouTube")
- Navigate to places (e.g., "Give me Home directions ")
- Weather information (e.g., "Do I need an umbrella today?")

## Settings

**Configure your phone's network and account or set up your phone**

### Wi-Fi

Connect to the internet through Wi-Fi.

#### Connect to Wi-Fi

1. Enter Settings > Wi-Fi, tap Wi-Fi.
2. Select a Wi-Fi network from the list.
3. You will automatically connect to an unencrypted Wi-Fi network that you have selected. To connect to an encrypted network, enter the password and tap the tick.

\* You can also manually add a Wi-Fi network by selecting Add network.

- **Wi-Fi Assistant:**
  - **Auto-connect to the best Wi-Fi:** When the option is turned on, the system will auto-connect to the best Wi-Fi.
  - **Auto-switch to mobile network:** Automatically switch to a mobile network when Wi-Fi networks are slow.
  - **Dual channel acceleration:** When the option is turned on, you can use Wi-Fi and mobile data at the same time for a faster internet experience.
  - **Dual Wi-Fi acceleration:** Connect two Wi-Fi networks at the same time for a faster Internet connection.

### Advanced settings

Go to **Settings > Wi-Fi** > click **:** > click **Advanced settings**

- **Saved networks:** Networks that have been successfully linked.
- **Install certificates:** Browse files in other apps (recent files).
- **Wi-Fi status display:** Turn on or off the Bandwidth label, and the Wi-Fi status number

will be presented.

\*Adjusting the Wi-Fi status display will not affect Wi-Fi functionality.

- **Wi-Fi data usage:** You can view your Wi-Fi data usage here, including the total data usage and the data usage of different apps.
- **Passpoint:** Allow your device to discover and connect to Passpoint networks.
- Wi-Fi Direct

## Mobile network

Enable or disable mobile data

Go to **Settings > Mobile network**, enable/disable **Mobile data**.

## General settings

When you insert the second SIM card, you can still use the internet when making calls.

## Data usage

You can check statistics on mobile data and Wi-Fi traffic usage.

## Network settings

Go to **Settings > Mobile network > Mobile data**, and turn on or off the network.

- **Data saving:** When turned on, apps running in the background will not be able to receive new messages over your mobile network unless they are specifically unrestricted.
- **Network access:** When you use different apps, you can set up different ways of using the network, including Wi-Fi & mobile data, Only Wi-Fi, Only Mobile Data and Disable network access, when you use different apps.

## Bluetooth

Bluetooth lets you connect to Bluetooth-enabled devices such as headsets and keyboards.

- Go to **Settings > Bluetooth**, select the device you want to connect from the list of available devices, and enter the pairing code to complete pairing.

\* When your Bluetooth device is turned on but cannot be found, check the device's manual and follow the instructions to switch the device to pairing mode to connect.

## Advanced settings

- **Device volume sync:** Sync your Bluetooth device's volume with this device.
- **Display codec standard:** Display the current codec standards for paired devices.

## Connection & sharing

Go to **Settings > Connection & sharing** to share personal hotspot and screencasts.

### Airplane mode

After switching your device to airplane mode, you will not be able to dial, but you can read, play games, watch videos, or use other applications that don't require network or phone connections.

### Personal hotspot

Share your mobile data or Wi-Fi connection with other devices. This may consume more mobile data and battery power.

\* Two ways of linking personal hotspots will be provided:

1. QR code: Scan the QR code and connect to this Wi-Fi network.
2. Personal hotspot password: Go to **Personal hotspot > Hotspot settings** > change the Name and Password.

● **Hotspot settings:** Set personal hotspot name and password.

\* **Hide hotspot:** You can hide this hotspot so it can only be connected to manually.

\* **Use Wi-Fi 6:** The Wi-Fi 6 protocol provides a faster connection. Hotspot using Wi-Fi 6 may not be found in some old device models.

● **Connection management:** Blocklist, device connection limit and data usage limit can be set.

● **Automatically turn off personal hotspot:** Automatically turn off this hotspot when no devices are connected for 10 minutes.

● **Bluetooth tethering:** You can share your device's mobile data or Wi-Fi network with other devices by Bluetooth tethering.

● **USB tethering:** Connect to a device using a USB cable to share your phone's network connection.

● **Ethernet tethering:** Connect to an Ethernet cable to share your phone's network connection. To share your device's mobile data or Wi-Fi network with other devices by Bluetooth tethering, follow the steps below.

### VPN

Go to **Settings > Connection & sharing > VPN**. Then, click "+", adding VPN after completing the VPN name, type, server address and other information.

### NFC

When NFC is enabled, you can exchange data with another device when the two devices are touching.

- **Tap & pay:** After the default payment app is set, you can make payment by tapping the back of your phone on a device with a payment logo, for example, a POS machine, subway gate or transportation payment terminal.

\*Before using the Tap and pay, you need to set up the default payment app, open the payment service in the app, and set the tap and pay feature with the following settings options:

- **Default Payment App:** Choose an app, such as Google pay, to use when making a payment by tapping the payment terminal.

## Private DNS

Private DNS is a mechanism used for encrypted transfer. Once connected, it helps to enhance network security, but it may also lead to network latency and connection failure. If you select **Specified Private DNS**, please pay attention to your device's network status.

## Android Auto

Use apps on your car display.

## Screencast

Make sure your phone and the display device are connected to the same network or that the display device has the wireless display function turned on. Pair your phone with the display device to stream your phone screen to it.

Before using the Miracast function, ensure that your TV, projector, screen and other display devices are compatible with the Miracast function and the function of the device is turned on.

- **Instructions:**
  1. Go to Settings > Connection & sharing > Screencast.
  2. Tap **Search for display devices**.
  3. Select the display device that needs to be projected and wait for the phone screen to be projected onto the display device.

## Print

The Print service lets you print documents, images, emails, and web pages. An option for the Print service appears when you choose to share a file.

When you set **Default Print service** and Quick device connect, the device will search for nearby printers quickly, and you can choose and connect to the printer for print services.

\***Add print service:** Add a new print service for printing works.

## Wallpaper & style

Go to **Settings > Wallpaper & style** to customize the wallpaper and style.

You can change the Wallpapers, Always-On Display, Font, Icons and other user interface here.

### Wallpapers

Go to Settings > Wallpapers & style > Wallpapers. Wallpapers provides a wide range of beautifully designed static and live wallpapers, including interactive live wallpapers. You can also use your photos as wallpapers.

- **Album:** Choose a photo from Album, and zoom in or move the photo to adjust it. Set the photo as your home screen wallpaper, lock screen wallpaper, or both.
- **Incentive wallpapers:** Take or select a photo. The system will then extract the main colors of the image and use algorithms to generate creative wallpapers in a variety of styles such as simple, abstract, complex, and Chinese style.
- **Live wallpapers:** Choose a desired live wallpaper and zoom in or move the wallpaper to adjust it. You can use it as your home screen wallpaper or home screen and lock screen wallpaper.
- **Static wallpapers:** Choose a desired static wallpaper and zoom in or move the wallpaper to adjust it. You can use it as your home screen wallpaper, lock screen wallpaper, or both.

### Always-On Display

OxygenOS offers a wide range of Always-On Display styles for customizing the phone.

- **More Display settings**
  - Display option: Power saving/ Scheduled/ All day.
  - Info: Show information on the Always-On Display.
  - New notifications: Show new notifications on the Always-On Display.
- **Personalized:** You can choose from a wide range of personalized Always-On Display styles, including Bitmoji, Canvas, custom patterns, text, text and image and Omoji.
- **System-provided:** Homeland, Insight, digital clock, analog clock and text clock.

### Font

There are several kinds of fonts available.

\* After the Adaptive font weight is used, the system automatically provides the best font display effects based on the scenario. Also, Font size and weight could be adjusted.



## Icons

Customize the status icon shape. There are several shapes available: Default, Material Style, Pebble, etc.

## Colors

You can choose your desired theme color from several different styles to make the UI more in tune with your personality and preferences. You can also pick the colors you like from the wallpaper and custom the system color directly.

## Quick settings

Customize the status notification shape. There are several shapes available: Square, Squirele and Rhombus, etc.

## Fingerprint animation

There are several different fingerprint animation effects that you can select.

## Edge light

There are several kinds of colors available, including Blue, Red, Gold, etc.

## Home screen & Lock screen

Go to **Settings > Home screen & Lock screen** to customize your home and lock screen.

### Home screen

- **Home screen mode:** Standard mode and Drawer mode.
  - Add apps to Home screen: Newly download apps will be added to the Home screen.
  - Show app suggestions
- **Home screen layout:** You can choose different layouts as you like.
- **Icon pull-down gesture:** Open apps on the Home screen with one hand.
- **Smart search in app drawer:** Find apps on your device, or search for and install new apps. You can see what you can do with Global Search in User guide.
- **Lock Home screen layout:** Lock the Home screen layout to prevent it from being changed.
- **Icon autofill**

- **Double-tap to lock:** Double-tap a blank area on the Home screen to lock the screen.
- **Swipe down on Home screen:** Notification drawer or Shelf.

## Lock screen

- **Raise to wake**
- **Double-tap to wake or turn off screen**
- **Lock screen shortcuts:** Swipe on the shortcuts at the bottom of the Lock screen to open an app or feature.

## Recent tasks

- **Recent tasks manager:** Display RAM/memory information for recent tasks. List locked and unlocked applications.

## Display & brightness

There are two modes here, including **Light mode** and **Dark mode**.

### Dark mode

- **Scheduled:** Set the time of dark mode switching
- **Dark mode settings:**  
Go to **Settings > Display & brightness > Dark mode > Dark mode settings**.  
There are three different styles, including Enhanced, Medium, and Gentle.  
You can make custom adjustments here, for example, adjusting wallpapers or icons to Dark mode or not.

### Brightness

- **Auto Brightness:** When enabled, the phone will optimize the screen brightness setting according to ambient light conditions.  
You can also manually adjust the slider bar to set your preferences.

### Screen color mode

- **Screen color mode:** There are several different modes here. You can choose the mode according to your preference and adjust the screen color temperature in the mode.
  1. **Vivid mode:** A vibrant color display.
  2. **Natural mode:** Softer colors. Supports color management.

### 3. Pro mode

- a. Cinematic: Use Display P3 mode for more faithful color reproduction.
- b. Brilliant: Use the Enhanced color display.

**\*Screen color temperature:** Adjust the screen color temperature when Eye comfort is on.

- **Eye Comfort:** Eye comfort reduces blue light from the screen and alleviates eye strain. It is normal for the screen to appear yellowish when eye comfort is on.

**\*Display effects:** Color / Black & white

- **Nature tone display:** Automatically adjust screen color temperature according to ambient lighting.
- **Font & Display size**
  - Font: You can customize the font type, size and weight.
  - Size: Adjusting the display size will change the size of the content on the screen, including icons and texts. The screen layout may also change on some device models.

## Video Enhancement Engine

- **Image sharpener:** Enhance the clarity of low-quality images and videos. This will increase battery usage.
- **Video color enhancer:** SDR-to-HDR technology widens the color gamut for a superb visual experience. This will increase battery usage.
- **Bright HDR video mode:** Increase screen brightness when playing HDR videos. This will consume more power and cause your phone to heat up.
  
- **Auto-rotate:** If enabled, the phone display will automatically rotate as the phone rotates.
- **Auto Screen off:** You can choose the length of time the screen will automatically go off here.
- **Screen resolution:** Auto select/Full HD+/Quad HD+.
- **Screen refresh rate:** Standard 60/High 120 Hz.
- **Full screen for apps:** Front camera display by app / Full screen display by app.

## Sound & vibration

Go to **Settings > Sound & Vibration** to change the sound settings on your device.

### Live Caption

Live caption detects speech on your device and automatically caption generates captions.

## Vibrate

- **Vibrates on ring** (on/off)
- **Vibrate intensity:** Vibrate on ring/ Notification vibration.

## Do Not Disturb

When Do Not Disturb mode is turned on, your phone will not show new or existing notifications or make a sound or vibrate. Note that critical notifications for phone activity and status will still appear. You can allow exceptions below.

- **Schedules:** Set Do not disturb duration or set the time to automatically turn on and off.
- **People:** People in the exceptions list are allowed to interrupt Do Not Disturb. (None/ Favorites/ Contacts)
- **Apps:** Apps in the exceptions list are allowed to interrupt Do Not Disturb.
- **Ring for repeated calls:** A second call from the same number within 3 minutes will not be silenced.
- **Silence media when Do Not Disturb is on.**

## Volume

- **Media:** Adjust the slider to set the volume for playing music, video and more.
- **Ringtone:** Adjust the slider to set the ringtone volume for phone calls and other notifications.
- **Notifications:** Adjust the slider to set the notification volume for phone calls and other media notifications.
- **Alarms:** Adjust the slider to set the ringtone volume for alarms.
- **Media volume muted:** The media volume and device are silenced simultaneously. You may make any adjustments manually.

## Ringtones

Set the ringtone and vibration for incoming phone calls.

- **Ringtone:** Set the ringtone and vibration pattern with the ringtone.
- **Notification sound:** Choose the notification sound from dynamic tones, alert tones or custom tones from the device.

## Dolby Atmos

There are several sound profiles for different environments and scenarios.

- **Environment profile:** Indoor / On-the-go / Commute / Flight.
- **Scenario-specific profile:** Smart / Movie / Gaming / Music

## Haptics and tones (O-HAPTICS)

All-new haptics mimic the feel of real materials and natural interactions for a true-to-life,

immersive experience.

- **System haptics:** get haptic feedback for touches, swipes, and more.
- **Haptic intensity**
- **How touches feel:** Crisp/Gentle
- **Sounds**
  - Dial pad tone
  - Lock screen sound
  - Screenshot sound
  - Deletion sound
  - Fingerprint animation sound
  - Touch sounds

## More settings

- **Volume button function:** When you press the volume adjustment button, the selected option will change accordingly. You can choose **media volume** or **ringtone volume** based on your preference.
- **Default recorder:** Auto select /Add-on.

## Notifications & status bar

Go to **Settings > Notifications & status bar** to set up system notifications and app notifications.

### By Location

You can set up notifications in different locations and choose allowed applications in each location.

- **Lock screen:** You can enable to **Swipe down on Lock screen to view notification drawer**, select **Lock screen notifications** pattern (show app and notification content / Do not show) and set to **Wake screen when a notification is received**.
- **Banner:** Enable to **Simplify banner notifications when using an app in full screen**.
- **App icon badges:** Set up **Badge** showing pattern (Number / Dot / Number or Dot / Do not show)

### Status bar

You can set the notification icons, style of the battery, enable/disable showing Battery percentage, time and manage icons in the status bar.

- **Notification icons:** You can change notifications icons status here, **Show icon**, **Show number**, and **Do not show**.
- **Battery style:** You can change battery style here (Horizontal/ Vertical / Loop / Do not

show)

- **Battery percentage:** Show the battery percentage at the top of the screen.
- **Status bar icons:** Status icons are displayed on the status bar at the top of the screen.

The icons listed in the table below are the most common ones.

- ☐ Real-time network speed
- ☐ Bluetooth
- ☐ HD voice
- ☐ VoWiFi
- ☐ Ring
- ☐ NFC
- ☐ Earphones
- ☐ Alarm
- ☐ Data saving
- ☐ High performance mode
- ☐ Do Not Disturb
- ☐ VPN

## More settings

- **Display data usage in notification drawer**
- **Allow notification snoozing**
- **Reduce notification feedback:** When you use an app in full screen (such as when watching videos or playing games), notification sounds are softer and vibration is less strong.
- **Bubbles**
- **Enhanced notifications:** Get suggested actions, replies, and more.
- **At a Glance**
- **Notification history**

## App notifications

You can turn notifications from receiving apps on or off.

## Apps

Go to **Settings > Apps** to manage your device's apps, change their settings, view app info, set notifications and permissions, and more.

## App management

You can check out the apps already installed on your phone here.

## App Cloner

Some apps can be cloned. The cloned app will appear on the Home screen and can run at the same time as the original app. The list will show you the applications that support App cloner. Tap the application to open App cloner.

## Default apps

Set the default apps for home, browser, phone, SMS, gallery, mail, and more.

## Recover system apps

You can recover system apps you uninstalled before.

## Auto launch

You can continue receiving messages normally by turning on the settings from some apps. Turning off the settings below will save power.

## Special app access

You can set special app access such as modifying system settings, device & app notification, usage access, all files access, Wi-Fi control, Premium SMS access, media management apps and display over other apps.

## Password & security

Go to **Settings > Password & security** to set up fingerprints, faces and passwords for your phone.

## Lock screen Password

Your Lock screen password cannot be retrieved if you forget it and you will no longer be able to unlock your phone or view phone data.

- **Select password type:** You can choose different ways to set your lock screen password, including Numeric (4-digits, 6 digits and 4-16 digits), Pattern and Alphanumeric (4-16 letters and digits).

## Face

You can add/delete face data and set face unlock preferences.

- **Add face data:** Follow the on-screen prompts to add your face data.  
\*It is recommended to enroll the face in a bright environment for a better result.
- **Use Face data for:** Use face unlock to unlock the screen, apps and private safe.

- **Enter Home screen after unlocking:** Enable this to unlock your phone with your face as soon as the screen turns on without swiping first.
- **Brighten screen in dim light:** In the situation where the camera cannot recognize your face, the screen will light up to help the camera recognize you.
- **Require eyes to be open**

## Fingerprint

You can add/delete fingerprints and set fingerprint preferences through fingerprint.

- **Add fingerprint:** Follow the on-screen prompts to add your fingerprint.
  - \*Add your fingerprint again after replacing the protective film.
  - \*Add only one fingerprint information at a time.
  - \*Press firmly on the phone screen to ensure your fingerprint data is fully added.
- **Use fingerprint for:** Use fingerprint unlock to unlock the screen, apps and private safe.
- **Quick launch:** Touch and hold the fingerprint sensor until an icon menu appears, then slide to an icon and release to launch the function or app.
- **Fingerprint animation effect:** Set animation effect. You can select one of the several forms below: (It could be adjusted in Wallpapers & style)
  - ☐ Fizz
  - ☐ Bubble
  - ☐ Stardust
  - ☐ Cosmos
  - ☐ Ripple
  - ☐ Stripe
  - ☐ Fireworks
  - ☐ None

\*In addition to unlocking your phone, you can use your fingerprint to authorize purchases and access apps.

- **Show fingerprint icon:** Quickly find the fingerprint icon when the screen is off.

## Privacy password

The privacy password will be used for verification in App lock, Hide apps and Private safe. It will be saved in a security module and cannot be accessed by the system or apps. You can set **Question** for Privacy password.

## Manage passwords

- **Autofill service:** Google/None



## System security

- **Security status**
  - **Google Play Protect**
  - **Find My Device:** It helps you locate your device remotely and keeps your data safe if the device is lost.
    - Find My Device app: Get it on Google Play.
    - Find My Device web: Open web portal (Web: Visit [android.com/find](https://android.com/find).)
  - **Security update**
  - **Google Play system update**
- **Device security**
  - **Smart Lock:** Keep your phone unlocked while it is on you, at specific places that you trust, or near your connected devices.
  - **Require password to power off:** Set your device to require the Lock screen password whenever you power off your device using the Power button or Google Assistant. This can prevent your device from being powered off by someone else so you can find it remotely if you lose it.
- **App installation**
  - **Installation sources**
- **Other**
  - **Device admin apps**
    - **Find My Device:** Enable to find your device or to lock or erase data from a lost device.
  - **Credential storage:** You can view **Trusted certificates** and **User credentials** and install certificates from storage.
  - **Trusted agents**
  - **Pin apps:** When you pin an app, you will be unable to use other apps or functions, and incoming calls and alarms will be affected. The pinned app can only be controlled using the navigation buttons.
    - To use this function:
      1. Turn on Pin apps.
      2. Open an app you want to pin and enter the recent tasks screen.
      3. Tap Pin in the upper-right corner of the app window.Note: “Pin apps” is unavailable if Navigation gesture is turned on.

## Privacy

### Permission manager

Set app permissions to use microphone, camera, contacts, calendar and others.

### Privacy protection

- **App lock:** Use the privacy password to access locked apps.
- **Hide apps:** Hide an app's Home Screen icon and notifications, and don't show it in recent tasks. You can enter your access code on the dial pad to access hidden apps.
- **Private Safe:** Safely secure your data, including images, videos, audio and documents etc., inside a virtual lockbox. Your protected files are isolated from other apps while remaining personally accessible.
- **System cloner:** Create a separate system for apps and data. You can access your system clone through its own screen lock.

## Privacy dashboard

Show the permissions of Location, Camera, Microphone and others.

## Show password

Enable this to display characters briefly as you type.

## Advanced

- **Android System Intelligence:** Get suggestions based on the people, apps, and content you interact with.
- **Autofill service from Google:** Saved passwords, credit cards and addresses.
- **Google location history:** Saves where you go with your device.
- **Activity controls:** Choose the activities and info you allow Google to save.
- **Ads:** Advertising ID and personalization.
- **Usage & diagnostic:** Share data to help improve Android.
- **Alert me when apps read clipboard: (on/off)** Allowing apps to read your clipboard may cause privacy leaks.
- **App content:** Allow apps to send content to the Android system.

## Location

Enable this to allow apps to use location information.

## Positioning control

- **Wi-Fi and Bluetooth scanning:** Allow apps and services to scan for Wi-Fi or nearby devices at any time. This can be used, for example, to improve location-based features and services.

## Recent location requests

You can see the recent location requests and information on applications here.

## Safety & emergency

### Emergency SOS

- **Power button for quick SOS:** Press the Power button 5 times quickly to enter the emergency call page.  
\* The specific operation varies from region to region. Please refer to the actual experience.
- **Emergency SOS:** Automatically call for help when you enter the emergency call page.
- **Emergency sharing:** You can set Auto send SMS with location to your contacts when you are in an emergency.
- **Emergency contacts:** View and call your emergency contacts on the emergency call page when you are in an emergency.
- **Medical info:** First responders can look at your medical info on the emergency call page during an emergency.

### Google Play services

- **Emergency Location Service:** Help to send device's location to emergency response partners.
- **Wireless Emergency alerts:** Allow alerts including Alerts options and Alert preferences.
- **Emergency alert history:** Previous emergency alert history.

## Battery

Go to **Settings > Battery** to view battery details and set battery preferences.

### Battery usage

View battery usage details since full charge and the list of which processes use the most battery.

- **Optimize battery usage:** Optimize battery life by turning off some apps.

### Power saving mode

Enable this to extend battery life. Battery saver will turn off some device features and restrict apps. You can choose to manually turn it on at a specified battery level or select Turn off when fully charged.

- Automatically turn off Power saving mode when the battery is charged to 90%
- Turn on at specified battery level
- Default optimization
- Super power saving mode

## Optimized night charging

To decelerate battery aging, your device learns your sleep schedule and waits to finish charging past 80% until just before you wake up.

## Reverse wireless charging

- **Reverse wireless charging:** Automatically turns off if your phone does not detect a device to charge within 2 minutes.
- **Disable when battery is low:** You can set a specified battery level.

## Wireless charging settings

- **Quiet charging:** the wireless charger runs at a low power level to minimize noise.

## More settings

- **High performance mode:** The system always operates in a high-performance mode, but it will increase extra power consumption.
- **Optimize battery use:** Automatically optimize apps that are draining battery in the background.
- **Sleep standby optimization:** Your phone consumes less power and reduces notifications when you are asleep.
- **Nearly Charging Stations:** Notify when there is a charging station nearby.
- **App battery management:** You can set power consumption controls and privacy permissions for applications

## Special features

### Split screen

- Display two apps on the screen for easier multitasking. You can swipe up with 3 fingers to enter Split screen. Or you can enter Split screen mode from recent tasks and Smart Sidebar.

### Flexible windows

- For floating windows, you can quickly open windows, open from Smart Sidebar, open with a swipe, resize a window, mini window, quickly hide a window, share files and switch to Split screen

### Quick return

- You can quickly go back to an app by tapping the Quick Return window, expand or collapse multiple tiles, move the tile position, hide the tile temporarily and pin or unpin the tile.

## Quick launch

- Touch and hold the fingerprint sensor until icons appear. Without lifting your finger, slide it to an icon and then release to launch the corresponding function or app.
- Immediately after unlocking the screen using your fingerprint and before icons appear, quickly slide your finger to the area where the target icon usually appears and release to launch the function or apps.

## Smart Sidebar

- Swipe in from the upper part of the screen to bring up Smart Sidebar. From Smart Sidebar, you can open apps in floating windows or Spilt screen, and also get smart recommendations based on your current activity.

## Kid Space

- **Dedicated home screen:** Add child-friendly apps to create a digital space your child will love.
- **Healthy screen time habits:** Set screen time limits for your child to prevent device overuse.
- **Eyesight protection:** Your child will get a message when the ambient light is too dark.

## Simple mode

- Larger text and icons, louder sounds and simple settings for you to use the phone easily.

## Work Life Balance

Strike the balance between your personal and professional life.

You can select location/ Wi-Fi name/timing to confirm the conditions for automatic activation, and customize the relevant applications that you want to receive notification, and add a reminder of "whether to switch to work/life mode" when switching modes.

- **Work mode**
  - **Be focused at work:** Get the information and notifications about work based on the types of applications and your accounts.
  - **Improved your productivity:** Manage work notifications and setup the mode as per work schedule, Wi-Fi, and locations.
- **Life mode**
  - **Be relaxed at home:** Only receive notifications from desired social/entertainment

apps.

- **Enjoy your “me” time:** Make memories and more! You can set up life mode based in your schedules, home Wi-Fi and locations.

## Digital Wellbeing & parental controls

### Your Digital wellbeing tools

**Today:** Show today’s screen wake up times.

**Unlocks:** Show today’s device unlock times.

**Notifications:** Show today’s notifications received times.

### Ways to disconnect:

- **Dashboard:** Manage the dashboard by screen time, Notifications received and Apps times opened. Click the icons on the right of the Apps name to set app timer, once ran out, the app will be paused for the rest of the day, it will pop up a window showing "App paused, your (App name) timer ran out. It'll start again tomorrow." You can click **Settings** on the pop-up window to delete the timer.
- **Bedtime mode:** Use **Bedtime mode** to disconnect from your phone and avoid interruptions while you sleep. When it starts, Grayscale removes the screen’s color, Do Not Disturb will mute sounds so you aren’t woken up by calls or notifications. When it ends, your phone changes back to its usual settings.
- **Focus mode:** Set to pause distracting apps when you need time to focus.

### Reduce interruptions:

- **Manage notifications:** Disable or enable app notifications.
- **Do Not Disturb:** Please refer to the **Do Not Disturb** part mentioned before (Go to **Settings > Sound & vibration > Do Not Disturb**) for settings.
- **Heads up:** If you’re walking while using your phone, get a reminder to focus on what’s around you. Use with caution. Heads Up doesn’t replace paying attention.
  - **Permissions:** Physical activity and location (optional)
- Show icon in the app list (on/off)
- **Parental controls:** Add content restrictions and set other limits to help children balance their screen time.

### Additional settings

Go to **Settings > System settings** to customize your system settings.

## System Navigation

The device supports two types of navigation: Buttons or Gestures.

- **Hide gesture guide bar:** Enable to set guide bar.
- **Vibrate on back navigation:** Enable to set up the vibration.
- **Switch to previous app:** Swipe inward from the left or right side of the screen and then hold to switch to the previous app.
- **Mistouch prevention:** Gestures in some games need 2 swipes to take effect when you use full screen in landscape mode.
- **Gesture tutorial:** You can learn gestures in the tutorial.

## Language & region

Set your system language and region.

- Tap **Edit** to add the language.
- Press and drag the selected language to the top of the list to set the language to the system language.
- Tap **Region** to choose your region.

## Keyboard & input method

You can set your preferred keyboard here.

- **Keyboard and input method:** You can select **current keyboard** and set **secure keyboard for passwords**.
- **Manage Keyboard**
  - **Gboard:** multilingual typing.
  - **Google voice typing:** Enable this feature to enter text by voice.  
\*Note: You can choose between Gboard and Google voice typing.
- **Keyboard settings:**
  - Keyboard location (default/hide)
  - Show input methods button
  - Mistouch prevention: Swiping on the left or right edges of the keyboard will not return you to the previous page.
- **Input assistance**
  - **Autofill service:** Enable this to automatically fill in saved data when you browse the web or enter your account password or in other scenarios. This function will require additional apps to be installed.
  - **Personal dictionary**
  - **Point speed**

## Date & time

Set system date and time.

- **Time format:** Choose 24-hour format or 12-hour format.
- **Set time automatically:** Enable this for setting system time automatically or disable it to select **date** and **time**.
- **Set time zone automatically:** Enable this for setting system time zone automatically or disable it to select **time zone**.
- **Dual clock:** Display two clocks when in a time zone outside of your usual residence.

## Accessibility

The accessibility is optimized for the operation experience of visually impaired users, so that visually impaired users can use the phone smoothly.

- **General**
  - **Press Power button to end calls**
  - **Accessibility menu:** Show frequently used functions in a large menu.
  - **Accessibility button:** Quickly access accessibility features from any screen.
  - **Shortcut from Lock screen:** Allow accessibility function shortcuts to be accessed from the Lock screen.
- **Vision**
  - **TalkBack:** When TalkBack is turned on, it will provide you with voice feedback so that you don't need to look at the screen while using the device. This feature is very useful for the blind and those with low vision.
  - **Select to speak:** When select to speak is enabled, you can click on certain items on the screen and the system will read them aloud.
  - **Text-to-speech settings:** You can customize the text-to-speech output. You can also choose the language (temporarily support Chinese and English), speed and pitch according to your usage habits.
  - **Magnification:** Quickly zoom in on the screen to display content more clearly. You can set magnification type to switch between full and partial of the screen.
  - **Other functions:** Color vision enhancement, color correction, color inversion, high contrast text and remove animations.
- **Hearing**
  - **Live Caption:** Live Caption detects speech in media and automatically generates captions.
  - **Caption preference:** You can set the language, text size and caption style.
  - **Hearing aids:** To pair your hearing aids, find and tap your device on the next screen. Make sure your hearing aids are in pairing mode.
  - **Mono audio:** Combine channels when playing audio.
  - **Channel volume balancing:** Sliding to the left or right will decrease the sound volume in the opposite channel.
- **Interaction**
  - **Touch & hold delay:** (short/medium/long)
  - **Time to take action:** Choose how long to show notice that ask you to take action before they go away.
  - **Ignore repeated taps:** Repeated taps within the time you set will be ignored.



- **Switch access:** Lets people with motor impairments control phones and tablets using one or more switches. Use switches to select items, scroll, enter text, and more.
- **Large mouse pointer** (on/off)
- **Click when pointer stops:** When a mouse is connected, you can set the mouse cursor to click automatically when it stops moving for a certain amount of time.

## Gestures & motions

### Gestures

- **Screen off gestures:** Use specified gestures on the screen for quick access when the screen is off.
  - **Double tap to wake or turn off screen**
  - **Draw an O to open camera**
  - **Draw a V to turn on/off flashlight**
  - **Music control:** Use two fingers to draw "II" to stop or resume music playbacks and "<" or ">" to play previous or next song even when the screen is off.
  - **More gestures:** You can set more specific gestures to unlock, call and open an app.
- **Swipe down with 3 fingers to take screenshot:** Take a screenshot.
- **Touch and hold with 3 fingers to take screenshot:** Take a partial or scrolling screenshot.

### Motions

- **Raise to wake**
- **Lift to ear to answer calls**
- **Auto switch to receiver:** Automatically switch to the receiver when you lift your phone to your ear.
- **Flip to mute incoming calls**

### One-handed mode

Swipe down from the bottom of the screen to enter **One-handed mode**. Swipe up or tap area at the top of the screen to exit. This feature works only when navigation gestures are enabled.

### Power button

- **Press and hold the power button:** Press and hold the power button for Voice Assistant when the device is on, and it can also be changed to **Power menu**.
- **Double click the power button:** Double click the power button to open the camera or none.

### Screenshot

There are three methods to get a screenshot.

- **3-finger swipe down:** Screenshot.

- **3-finger touch and hold:** Take a partial or scrolling screenshot.
- **Power and Volume Down button:** Screenshot.

## Tutorial

- **Delete original image after editing:** You can turn off or on delete the original image after editing.
- **Screenshot sound (on/off):** You can turn off the screenshot sound.
- **Preview window location:** left or right.
- **About:** Privacy notice and source licenses

## Screen recording

Tap "Screen recording" in Quick settings to start recording. During screen recording, if you turn off the screen, make a phone call, or power off your device, the current recording will end and be saved automatically.

- **Record system sound:** Record system sound at maximum volume.
- **Record microphone sound.**
- **Definition:** High/ Medium/ Low/ Custom
- **Frame rate:** A higher frame rate results in more fluid videos, but may consume more power.
- **Record front camera video:** Record video with the front camera when taking a screen recording.
- **Show screen touches.**
- **Video coding formats:** H.265/ H.264
- **About:** Function description and user instructions and source licenses.

## Scheduled power on/off

For the convenience of users, the time switch on/off function is built in. You can go to **Settings > Additional settings > Scheduled power on/off** to set this function.

## OTG connection

OTG connection: Automatically turns off if not used 10 minutes.

## Back up and reset

- **Back up & migrate:** Back up data to or restore data from a local storage device or from the cloud.
- **Google Backup:** Using google to backup data, accounts and automatic restore.
- **Reset phone:** Reset network settings; Reset all settings; Erase all data (factory reset)

## About Device

View basic phone information, system version, and more in the **About device** option.

- **Device name:** Tap to edit the device name.
- **Storage:** Apps storage.
- **Processor**
- **Model**
- **RAM:** When enough storage space is available, you can use part of it to expand your RAM.
- **Android version:** Show the Android version and Android security update.
- **Version:** This shows the baseband & kernel version.
- **Legal information:** This shows user agreement, privacy notice, open source licenses, google legal, Google play system update licenses and health & safety information.
- **User guide:** Troubleshooting and product safety.  
\*Functions may vary with different models. Please refer to your actual phone.
- **All specifications:** Tap to view the Android version and Status.
- **Experience improvement programs:** Enable to join Use Experience Program and System Stability Improvement Program.
- **Award:** Tap to view OxygenOS Contributors.
- **Regulatory**

## Users & accounts

### Multiple users

- **You (Owner):** Display the currently logged in user. Tap to change username (username defaults to the phone owner).
- **Guest:** Tap to switch to guest mode, and limit calls and some features. You can enable/disable the **Allow calls** by tapping the settings icon to the right of the **Guest**.
- **Add user:** Share the device with other people by creating additional users.

### OnePlus Account

View the services for accounts.

### Automatically sync app data

This will conserve data and battery usage, but you will need to sync each account manually to collect recent information, and you will not receive notifications when updates are available.

## Google

Manage your Google account and services.

## Help & feedback

Tips and Support provide tips on device usage.

## Apps

Learn about the apps on your OnePlus device.

## Phone

### Dialing

- Method 1: Tap the keypad (dial pad) button, enter the contact number, and press the call button to dial the number.
- Method 2: Browse your contacts or call logs, and tap the number to dial it.
- Answer or refuse incoming calls: Swipe down to reject a call or swipe up to accept it.
- Incoming call during normal use: The green button is to accept the call and red is to reject it.

### Call screen

After accepting a call, the interface functions are as follows:

- **Speaker:** Enables loud speaker mode during call.
- **Keypad:** Opens the dial pad.
- **Mute:** Mutes the microphone.
- **Add call:** Adds multiple calls.
- **Hold:** Allows you to answer a new call by putting the current call on hold and then resume the current call when the new call ends.

### Settings

Tap the menu button in the upper right corner to start settings.

- **Caller ID & spam:** Switch on to identify business and spam numbers based on data provided by Google.

- **Accessibility:** Switch on Noise reduction to suppress your background noise during calls.
- **Assisted dialing:** To enable or disable “Assisted dialing” while roaming, and “Default home country/region code”.
- **Blocked numbers:** When switched on, you won’t receive calls or texts from blocked numbers from unidentified callers.
- **Calls**
  - **Answer/End call:** You can set auto answer calls when connected to external audio device, press Power button to end call, vibrate when call is answered/ended.
  - **Accessibility function:** Set TTY mode and hearing aid compatibility.
  - **Carrier-related settings**
  - **More settings:** You can set flash on call that the camera flash will blink for incoming calls when the screen is locked.
    - **Flash on call:** The camera flash will blink for incoming calls when the screen is locked.
- **Display options:** Change the sort order rule, name format and turn on and off dark theme of contact’s background.
- **Nearby places:**
  - **Personalized search results:** Enable to improve your search results by including items from search history.
- **Location permission is denied:** Nearby places search will not work without the location permission.
- **Quick responses:** Respond to an incoming call with a text message. You can tap to edit the content.
- **Sounds and vibration:** Set the sound and vibration.
- **Voicemail:** Set voicemail notification as Important or Other.
- **Caller ID announcement:** The caller’s name and number will be read out loud for incoming calls.
- **Flip to Silence:** Enable to silence an incoming call by placing your phone face down on a flat surface.

## Contacts

Contacts has following functions: Edit, delete, search, set labels, manage blocked numbers and more.

### Add a contact

1. Enter Contacts
2. Tap + to create a new contact
3. Enter contact information
4. Tap “save” in the upper right corner to save it

## **My Files**

In **My Files** you can quickly access and manage a variety of files. Enter the application drawer and open the My Files application.

### **Device storage**

You can view and manage folders and documents stored on your phone.

### **Categories**

You can check files by file category, including Photos, Videos, Audio and so on.

### **Sources**

You can see your files from downloads and Bluetooth. You can also check files you add to Favorites and private safe.

## **Messages**

Send, receive, and view Messages through the Messages app.

### **Send message**

1. Open the Messages application.
2. Tap the button in the lower right corner.
3. Select recipient.
4. Enter SMS content.
5. Tap the send icon to send a message.

### **View and reply message**

Messages are sorted by time.


1. Open the Messages app.
2. Select the message you want to view from the list.
3. If you want to reply to a message, enter the message in the text box at the bottom of the screen, and then tap the send icon on the right to send it.

## Message settings

Tap the menu button in the upper right corner and select Settings. Message settings include Chat features, Notifications, Bubbles, Hear outgoing message sounds, Your current country, Automatic previews, Spam protection, Advanced, About, Terms & privacy. Enter advanced settings to reach Group messaging, Auto-download MMS when roaming, Use simple characters, Get SMS delivery reports, Wireless emergency alerts and more.

## Weather

Provides the weather forecast and early warning function.

- **Check the weather:** Provides information on weather, temperature, the following six days of weather, the following 24 hours of weather, wind direction, body temperature, humidity, visibility, pressure and more.
- **Add city:** Tap “”, tap the "+" button, enter the city name to search, and select the city to add.
- **Switch city:** Swipe left and right to switch between cities.
- **Settings:** Tap the menu button in the upper right corner and select **Settings**.
- **Temperature:** Select the temperature unit – Celsius or Fahrenheit.
- **Wind:** Select the wind unit, like Meters per second – m/s, Kilometers per hour – km/h, Feet per second ft/s, Miles per hour- mph, Nautical miles per hour – kts.
- **Visibility:** Select units of visibility, Kilometers – km/ Miles – mi.
- **Air Pressure:** Choose the unit of pressure, Hectopascals – hPa, Millimeters of mercury – mmHg, Inches of mercury – inHg.
- **About weather:** OnePlus Weather

## Calculator

Calculator provides common calculator functions.

Enter the application drawer and open the Calculator app.

- **Basic Calculator:** The calculator provides a basic calculation mode by default, which can perform simple addition, subtraction, multiplication and division calculations.
- **Scientific Calculator:** Tap the spread icon on the right bottom corner to enter scientific mode.
- **Records:** Go to Record to view history, and tap the button in the upper right corner to clear it.
- **Enter small window mode:** Tap the button in the upper left corner. Calculator will be displayed in a small floating window. You can use calculated values in another app without switching between the apps. You can adjust the visibility as you like.
- **Use unit conversions:** You can convert units such as length, area, volume, speed, weight,

temperature, power, and pressure.

## Recorder

Recorder provides recording and playback functions.

Enter the application drawer and open the Recorder app.

- **Recording:**
  - **Choose the recording mode:**
    - **Standard:** Records sound without much processing. It can be used for most general occasions.
    - **Meeting:** Makes voices sound louder. Best for recording from a distance, such as when in a meeting or lecture.
    - **Interview:** Cancels noise. Best for recording voices near your device, such as when conducting an interview.
  - **Start recording:** Tap the start button to start recording.
  - **Pause the recording:** Tap the pause button to pause a recording.
  - **Insert tags:** Tap the flag button to insert tags.
  - **Set the recording format:** You can set the recording format (MP3/AAC/WAV) by selecting the settings in the upper right corner of the main interface.
  - **Photo mark recommendation:** Enable to have recommended photo marks during recording.
- **Recording playback and management:**
  - **Play recording:** Tap the recording to play.
  - **Delete recording:** Long press the recording that needs to be deleted and tap the delete button.
  - Tap the menu icon in the upper right corner to share the recording, rename the recording and set it as ringtone.

## Notes

Sticky notes let you take quick notes and edit text and pictures.

- **Add note:** Tap the plus button to add a note. Supports adding text, album pictures, photos, voice recognition, doodles, notebook, to-do list. Allows to delete notes, set reminders, etc.
- **Change the text styles:** Tap the “Aa” icon to change the style of your texts.
- **Search notes:** Tap the search button and enter the keywords to search.
- **Delete a note:** Long press the note that you want to delete and tap the "delete" button.
- **Share a note:** Open the note you want to share, tap the share button in the upper right corner, select the sharing method, and then press the page prompt to complete the sharing.
- **Add reminders to your notes:** Open the note and tap the menu icon in the top bar, then select reminder to set the date and time for the reminder.
- **Add draws to your notes:** Open the note and you can add draws to your notes.



## Photos

All images and videos are saved by default in the Gallery app, which includes albums, recently deleted photos, and photo editing functions.

- **Photos:** Photos and videos are displayed in a timeline list view.
- **Albums:** This includes commonly used albums, recently deleted albums and other albums. Tap albums to view specific lists and photos.
- **Explore:** This includes Smart category feature and Story function. Smart category will categorize photos by “people”, “places” and “things” and other standards. Story feature will create personal videos automatically based on specific photos.
- **Dynamic Layout:** Double-finger zoom to open the size display and enjoy a reasonable image layout.

## Clock

### Alarm

- **Add alarm clock:** Tap the “+” button below to add and set a new alarm.
- **Alarm clock time:** Drag the numbers on the dial to set the hours and minutes.
- **Repeat:** You can choose Monday to Sunday.
- **Ringtone & vibration:** Select the alarm clock ringtone from system ringtones or local storage and set the vibrate.
- **Label:** An alarm note will be displayed on the screen when it rings.
- **Snooze:** Set internal time for the snooze.
- **Delete alarm:** Long press the alarm you want to delete and tap “Delete”.

### World Clock

- **Add region:** Tap the globe icon at the bottom of the screen to check and select the cities from the list.
- **Comparison time:** Drag the dot on the dial to see the time of the city you added.
- **Weather:** The weather will be shown when you tap on the city name.

### Stopwatch

- **Start:** Tap the start button to start the timer.
- **Pause:** Tap the pause button to pause the timer.
- **Mark:** Tap the flag button to mark in the lower right corner.
- **Clear records:** Tap the reset icon in the lower left corner.

### Timer

- **Add countdown:** After entering the minutes and seconds, press the start button to start the countdown.
- **Pause:** Tap the pause button to pause a countdown.

## Zen Mode

Zen Mode allows you to put the phone down and enjoy your life just yourself or with others you like. Once started, it can't be canceled, and incoming notifications will be temporarily muted. Applications except camera will be locked, but you can still receive phone calls and use the emergency call.

- Turn on Zen Mode

There are two ways to turn on Zen Mode.

1. Pull the notification panel down > tap **Zen Mode**.
  2. Zen Mode can be dragged to the desktop and turned into an icon.
- \* Zen Mode can be uninstalled.

In Zen Mode > tap the time > set the duration > Swipe left or right to switch between different themes > tap the button below to start.

- **Set Zen Mode:** Enter Zen Mode > tap profile icon in the top right corner and then tap settings icon. Set the theme sounds, daily reminder, notification and more.

## Clone Phone

“Clone phone” allows you to quickly migrate contacts, call logs, text messages, pictures, audio, video, notes, apps, downloads, documents, and other data from your previous phone to your new phone. Clone phone also provides local backup and recovery.

## Google Apps

Enjoy applications powered by Google. Visit [Google.com](https://www.google.com) to learn more.

### Google

Find online content with tools that learn what you are interested in. Turn on your personalized feed to receive customized content.

### Chrome

Browse the Internet with Chrome and bring your open tabs, bookmarks, and address bar data from your computer to your mobile device.

## **Gmail**

Send and receive emails with Google's web-based email service.

## **Maps**

Get directions and other location-based information. You must enable location services to use Google Maps.

## **YouTube**

Watch and upload videos from your device.

## **Drive**

Open, view, and share files saved to your Google Drive cloud account.

## **Duo**

A video calling app allows you to connect with the people who matter most.

## **Photos**

Store and back up your photos and videos automatically to your Google Account with Google Photos.

## **YouTube Music**

A new music app by Google that allows you to easily find the songs and videos you're looking for and to discover new music.

## **Files**

Files is a file management app for file browsing and transfer.

## **Calendar**

Google Calendar is an app for time management and scheduling.

## **Assistant**

Google Assistant is an artificial intelligent assistant. Refer to "[Google Assistant](#)" for more details.

## **Play Store**

Play store is an online application store. You can install applications you need here.

## Advanced

### Learn about advanced tips for your phone

## Games

OxygenOS provides **Games** to stop you from being disturbed and give your immersive feelings and experience when you are gaming.

\*Some features in Games may vary between different countries and areas.

### My games

You can see your games list, view notifications and messages and stored game captures. You can add games and switch layout in the Games. Your game duration and playing frequency can be viewed in **Gaming data**.

### Explore

Provides excellent game contents for game recommendation. You can see the most played games and trending games lists.

### Reviews

Show the latest and popular evaluations and comments for different games.

### Settings

Go to **Games > My games > Settings** to customize your game setting for preference.

### General

- **Gaming Tools:** A collection of handy gaming tools. Swipe down from the upper left or right corner of the screen while in a game to bring up the Gaming tools.
  - Add WhatsApp, discord and messenger: Provide a more convenient social channel for players.
  - Performance settings: Low power mode/ Balanced mode/ ProGamer mode
  - Game forces mode: Turn on the game focus mode.
  - Notification: Set the notification style.

- Screen recorder: Lets you capture videos of your phone screen (including touch events) along with sound
  - Touch optimization: Allows players to adjust Touch sensitivity & Swipe sensitivity, and it can provide richer customization (for example: notification drawer mistouch prevention settings, etc.)
  - System status: Display Real-time FPS/GPU/CPU data can be displayed in-game.
  - Voice modulator: Fake your voice during playing games to have fun and protect your privacy. These five popular games support the voice change: PUBG/CODM/LOLM/Free Fire/Fortnite. Voice modulator is also available in Discord.
- **Move game icons to "Games":** Display all your games in "Games" instead of the Home screen or app drawer.
  - **Update Settings**

## Do not disturb

When you do not want to be disturbed by a message, enable Do Not Disturb mode. The phone will not ring or vibrate when it receives a notification, except for alarms and settings. Scroll to the notification bar and tap to enable the “Do Not Disturb” function. See Do Not Disturb for settings.

- **Answer calls on speaker:** calls are automatically answered on the speaker when playing the game.
- **Notifications style:** Select the notification display mode when game mode is on. There are four modes: Heads-up notifications, Text notification, Bullet notifications and Block.
- **Brightness lock:** The screen brightness will not be automatically adjusted when playing the game.

## Performance enhancement

- **4D vibration:** Get an immersive audio-visual gaming experience with scenario-specific vibration effects.
- **Smart network switching:** Automatically switch to a better network when your current network connection is slow. This may consume some mobile data.

## Other

- **Lightning start:** Quickly launch games you frequently play.
- **Game focus mode:** An advanced gaming mode created by e-sport experts. This mode will block all disturbances for a more immersive gaming experience. This mode will eliminate all gaming mistouches and interruptions by disabling Quick settings, navigation gestures, and Gaming Tools.

- **Game filters:** Apply real-time effects for your games. Game filters is available in gaming tools and supported by games PUBG MOBILE.

## App Cloner

Create a new copy for the application to log in to different accounts.

Go to **Setting > Apps > App Cloner**. The list will show you the applications that support App cloner. Tap the application to open App cloner.

## Reboot, Update, Backup, Recovery

Learn to upgrade and reset your OnePlus device

### Reboot or force reboot

Most issues can be resolved by rebooting your device in the following two ways:

1. When powered on, press power button and volume up button simultaneously, and then tap “Restart” to reboot the device.
2. When powered on, long press the power button and volume up button for 10 seconds, the phone will shut down, and then press the power button to turn on the device again.

### System updates

1. Enter **Settings > About device > Software update**, then the system starts to check for updates.
2. Follow the instructions to download and update.
3. If your device is up to date, you will not see the instructions.

### Backup and Restore

Create a backup or recovery when needed.

### Backup and restore by Clone Phone.

Refer to Clone phone for more information.

## Use Google drive for backup and recovery

- **Create backup**

1. Access Settings > Users & accounts > Add account, login Google account and enable Account sync.
2. Wait for the system to complete synchronization automatically.
3. Use the Wi-Fi network to back up your device as the data size may be too large to back up using mobile data.

- **Restore Backup:** After a factory reset or when you switch to a new device, log in to your Google account on the device and enable Account sync to restore the data on the phone.

## Factory reset

- **Note:**

1. Restoring factory settings will wipe all app data, contacts, text messages, and so on. Backup important data before a factory reset.
2. If “Erase all data” is enabled, ensure that all important files, such as photos and documents in the phone and local backup, have first been copied to another device.

- **Operating guidelines:**

1. Settings > Additional settings > Back up and reset > Reset phone
2. Tap Reset phone
3. Enter passcode (If the passcode is enabled)
4. Wait till the factory reset is complete

## Accessibility

Learn about Special features that make using the device easier for people with physical disabilities.

## Press power button to end calls

Go to **Settings > System settings > Accessibility > General** and then enable “Press power button to end calls”. This allows you to end a call by simply pressing the power button.

## Magnification

Go to **Settings > Additional settings > Accessibility > Vision > Magnification > Magnification type**.

- **To zoom in:**

1. Use the preset shortcut to start magnification.
2. Tap the screen.
3. Drag with two fingers to move around the screen.
4. Pinch in or out with two fingers to adjust zoom.
5. Use the shortcut again to stop magnification.

- **To zoom in temporarily:**

1. Use the preset shortcut to start magnification.
2. Touch and hold anywhere on the screen.
3. Drag your finger to move around the screen.
4. Lift your finger to stop magnification.

## Color correction

Go to **Settings > Additional settings > Accessibility > Vision** and enable **Color correction** to let you adjust how colors are displayed on your device.

- **Red-green:** Green weak, deuteranomaly
- **Red-green:** Red weak, protanomaly
- **Blue-yellow:** Tritanomaly
- **Grayscale:** All colors on your screen will turn gray

## Color vision enhancement

Go to **Settings > Additional settings > Accessibility > Vision** and enable **Color vision enhancement** to adjust colors based on your color vision for the most comfortable display effects.

- **Grayscale**
- **Red filter**
- **Green filter**
- **Blue filter**
- **Personalized**

## Color inversion

Go to **Settings > Additional settings > Accessibility > Vision** and enable “Color inversion” to invert the display colors.



## High contrast text

Go to **Settings > Additional settings > Accessibility > Vision > High contrast text**. Enable this function to increase the contrast with the background.

## Legal Notice


### Declaration

Without prior written permission of OnePlus, reproduction, transfer, distribution or storage of the contents in this document in any form is prohibited. OnePlus operates a policy of ongoing development. Thus, OnePlus reserves the right to make changes or improvements to any of the products described in this document without prior notice. The contents of this document are all provided “as is”. Except as required by applicable law, no warranties of any kind, either express or implied, are made in relation to the accuracy of this document. To the maximum extent permitted by applicable law, under no circumstances shall OnePlus or any of its licensors be responsible for any loss of data or incur any special, incidental, consequential, or indirect damages caused.

Availability of product supplies, application software, and accessories may vary. For detailed information, please refer to an authorized OnePlus distributor. This device may contain commodities, technology, or software subject to export laws and regulations. Diversion contrary to law is prohibited.

### Trademarks and Permissions

Copyright © 2022 OnePlus Technology (Shenzhen) Co., Ltd. All right reserved.

ONEPLUS and  are trademarks or registered trademarks of OnePlus Technology (Shenzhen) Co., Ltd.

Android™ is a trademark of Google Inc.

LTE is a trademark of ETSI.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.



The N-Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.



Manufactured under license from Dolby Laboratories. Dolby, Dolby Atmos, and the double-D symbol are trademarks of Dolby Laboratories, Inc.

Wi-Fi®, the Wi-Fi CERTIFIED™ logo, and the Wi-Fi logo are trademarks of Wi-Fi Alliance

® .

Other trademarks, product, service and company names mentioned may be the property of their respective owners.

## **Privacy Policy**

OnePlus is constantly striving to protect your personal information. To better understand how we protect your personal information, you can read our "Privacy Policy" in the Setup Wizard when you turn on your phone for the first time.

## **Precautions for using the device**

Please read all the safety and health information carefully before using your device to ensure its safe and proper operation.

## **General Safety Information**

Failure to follow these guidelines may cause harm to your device, property, yourself, or others.

- Do not switch on the device where prohibited or when it may cause interference or danger.
- Do not use device at gas stations, service stations, or near fuel or chemicals.
- Please do not store or carry your mobile phone or accessories near liquid or flammable gas.
- Do not place the phone near magnetic cards or other magnetic objects, since information stored on floppy discs, memory cards and credit cards could be damaged by magnetic radiation.
- Do not place the battery, phone or charger in a microwave oven or other high voltage equipment. Otherwise, it may cause circuit damage, fires, or other damage.
- Do not disassemble or open, crush, bend or deform, puncture, or shred.
- All wireless devices, including mobile phones, might be susceptible to interference, and it can also cause interference. Please check all laws and regulations when using your mobile phone, especially in airplanes, hospitals or medical institutions.
- Only use branded accessories and batteries that are approved by OnePlus. Accessories which are not approved by OnePlus may damage the phone or violate local regulations for radio devices. OnePlus will not take any responsibility for accidents or problems caused by using accessories that are not approved by OnePlus.
- The device is designed for water resistance under certain conditions, but OnePlus does not recommend excessive submersion. Liquid damage will void the warranty.
- When connecting with other devices, please follow the safety guidelines presented in this manual. Do not attempt to connect your device with incompatible products.
- Please do not use the phone if antenna is damaged. Otherwise, it could cause injury.

- Please keep metallic objects away from phone receiver. Small metallic objects may be attracted to the device and personal injury or device damage could occur.
- Keep a minimum distance of 15 cm between a wireless device and an electronic implant (pacemaker, insulin pumps, neurostimulators, etc.). If wearing an electronic implant, hold the device on the side opposite the implants.
- Keep the device away from the belly of pregnant women.
- Keep the device away from the lower abdomen of adolescents.
- Children and adolescents should make reasonable use of the phone. Avoid night communications and limit the frequency and duration of calls.
- Only connect to power sources with USB 2.0 or above.
- To reduce the level of exposure to radiation, you should use the mobile telephone proximity to the network tower or use of accessories (hands-free kit etc.) or use loudspeaker if suitable; use the device under good reception conditions (when the signal indicator displays a full signal on the signal reception bar) can reduce the amount of radiation received; giving priority to the use of data, SMS and MMS messages rather than calls.
- If your device support wireless charger and when using it as a wireless charger it is intended for use as a desktop device and should not be carried when in this mode. To comply with RF exposure requirements when using in the wireless charging mode please place the device at a minimum distance of 10cm from your body.
- Do not remove the Back Cover.
- Please keep the phone out of reach of children in order to prevent injuries or property damage.
- Ideal operating temperatures are 0°C to 35°C, Ideal storage temperatures are -20°C to +45 °C.
- Only operate your phone between 35% to 85% humidity.

## **Battery Safety**

- Please do not attempt to repair, disassemble or modify the battery. Replacing battery by an incorrect type may present a risk of fire, explosion, leakage, or other hazard. Your phone can only use OnePlus authorized batteries.
- Do not place or use battery near fires, heaters, direct sunlight, immerse or expose to water or other liquids, or other heat sources. Prolonged exposure to heat may cause battery leakage, explosions, or fires.
- Please do not place pressure on or pierce the battery with hard objects. Damaging the battery could cause battery leakage, overheating, or fires.
- Do not short-circuit a battery or allow metallic or conductive objects to contact the battery terminals.
- Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- If you experience any battery abnormalities, such as high temperature, discoloration, distortion, or leakage, immediately discontinue usage of the device and contact customer support.
- All batteries have a limited lifespan and will begin to lose capacity after several hundred

charges/discharges.

- Do not dispose of the battery as household waste. Promptly dispose of used batteries in accordance with local regulations.
- Do not place the phone or battery in a low air pressure location, which may lead to an explosion or battery leakage.

## **Charging Safety**

- The charger is intended for indoor use only.
- Do not charge the battery under the following conditions: in direct sunlight, in temperatures below 5°C; in areas with humidity, dust or strong vibrations; in areas near a TV, radio or other electrical appliances.
- The charger shall be installed near the equipment and shall be easily accessible.
- The maximum ambient charging temperature of the equipment declared by manufacturer is 35°C.
- Sockets that are dirty may cause poor contact with the charger and your phone may fail to charge properly.
- Please only use the official OnePlus charger. Using unauthorized chargers can be dangerous and can void your warranty.
- Make sure to only use outlets with the correct voltages (as label led on the charging brick). Using an incorrect voltage can damage your phone and/or battery and lead to injury.
- Do not use unsafe plugs or outlets.
- Do not use a short-circuit charger.
- Do not connect your device to a high-voltage power supply or the battery could become damaged.
- Do not disassemble or modify charger, as this may lead to personal injury, electric shock or fire.
- Do not touch the charger, cable or power socket with wet hands, as this may cause electric shock.
- Do not place heavy objects on the power cord or attempt to modify any cables.
- Make sure to grasp the charger firmly while unplugging it.
- Do not pull the power cord as this may lead to damage and cause electric shock or fire.
- Before cleaning the device, unplug the power plug from the socket.
- Unplug the charger from electrical outlets and the device when not in use.
- When charging, please keep the device in a well-ventilated area. Please charge this mobile phone in an environment between 5°C and 35°C. If the phone has a flash charging function, it may not be able to enter the flash charging mode when the temperature is below 15°C or over 35°C.
- Do not charge the battery over 12 hours.

## **Driving Safety**

- Do not use the device and safety should take priority when you are operating a vehicle. Be sure to obey related regulations in the area or country in where you drive.
- Do not place your phone or accessories near safety air bags.
- Compass and GPS information are only used for reference purposes.
- If you do not wish to disclose your location, be sure not to use applications that can record your location.

## Health Information



- To prevent possible hearing damage, do not listen at high volume levels for long periods.
- Damage to the display or battery could lead to leakage of the liquid. If this liquid comes in contact with your eyes, skin or clothes, immediately rinse your eyes (do not rub) or wash skin with water thoroughly and seek medical attention.
- Some people may get dizzy or experience medical problems in response to flashing lights. If you are at risk, please consult your doctor before using this device. If you have the following symptoms: headache, dizziness, convulsion, eyes or muscle cramps, loss of consciousness, or involuntary body movements, please stop using the device immediately and seek medical attention. Avoid using the device for extended periods and keep proper distance from your eyes.

## Laser Safety Statement

If this product supports the laser auto-focus feature. To ensure proper use of this product, please read this owner's manual carefully and retain for future reference. Should the unit require maintenance, contact an authorized service center. Use of controls, adjustments, or the performance of procedures other than those specified herein may result in hazardous radiation exposure. To prevent direct exposure to laser beam, do not try to open the enclosure or make direct contact with the laser.

**CLASS 1 LASER PRODUCT**

## EU/UK Regulatory Conformance

### CE Statement

Hereby, OnePlus Technology (Shenzhen) Co., Ltd. declares that the radio equipment type Smart Phone is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity (EU-DoC) is available at the following internet address:  
<https://service.oneplus.com/global/user-manual>.

Notice: Observe the national local regulations in the location where the device is to be used. This device may be restricted for use in some or all member states of the European Union (EU).

## **UK Statement**

Hereby, OnePlus Technology (Shenzhen) Co., Ltd. declares that the radio equipment with this declaration and bearing the UKCA Mark is in compliance with UK Radio Equipment Regulations 2017. The full text of the UK declaration of conformity is available at the following internet address: <https://service.oneplus.com/global/user-manual>.

## **RF Exposure Information (SAR)**

- The SAR limit of Europe for Head and Body is 2.0W/kg, and for Limbs is 4.0W/kg. The highest SAR value of this device complies with this limit. And please see the “Quick Start Guide” card to find the highest SAR value.
- This device was tested for typical operation with the back of the handset kept 5mm from the body. To maintain compliance with RF exposure requirements, use accessories that maintain a 5mm separation distance between your body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with RF exposure requirements, and should be avoided.
- Cases with metal parts may change the RF performance of the device, including its compliance with RF exposure guidelines, in a manner that has not been tested or certified, and use such accessories should be avoided.

## **Use Restriction**

Restrictions in Norway: Use of this radio equipment is not allowed in the geographical area within a radius of 20 km from the center of Ny-Ålesund, Svalbard.

The 5150 to 5350 MHz frequency range is restricted to indoor use only and the 5945 to 6425 MHz frequency range is not permitted to use on Unmanned Aircraft Systems (UAS). These restrictions apply in: AT, BE, BG, CH, CY, CZ, DE, DK, EE, EL, ES, FI, FR, HR, HU, IE, IS, IT, LI, LT, LU, LV, MT, NL, NO, PL, PT, RO, SE, SI, SK, TR, UK(NI).

Please check Radio Waves Specifications in the Quick Guide to determine the Wi-Fi frequency range supported by the device.

## **Frequency Bands and Power**

(a) Frequency bands in which the radio equipment operates:

Some bands may not be available in all countries or all areas. Please contact the local carrier for more details.

(b) Maximum radio-frequency power transmitted in the frequency bands in which the radio equipment operates: The maximum power for all bands is less than the highest limit value specified in the related Harmonized Standard. Please see the “Quick Start Guide” to find the frequency bands and transmitting power.

## Correct Disposal of this Product



This symbol (with or without a solid bar) on the device, batteries (included), and / or the packaging, indicates that the device and its electrical accessories (for example, a headset, adapter or cable) and batteries should not be disposed of as household garbage. To safely recycle your device, please use return and collection system or contact the retailer where the device was originally purchased.

## RoHS Compliance

This product complies with directive 2011/65/EU, RoHS regulations 2012(S.I. 2012/3032) and its amendments, on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

## ERP Compliance

OnePlus Technology (Shenzhen) Co., Ltd. Hereby declares that its products conform to the Energy-related Products Directive (ERP) 2009/125/EC.

Model	VCBAJAEH、VCBAJAYH			
Manufacturer	Huizhou Golden Lake Industrial Co., Ltd			
Manufacturer address	Huizhou Golden Lake Industrial Co., Ltd. Dongjiang Industrial Estate, Shuikou Street, Huicheng District, Huizhou City, Guangdong Province, 516005, P.R. China			
Input voltage	115V		230V	
Input AC frequency	60 Hz		50Hz	
Output voltage	5.0 V DC	11V DC	5.0 V DC	11.0 V DC
Output current	2.0 A	7.3 A	2.0 A	9.1 A
Output power	10.0 W	80.0W	10.0 W	100.0 W
Average active efficiency	87.54%	89.17%	84.47%	89.73%
Efficiency at low load (10%)	/	88.86%	/	87.24%
No-load power consumption	0.054W		0.084W	

## FCC Regulatory Conformance

### FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference; and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **FCC Caution**

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- The antenna(s) used for this transmitter must not be collocated or operate in conjunction with any other antenna or transmitter.
- The country code selection is for non-US model only and is not available for all US models. Per FCC regulation, all Wi-Fi products marketed in US must be fixed to US operation channels only.

## **RF Exposure Information (SAR)**

- This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.
- The SAR limit set by the FCC is 1.6W/kg. The highest SAR value of this device type complies with this limit. And please see the "Quick Start Guide" card to find the highest SAR value reported to FCC.
- Tests for SAR are conducted using standard operating positions accepted by the FCC with



the device transmitting at its highest certified power level in all tested frequency bands.

- Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.
- While there may be differences between the SAR levels of various devices and at various positions, they all meet the government requirement.
- This device has also been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and positions the handset a minimum of 15mm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. Position the handset a minimum of 15mm from your body when the device is switched on.
- Choose the belt clips, holsters, or other similar body-worn accessories which do not contain metallic components to support the minimum distance of body-worn operation. Cases with metal parts may change the RF performance of the device, including its compliance with RF exposure guidelines, in a manner that has not been tested or certified, and use such accessories should be avoided.

## **Hearing Aid Compatibility (HAC) regulations for Mobile phones**

- Your phone is compliant with the FCC Hearing Aid Compatibility requirements.
- The FCC has adopted HAC rules for digital wireless phones. These rules require certain phone to be tested and rated under the American National Standard Institute (ANSI) C63.19-2011 hearing aid compatibility standards.
- The ANSI standard for hearing aid compatibility contains two types of ratings.
- M-Ratings: Rating for less radio frequency interference to enable acoustic coupling with hearing aids.
- T-Ratings: Rating for inductive coupling with hearing aids in tele-coil mode.
- Not all phones have been rated, a phone is considered hearing aid compatible under FCC rules if it is rated M3 or M4 for acoustic coupling and T3 or T4 for inductive coupling. These ratings are given on a scale from one to four, where four is the most compatible. Your phone meets the M3/T3 level rating.
- However, hearing aid compatibility ratings don't guarantee that interference to your hearing aids won't happen. Results will vary, depending on the level of immunity of your hearing device and the degree of your hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.
- This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone

retailer.

• Hearing devices may also be rated. Your hearing device manufacturer or hearing health professional may help you find this rating. For more information about FCC Hearing Aid Compatibility, please go to <http://www.fcc.gov/cgb/dro>.



## **ISED Regulatory Conformance**

### **ISED Statement**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient un ou plusieurs émetteurs/récepteurs exempts de licence conformes aux normes RSS(s) applicables aux appareils radio exempts de licence d'Innovation, Sciences et Développement Économique Canada. Son fonctionnement est soumis aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et.
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### **CAN ICES-003(B)/ NMB-003(B).**

This device complies with the Canadian ICES-003 Class B specifications.

Cet appareil numérique de la Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux radiations IC RSS-102 établies pour un environnement non contrôlé.

### **Restrictions in 5GHz band**

The device could automatically discontinue transmission in case of absence of information to transmit, or operational failure. Note that this is not intended to prohibit transmission of control or signaling information or the use of repetitive codes where required by the technology. The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

- Les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes

de satellites mobiles utilisant les memes canaux.

## **RF Exposure Information (SAR)**

The SAR limit set by the ISED is 1.6W/kg. The highest SAR value of this device type complies with this limit.


This device has also been tested and meets the ISED RF exposure guidelines for use with an accessory that contains no metal and positions the handset a minimum of 15mm from the body. Use of other accessories may not ensure compliance with ISED RF exposure guidelines. Position the handset a minimum of 15mm from your body when the device is switched on.

Déclaration d'exposition aux radiations:

Le produit est conforme aux limites d'exposition pour les appareils portables RF pour les Etats Unis et le Canada établies pour un environnement non contrôlé. Le produit est sûr pour un fonctionnement tel que décrit dans ce manuel. La réduction aux expositions RF peut être augmentée si l'appareil peut être conservé aussi loin que possible du corps de l'utilisateur ou que le dispositif est réglé sur la puissance de sortie la plus faible si une telle fonction est disponible. Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 15mm de distance entre la source de rayonne.

## **India Regulatory Conformance**

### **Waste Electrical and Electronic Equipment (WEEE)**



This symbol (with or without a solid bar) means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, user has the choice to give his product to a competent recycling organization. Proper recycling of your product will protect human health and the environment. If you are not sure what to do with e-waste, please contact your local authorities, retailer, or household waste disposal service.

Declaration of Conformity hereby, OnePlus/Mobitech India Private Limited (“OnePlus/Mobitech”) states that OnePlus/Mobitech is committed to comply with the extended producer responsibility vide authorization no. B-29016/(824)/EPR18/WM-III and amendment Division dated 18.07.2018 issued by Central Pollution Control Board.

For more information on safe disposal and recycling you may log on to <https://www.oneplus.in/legal/e-waste-management> or contact our Toll Free No. 1800-102-8411

## **RF Exposure Information (SAR)**

- The SAR limit is 1.6W/kg.

- Position the handset a minimum of 15mm from your body when the device is switched on.

## **How to switch system languages**

Go to Settings—Additional settings—Keyboard & Input method-manage keyboards—Gboard-languages—Add Keyboard—Add your prefer languages. The device supports: English, Hindi & Marathi, for inputting. The device also supports: Assamese, Bengali(Bangla), Gujarati, Hindi, Kannada, Kashmiri, Konkani, Malayalam, Manipuri(Bangla), Marathi, Nepali, Oriya, Punjabi, Sanskrit, Sindhi(Devanagari), Tamil, Telugu, Urdu, Bodo (Boro), Santhali(OlChiki), Maithili, Dogri, Manipuri (MeeteiMayek), Santhali (Devnagari) and English for readability.