

About the Manual

- This manual is for reference only. The operation of the actual product shall prevail if there is any inconsistency.
- All the designs and software are subject to change without prior written notice.
- All trademarks and registered trademarks mentioned are the properties of their respective owners.
- Please visit our website or contact your local customer service if there is any problem when using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Step 4

Wait for booting to be finished, and then the camera indicator light flashes green.

Step 5


Do the following operations to finish adding the camera.



- If you have more than one camera, do step 5 to add them one by one.
- If the Wi-Fi network has changed or the indicator status goes wrong, press and hold the RESET button for 10 s to reset the camera, and then do step 5 to add the camera again.

Installing Camera

Make sure that the mounting surface is strong enough to hold at least three times of the device weight.



- Step1** Drill screw holes on the mounting surface as the positioning map shows, and then put in the wall anchors.
- Step2** Attach the pedestal to the mounting surface with the mounting screws.
- Step3** Power up the camera, and then adjust the lens to the ideal angle.

FAQ

► Q: The device cannot work normally or start?

Check the LED indicator status. If the light is not in green, press and hold the reset button for 10 s to reset the camera.

► Q: How to connect the camera to a new Wi-Fi?

- If the camera is online, select **Device Detials > Network Config** to change the Wi-Fi connection on the app.
- If the camera is offline, reset the camera, and then configure the camera again.

► Q: Connection is overtime?

- Check the Wi-Fi configuration of the router: Select the channel to auto, and the mode to 11bgn mixed.
- Check if the distance between the camera and the router, the camera and the smart phone is within 5 m (16.4 ft) during the connection.

► Q: When the Micro SD card is full, how is the recorded video saved?

When the Micro SD card is full, the system will overwrite the previous recorded videos. Save the important information in time.

► Q: The device is offline?

Check the indicator status:

- If the green light is on, check whether the router can connect to the Internet. If Internet is working, restart the camera.
- If the red light flashes, reset the camera, and then configure the camera again.
- If the red light is on, it means the camera is faulty.

For more questions, please scan the QR code below or visit:
www.imoulife.com/web/support/help



Imou

Quick Start Guide

Version 1.0.0

Packing List



Camera ×1



Positioning Map ×1



Power Adapter ×1



Screw Package ×1




QSG ×1



Waterproof Connector ×1

Camera Introduction



The pattern of the LED indicator is included in the following table.

LED Indicator Status	Device Status
Off	<ul style="list-style-type: none">Powered off/LED turned offRebooting after reset
Red light on	<ul style="list-style-type: none">BootingDevice malfunction
Red light flashing	Network connection failed
Green light flashing	Waiting for network
Green light on	Operating properly
Green and red lights flashing alternately	Firmware updating

Operating with Imou Life App

Step 1

Scan the following QR code or search "Imou Life" in Google Play or App Store to download and install the app.

If you have installed the app, update it to the latest version.



Step 2

Run the Imou Life App, and then create an account for the first use.

Step 3

Connect the camera to power source with the power adapter.