



THUNDERBLADE V4

User Guide



Introduction	1
1.1 Minimum System Requirements	
1.2 Package Contents	
1.3 Getting Started	
1.4 About This Manual	
1.5 Front View	
1.6 Rear View	
Mac & PC Setup	3
2.1 Mac Formatting & SoftRAID Information	
2.2 PC Formatting Process	
Support Resources	10
3.1 Troubleshooting	
3.2 About Data Backup	
3.3 Contacting Technical Support	

INTRODUCTION

1.1 Minimum System Requirements

- **Mac:** host with Thunderbolt™ 3 port running macOS 10.13 or later
- **PC:** host with Thunderbolt 3 port running Windows 10 or later

1.2 Package Contents

- OWC ThunderBlade V4
- 0.5m Thunderbolt 3 cable
- Power supply and cable

1.3 Getting Started

- To use the ThunderBlade V4, connect it to your computer via the included Thunderbolt 3 cable. Device drivers are not required, however use of SoftRAID XT (macOS only at the time of this writing) requires the SoftRAID driver and application.
- The LED indicator on the front of the device (see Section 1.5) will glow blue when the device is receiving power and is connected to an active host. The LED will glow white when the device is connected to a host that is in Sleep or hibernation mode, or when it has power but is not connected to a host. This LED is also connected to a light sensor on the back of the device; this enables the LED brightness to adjust automatically based on ambient lighting conditions.
- The LED has four segments, one for each installed M.2 SSD. When one or more of the SSDs are accessed for read/write operations, the corresponding segments will blink blue.
- While it is possible to connect a DisplayPort 1.2 display to the spare Thunderbolt 3 port on the device by using the appropriate cable or adapter, HDMI and other types of displays require an *active display adapter* with a USB-C host connection.

1.4 About This Manual

The images and descriptions may vary slightly between this manual and the unit shipped. Functions and features may change depending on the firmware version. Screenshot images may vary slightly from the installed operating system. The latest product details and warranty information can be found on the product web page. OWC's Limited Warranty is not transferable and subject to limitations.

1.5 Front View



1. LED array (power and disk activity)

1.6 Rear View



2. Dual Thunderbolt 3 ports
3. Power input
4. Ambient light sensor (do not cover)

MAC & PC SETUP


2.1 Mac Formatting & SoftRAID Information

The pre-installed SSDs have been formatted as a Journaled HFS+ volume for Mac, and configured as a RAID 0 using SoftRAID XT. While you can use the drive without SoftRAID XT installed on your Mac, we recommend you download the application at softraid.com/srxt and install the latest version to get the best performance. The OWC ThunderBlade V4 ships with a license for SoftRAID XT; the serial number is on the bottom of the device.


2.2 PC Formatting Process

Note: all data on the ThunderBlade V4 will be lost when following the steps below. Back up all important data before proceeding.

1. Connect the ThunderBlade V4 to a Windows 10 host using the included Thunderbolt 3 cable, then connect the included power supply.
2. When the 'New Thunderbolt devices...' dialog appears (shown below), click OK. Note: if you are using Windows via Bootcamp, the dialog box noted in this step may not appear. On some PC systems, a secondary dialog may appear after the 'New Thunderbolt devices' dialog and before the dialog shown in Step 3, asking if you want to allow 'Thunderbolt Software' to make changes to the device. Click 'Yes' in that case.




3. The 'Approve Thunderbolt Devices' dialog will appear. Choose the 'Always Connect' option from the menu (shown below) and then click OK.




4. Type 'Create' in the search field next to the Start menu. From the results, choose 'Create and format hard disk partitions' to open Disk Management.

First-time SSD Users


If you've never connected an SSD to your PC before, your Disk Management window will look like the one below (note only 1 of the 4 SSDs are shown - bottom panel). If you have connected SSDs before, skip ahead to the next page.




After a short time the 'Import Foreign Disks' dialog will appear. Click OK.




Next the 'Foreign Disk Volumes' dialog will appear. Click OK.




All four SSDs should appear as they do in the Disk Management window below.



- Type 'Command' in the search field next to the Start menu, then select the Command Prompt result. In the Command Prompt, type (without the marks) 'diskpart' then press Enter. A new dialog box will appear; click 'Yes'. Next, at the DISKPART > prompt type 'list disk' — you should see a screen similar to the one below. Note the numbering of the four identical capacity disks.



6. You now need to clean the disks (this will require you to step through the same process four times). Start with the first disk in the series; in this example we'll use Disk 2 (i.e. the series is disks 2-5). At the DISKPART > prompt type 'select disk 2' and press Enter. You should see a message that the disk has been selected (as shown below). Next, at the DISKPART > prompt type 'clean' and press Enter. You should see a message like the one below.



```
C:\WINDOWS\system32\diskpart.exe

DISKPART> select disk 2


Disk 2 is now the selected disk.

DISKPART> clean


DiskPart succeeded in cleaning the disk.

DISKPART> _
```


7. Once you've repeated the clean command for all four disks, go back to the Disk Management window. Right-click on the first of the four disks listed in Disk Management and select 'Initialize Disk' from the context menu options.




8. From 'Initialize Disk' select all four disks and the 'GPT' option. Click OK.




9. The 'New Striped Volume' wizard will appear. Click the 'Next' button. From the 'Select Disks' dialog, select all three of the disks in the 'Available' section...




.... then click the 'Add' button, then click 'Next'.



10. From the 'Assign Drive Letter or Path' dialog, leave the default setting intact. A drive letter will automatically be chosen, then click the 'Next' button.




11. From the 'Format Volume' dialog, choose the "Format this volume with the following settings" option, then make sure the following are selected: File System: NTFS; Allocation unit size: Default (unless you have a specific reason to use a different setting); Volume label: type a name here; and 'Perform a quick format' should be checked as well. Do not enable compression. Click the 'Next' button.



12. The wizard's summary screen will appear. Click the 'Finish' button. You will then be asked by Disk Management if you are sure you want to continue. Click 'Yes'. Once the formatting process is complete, the ThunderBlade V4 will be visible in the Windows File Explorer. This concludes the PC formatting and RAID 0 setup process.

Notice: Windows 10 does not currently have a method of ejecting Thunderbolt storage devices. Before disconnecting the ThunderBlade V4 from the host computer, please check the LED on the front of the drive to make sure no disk activity is in progress.



3.1 Troubleshooting

If your computer does not recognize the drive when it is connected, make sure the cable is attached securely. You can also try plugging the cable into a different Thunderbolt 3 port on your computer and/or trying a different Thunderbolt 3 cable.

PC users: if you have opened Disk Management but do not see the ThunderBlade V4 SSDs listed, make sure you followed all the steps in Section 2.2 from the start. Multiple permission steps are required for a PC to communicate properly with Thunderbolt 3 SSDs; skipping one or more of those steps may result in the disks not being visible in Disk Management.

3.2 About Data Backup

To ensure your files are protected and to prevent data loss, we strongly suggest that you keep two copies of your data: one copy on your OWC ThunderBlade V4 and a second copy on either your internal drive or another storage medium, such as an optical backup, or on another external storage unit. Any data loss or corruption while using the ThunderBlade V4 (including with SoftRAID XT) is the sole responsibility of the user, and under no circumstances may OWC, its parent, partners, affiliates, officers, employees, or agents be held liable for loss of the use of data including compensation of any kind or recovery of the data.

3.3 Contacting Technical Support



Phone: M–F, 8am–5pm Central Time
(866) 692-7100 (N. America) | +1 (815) 338-4751 (Int'l)



Chat: M–F, 8am–8pm Central Time
www.owcdigital.com/support



Email: Answered within 48 hours
www.owcdigital.com/support

© 2018 Other World Computing, Inc. All Rights Reserved.

OWC and the OWC logo are trademarks of Other World Computing, Inc. registered in the U.S. Patent and Trademark Office and/or in Canada. ThunderBlade is a trademark of Other World Computing, Inc. SoftRAID and the SoftRAID logo are registered trademarks of OWC Holdings, Inc. Apple, Mac, and macOS are trademarks of Apple Inc. registered in the U.S. and in other countries. Thunderbolt and the Thunderbolt logo are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Other marks may be the trademark or registered trademark property of their owners.

R1 11/14/17 DM

OWCQSGBLADETB3W