

## Instruction of Zhong Yi Optics ILDC (Interchangeable Lens Digital Camera)

Thank you for using lens produced by Zhong Yi Optics. Before you use the lens, please read the instruction carefully and thoroughly. If you encounter any problems, feel free to contact us and the information is written at the back of the instruction, or contact the distributors.

Currently, there are two main series lens of Zhong Yi Optics, Speed Master series distinguished in large aperture, and Creator series featured in high cost performance. Both are manual focus and manual aperture adjustment, and manual lens without transferring signals to the camera bodies.

### Lens Installation

Taking off the ear lens caps, then aim the red pot in the lens mount to the the anchor point in the body mount. Inserting the lens into the camera, rotate the lens as the same direction you install the lens. When you hearing the tick sound from the camera body, it means the lens is in the right spot and could be used.

### Usage

Manual lens have different operational approaches in different ILDCs. In this instruction, the usage of Zhong Yi Optics ILDC lens in Sony  $\alpha$  series, Fuji FX series, and M4/3 would be introduced. At the same time, Please read the manual lens usage part in the instruction.

### Usage in Sony $\alpha$ ILDC series:

For now,. Sony ILDCs support manual lens the best, they could use A position ( aperture priority ), and M position ( manual operation ),meanwhile, they could manual focus accurately by magnifying the screen to focus, or achieve manual sharp focusing rapidly via focusing peaking.

When using Zhong Yi Optics ILDC lens, on account of no touch spot in lens connecting with body, therefore you cannot control aperture though body, or though auto focus. You need to set the aperture value by rotating aperture ring manually, and to focus by rotating focusing ring.

**Body setting:** When using Sony ILDC manual lens, set the no-lens-releasing option on body to allow state,

**Usage in Fuji ILDC:**

Fuji ILDC could use A position ( aperture priority ), and M position ( manual operation ). Meanwhile, they could focus through zooming or focusing peaking.

When using Zhong Yi Optics ILDC lens, on account of no touch spot in lens connecting with body, therefore you cannot control aperture through body, or through auto focus.

You need to set the aperture by rotating aperture ring manually, and to rotate focusing ring manually.

**Body setting:** turn on the " no lens filming" model. Press "Q" button and set the focusing to "MF" model.

**Usage in M4/3 ILDC body:**

M4/3 body can use all shooting models except " S" model.

Camera neither can control lens aperture movement, nor focus automatically. Set the wanting aperture through rotating aperture ring, rotate the focusing ring manually, and zoom images in screen to focus.

**Body setting:** turn on the " no lens filming" model.

Inquiring more details, please look the manual lens usage part in this instruction.

**Notices about lens deposit**

Please avoid to exposure the lens in sandstorm, or in dusty environment for a long time.

Nor leave lens in humid environment for a long time, for it would boost mildew growth in lens and affect the usage of lens. Therefore, drying oven is highly recommended in humid environment.

**Tips about lens maintenance**

The lens cap is made of aluminum, therefore it can be wiped by clean cotton cloth with small amount of alcohol.

The lens surface is coated with several high transmittance films, do not scratch, collapse or rub. Blow the dust on the surface while cleaning. Dedicated lens paper dipped with small amount of alcohol and specialized lens cleanser can wipe off the fingerprints, water marks or other stains, along the clockwise direction from the center to the outer edge vortically.

If you find mechanical breakdown in lens or dust inside the lens, please reach to us with the contact information in the instruction, rather than disassemble the product by yourself. Wrong operation may leads to permanent damage.

### **After-sales Service Items**

Zhong Yi lens made by Shen Yang Zhong Yi Optics Technology CO., Ltd. are guaranteed for five years, and life-long maintenance. In guaranteed period if such situation happened, follow the below items.

1. Due to improper use, such as falling, watering, improper saving, repairing or disassembling by yourself or others, damages caused artificially are not included in warranty.
2. Natural disasters, like fire, earthquake, are also not included in warranty..
3. Inside lens cleaning is not included in warranty. Please inquire more relative costs with after-sales service personnel.
4. The given accessories with lens, like lens hood, are not included in warranty.
5. The after-sales service only include relevant items that in the after-sales services, we are not responsible for any claim for compensation that guaranteed. The extent of the damage to the lens is decided by the inspection of the company. Reflections from customers are for reference only.
6. The warranty cards are kept by customers, if lost, will not be replaced.
7. The warranty cards are effective only after stamped by Shen Yang Zhong Yi Optics Technology CO., Ltd.

In addition, the replacements won't put into production, if the lens is revised or stopped production for more than five years. The accessories cannot be changed if replacements run out, we won't inform customers, please understand.

### **Visit the official website for the lens parameters**

#### **contact information and QR code**

Tel 024-25909362

Fax 024-25911545

Address: #66 Yan Fen Road, Tie Xi district, Shen Yang City, Liao Ning Province

website: [www.zy-optics.com](http://www.zy-optics.com) [www.syzygx.com](http://www.syzygx.com)

E-mail: [sy@zy-optics.com](mailto:sy@zy-optics.com) [syzygx@163.com](mailto:syzygx@163.com)

## Warranty card and certificate

The warranty card ( product certificate )

Product model:

Issue date:

Distribution unit:

Username:

Tel:

Address:

