

2 in 1 - Racchetta elettronica + torcia LED
 Pratica racchetta elettronica a tripla rete per eliminare con una scarica elettrica mosche, zanzare ed altri insetti volanti in completa sicurezza e pulizia, senza schiacciarli, senza sporcare le pareti e senza utilizzare prodotti chimici. La rete elettrificata interna a maglie strette riesce ad eliminare anche gli insetti più piccoli. Dotata di luce per uso notturno. La racchetta è alimentata dalla batteria ricaricabile contenuta nella torcia. La torcia è separabile dalla racchetta e può funzionare autonomamente. Dotata di cavo USB per la ricarica.

2 in 1 - Electronic mosquito racket + LED torch
 Electronic mosquito swatter with triple net to eliminate flies, mosquitoes and other flying insects using electric shock. It is completely safe and clean, without squashing the insects, drying walls and without using chemical products. The inner electrified net with close links manages to also eliminate smaller insects. Equipped with lamp for night use. The racket works with the rechargeable battery assembled in the torch. The torch is detachable and can work alone. Equipped with charging USB cable.

ISTRUZIONI IMPORTANTI DA CONSERVARE PER RIFERIMENTI FUTURI
AVVERTENZE
 Utilizzare il prodotto solo per l'uso indicato. Tenere fuori dalla portata dei bambini. I bambini non devono giocare con l'apparecchio. L'apparecchio non deve essere usato da bambini o da persone con ridotte capacità fisiche, sensoriali o mentali o prive di esperienza o della necessaria conoscenza. La pulizia e la manutenzione destinata ad essere effettuata dall'utilizzatore non deve essere effettuata da bambini.
 L'apparecchio è destinato all'uso in ambienti asciutti e non polverosi. L'apparecchio può essere utilizzato solo all'interno dei locali. Non utilizzare in fienili, stalle e locali simili. Non utilizzare in posti in cui potrebbero essere presenti vapori infiammabili o polveri esplosive. Spegnerne l'apparecchio e scollegare la torcia prima di effettuare le operazioni di pulizia.
 Utilizzare esclusivamente la torcia fornita in dotazione per alimentare la racchetta. Per la ricarica della batteria contenuta nella torcia, utilizzare esclusivamente il cavo USB fornito in dotazione ed assicurarsi che la tensione e corrente di ingresso corrispondano a quelli marcati sulla torcia.
NON COLLEGARE ALTRI CAVI O DISPOSITIVI AI CONNETTORI DELLA TORCIA E ALLA RACCHETTA.
 La torcia contiene delle batterie al litio (Li-ion); tenere lontano da fonti di calore e non esporre il prodotto ad agenti atmosferici. Le batterie non sono sostituibili. Non smontare le batterie.
ATTENZIONE: non toccare con parti del corpo o con qualsiasi altro oggetto la rete di scarica mentre è premuto il pulsante (5).

ISTRUZIONI PER L'USO
Carica della batteria
 Posizionare il selettore (8) su OFF (posizione centrale); inserire il connettore tondo del cavo nella spina di connettore piccola della torcia (6). Collegare il connettore USB (10) ad una porta USB type-A. Durante la carica, il LED verde (3) sulla torcia si accende. Quando la batteria è completamente carica, il LED (3) si spegne. Il tempo impiegato per una carica completa (con batteria scarica) è di circa 3-5 ore.
Utilizzo della torcia
 Posizionare il selettore (8) nella direzione della testa LED (9) per accendere la torcia.
Utilizzo della racchetta
 Avvicinare la torcia nella racchetta. Posizionare il selettore (8) nella direzione della racchetta. Per attivare la griglia (1), tenere premuto il pulsante di attivazione (5). Mentre il pulsante è premuto, si accende anche il LED rosso (2). Quando l'insetto passa attraverso la griglia, viene attraversato da una scarica elettrica.
 Tramite l'interruttore (4) è possibile spegnere la luce (9) posizionando sotto la griglia.
 Dopo l'uso, posizionare il selettore su OFF.
PULIZIA E MANUTENZIONE
 Prima di effettuare le operazioni di pulizia della griglia, posizionare il selettore su OFF e scollegare la torcia.
 Eventuali residui di insetti o altri materiali rimasti tra le griglie, potrebbero impedire alla griglia di caricare e di funzionare. Utilizzare un pennellino asciutto o setole morbide per rimuovere gli eventuali residui di insetti. Per la pulizia delle altre parti, utilizzare un panno morbido e asciutto. Non utilizzare acqua o altri liquidi per evitare cortocircuiti.

SMALTIMENTO
INFORMAZIONE AGLI UTENTI
 Informazioni agli utenti ai sensi dell'art. 26 del Decreto Legislativo 14 marzo 2014, n. 49 "Attuazione della direttiva 2012/19/UE sui rifiuti di apparecchiature elettriche ed elettroniche (RAEE)".
 Il simbolo del cassonetto barrato riportato sull'apparecchiatura o sulla sua confezione indica che il prodotto alla fine della propria vita utile deve essere raccolto separatamente dagli altri rifiuti. L'utente dovrà, pertanto, conferire l'apparecchiatura giunta a fine vita agli idonei centri comunali di raccolta differenziata dei rifiuti elettronici ed elettronici. In alternativa alla gestione autonoma è possibile consegnare l'apparecchiatura che si desidera smaltire al rivenditore, al momento dell'acquisto di una nuova apparecchiatura di tipo equivalente. Presso i rivenditori di prodotti elettronici con superficie di vendita di almeno 400 m² è inoltre possibile consegnare gratuitamente, senza obbligo di acquisto, i prodotti elettronici da smaltire con dimensioni inferiori a 25 cm. L'adeguata raccolta differenziata per l'evvio successivo dell'apparecchiatura dismessa al riciclaggio, al trattamento e allo smaltimento ambientalmente compatibile contribuisce ad evitare possibili effetti negativi sull'ambiente e sulla salute e favorisce l'impiego sicuro dei materiali di cui è composta l'apparecchiatura.

SMALTIMENTO BATTERIE
 L'apparecchio contiene delle batterie al litio (Li-ion).
 - le batterie devono essere rimosse dall'apparecchio prima del suo smaltimento;
 - l'apparecchio deve essere scollegato dall'alimentazione quando si rimuovono le batterie.
 Per accedere alle batterie, smontare la vite di chiusura della torcia e rimuovere la ghiera di fissaggio della testa LED. Tagliare i collegamenti delle batterie una alla volta, facendo attenzione a non provocare cortocircuiti.
 - le batterie devono essere eliminate in modo sicuro, in un centro di raccolta specifico.


IMPORTANT INSTRUCTIONS TO BE KEPT FOR FUTURE REFERENCE
WARNINGS
 Use the product only for its intended use. This appliance is to be kept out of reach of children. Children must not play with the appliance. This appliance shall not be used by children or by people with reduced physical, sensory or mental capacities or with a lack of experience and knowledge. Cleaning and maintenance operations must not be performed by children. The appliance is intended to be used only in dry and not dusty environment. The appliance is for indoor use only. Do not use in barns, stables and similar locations. Do not use in locations where flammable vapour or explosive dust is likely to exist. Switch off the appliance and disconnect the torch from the racket before cleaning. The racket has to be supplied exclusively by the torch supplied with the appliance. The torch battery has to be charged exclusively by the USB cable supplied with the appliance; make sure that the input voltage and current corresponds to the ratings marked on the torch. DO NOT CONNECT ANY OTHER CABLE OR DEVICE TO THE TORCH CONNECTOR PLUGS AND TO THE RACKET. The torch contains Lithium batteries (Li-ion); keep the appliance far from heat sources and do not expose to weathering. Batteries are not replaceable. Do not disassemble the batteries. **WARNING:** do not touch, with your body and any other body or objects, the discharge grid while the switch (5) is on.


INSTRUCTIONS FOR USE
Battery charging.
 Set the main switch (8) in OFF position (middle position); connect the round connector of the USB cable (10) on the smaller input plug (6) of the torch. Connect the USB connector (10) to a type-A USB port. During the charging, the green LED (3) on the torch will switch off when battery is full charged. The full charging time (with discharged batteries) is about 3-5 hours.
Torch using.
 Set the main switch in ON position, in the direction of the LED torch (9) to switch on the torch.
Racket using.
 Screw the torch to the racket. Set the main switch (8) in ON position in the direction of the racket. To switch ON the grid, keep pushed the button (5). While the button (5) is pushed, the red LED (2) is light on. When an insect pass through the grid, it will be subjected to an electric discharge. By switch (4), it is possible to activate the grid light.
 After using, set the main switch (8) in off position.

MAINTENANCE
 Before carrying out routine cleaning of the grid, switch off the appliance and unscrew the torch. If insect residu remain between the grids, the grid might not charge and might not work. Use a soft dry brush to remove the insect residu. To clean other parts, use a soft dry cloth. Do not use water or other liquids in order to avoid shortcuits.

DISPOSAL
USER INFORMATION
 Information for users pursuant to Art. 26 of Legislative Decree 14 March 2014, no. 49 "Implementation of Directive 2012/19/EU on electrical and electronic waste equipment (WEEE)". The symbol of the crossed bin on the equipment or on the packaging indicates the product at the end of its useful life must be collected separately from other waste. The user should therefore give the appliance, which is no longer usable, to suitable municipal differentiated waste collection centres for electrochemical and electronic waste. Alternatively, autonomous management is possible by delivering the appliance you want to dispose of to the retailer when purchasing a new equivalent appliance. Electronic wastes with a surface of at least 400 m² can also accept electronic products for disposal with dimensions under 25 cm free of charge, without you being obliged to make a purchase. Appropriate differentiated collection and subsequent sending of the equipment for recycling, processing and disposal, using environmentally compatible means, contributes to avoiding possible negative effects on the environment and health and promotes re-use and recycling of materials used to manufacture the equipment.

BATTERIES DISPOSAL
 This appliance contains Lithium batteries (Li-ion).
 - the batteries must be disconnected from the supply mains when removing the appliance before it is scrapped;
 - to access the batteries, remove the side screw from the torch and unscrew the LED head (9);
 - the appliance must be disconnected from the supply mains when removing the batteries;
 - the cables connected to the batteries, one by one, and pay attention to do not cause short-circuits.
 - the batteries is to be disposed of safely in a suitable separate collection centre.





1- Griglia / grid
 2- Luce griglia / grid light
 3- Spina griglia access / grid ON Led
 4- Interruttore luce / light switch
 5- Pulsante attivazione griglia / grid ON button
 6- Spina per carica USB / plug for USB charging
 7- Spia batteria in carica / battery recharge LED
 8- Interruttore principale / power switch
 9- Testa LED / LED torch
 10- Cavo USB / USB cable

Tensione pericolosa / dangerous voltage