


## Bluetooth® 5.0 Audio Receiver

### Product Diagram (BT52A)



Component	Function
1 DC 5V Port (micro USB)	• Used to connect the <b>Power Adapter</b> to the <b>Audio Receiver</b> .
2 Optical Port	• Used to connect an <b>Audio Device</b> via <b>Toslink® Cable</b> to the <b>Audio Receiver</b> .
3 Audio Out Port	• Used to connect an <b>Audio Device</b> via <b>3.5 mm Cable</b> to the <b>Audio Receiver</b> .
4 LED Indicator (front)	<ul style="list-style-type: none"> <li>• <b>Flash Once:</b> Indicates that the <b>Audio Device</b> is powered and waiting to pair with a <b>Bluetooth Device</b>.</li> <li>• <b>Solid:</b> Indicates that a <b>Bluetooth Device</b> has been paired with the <b>Audio Receiver</b>.</li> <li>• <b>Blinking:</b> Indicates that the <b>Bluetooth Device</b> is disconnected from the <b>Audio Receiver</b>.</li> </ul>

### Requirements

For the latest requirements, please visit [www.startech.com/BT52A](https://www.startech.com/BT52A)

### Powering the Audio Receiver

1. Connect the **Universal Power Adapter** to the **DC 5V Port** on the **Audio Receiver** and the other end to an **AC Electrical Outlet**.
2. The **LED Indicator** will flash once, indicating that the **Audio Device** is powered and waiting to pair with a **Bluetooth Device**.

### Connecting the Audio Receiver

#### Analog

- Connect the **3.5 mm Audio Cable** (included) to the **Audio Out Port** on the **Audio Receiver** and the other end to an **Audio In Port** on the **Audio Device** (audio receiver, etc.)

- or -

- Connect the **3.5 mm Audio Cable** (included) to the **Audio Out Port** on the **Audio Receiver** and the other end to the **RCA Breakout Cable** (included). Then connect both the left and right connectors on the **RCA Breakout Cable** to the left and right **Audio In Ports** on the **Audio Device**.

#### Digital

- Connect the **Toslink Cable** (sold separately) to the **Optical Port** on the **Audio Receiver** and the other end to an **Optical Port** on the **Audio Device** (audio receiver, etc.)

### Pairing with NFC Fast Connection

The **Audio Receiver** is equipped with a standard NFC tag to allow for NFC pairing. NFC allows you to connect a **Bluetooth Device** to the **Audio Device** by touching the **Bluetooth Device** to the **Audio Receiver**.

The maximum distance the **Bluetooth Device** can be from the **Audio Receiver** is 66 ft (20 meters).

**NOTE:** Store the connection data for up to eight **Bluetooth Devices**. Connect and use one **Bluetooth Device** at a time.

1. Ensure NFC is enabled on your **Bluetooth Device**. Check the device's manual for details.
2. Touch a **Bluetooth Device** to the top of the **Audio Receiver** for 3 seconds.
  - **NOTE:** If this is the first time your **Bluetooth Device** has been paired you may receive a message requesting access.
3. The **Bluetooth Device** is now paired, the **LED Indicator** will be solid and audio from the **Bluetooth Device** will output through the connected **Audio Device**.

### Disconnecting from your NFC Device

1. Touch the paired **Bluetooth Device** to the top of the **Audio Receiver** for 3 seconds.
2. The **Bluetooth Device** is now disconnected from the **Audio Device**.

## Manually Pairing a Device

**Note:** If the instructions below do not match your **Device**, please refer to the owners manual for your **Device** for further instructions.

1. From the **Host Bluetooth Device**, select **Settings**.
2. On the **Settings** screen, select **Bluetooth**.
3. Select the **Sider** to activate the **Bluetooth** function.
4. A list of enabled **Bluetooth Devices** will appear. Select the **HD Receiver** from the list.

## Reconnecting a Device

1. Move the **Bluetooth Device** back into the expectable range of the **Audio Receiver** (66 ft or 20 meters).
2. Go back into the **Bluetooth Device's Bluetooth Settings** and select the **HD Receiver** from the list.

### FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

### Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### ISED Statement

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference,
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### IC Radiation Exposure Statement

This equipment complies with IC RSS-102 radiation exposure limit set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0.5cm between the radiator and your body.

### Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Qualcomm aptX is a product of Qualcomm Technologies, Inc. and/or its subsidiaries. Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and other countries.



### Warranty Information

This product is backed by a two-year warranty.

For further information on product warranty terms and conditions, please refer to [www.startech.com/warranty](http://www.startech.com/warranty).

### Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

### Safety Measures

- If product has an exposed circuit board, do not touch the product under power.

### Mesures de sécurité

- Si l'un des circuits imprimés du produit est visible, ne pas toucher le produit lorsqu'il est sous tension.

### 安全対策

- 製品に露出した状態の回路基盤が含まれる場合、電源が入っている状態で製品に触らないでください。

### Misure di sicurezza

- Se il prodotto ha un circuito stampato visibile, non toccare il prodotto quando è acceso.

### Säkerhetsåtgärder

- Rör aldrig vid enheter med oskyddade kretskort när strömmen är påslagen.

### StarTech.com Ltd.

45 Artisans Crescent  
London, Ontario  
N5V 5E9  
Canada

### StarTech.com LLP

4490 South Hamilton  
Road  
Groveport, Ohio  
43125  
U.S.A.

### StarTech.com Ltd.

Unit B, Pinnacle 15  
Gowerton Road  
Brackmills,  
Northampton  
NN4 7BW  
United Kingdom

### StarTech.com Ltd.

Siriusdreef 17-27  
2132 WT Hoofddorp  
The Netherlands

FR: startech.com/fr  
DE: startech.com/de  
ES: startech.com/es  
NL: startech.com/nl  
IT: startech.com/it  
JP: startech.com/jp